

M211316EN-H

Original instructions - RESTRICTED

User Guide

Utilities
IRIS and RDA



VAISALA

PUBLISHED BY

Vaisala Oyj
Vanha Nurmijärventie 21, FI-01670 Vantaa, Finland
P.O. Box 26, FI-00421 Helsinki, Finland
+358 9 8949 1

Visit our Internet pages at www.vaisala.com.

© Vaisala 2021

No part of this document may be reproduced, published or publicly displayed in any form or by any means, electronic or mechanical (including photocopying), nor may its contents be modified, translated, adapted, sold or disclosed to a third party without prior written permission of the copyright holder. Translated documents and translated portions of multilingual documents are based on the original English versions. In ambiguous cases, the English versions are applicable, not the translations.

The contents of this document are subject to change without prior notice.

Local rules and regulations may vary and they shall take precedence over the information contained in this document. Vaisala makes no representations on this document's compliance with the local rules and regulations applicable at any given time, and hereby disclaims any and all responsibilities related thereto.

This document does not create any legally binding obligations for Vaisala towards customers or end users. All legally binding obligations and

agreements are included exclusively in the applicable supply contract or the General Conditions of Sale and General Conditions of Service of Vaisala.

This product contains software developed by Vaisala or third parties. Use of the software is governed by license terms and conditions included in the applicable supply contract or, in the absence of separate license terms and conditions, by the General License Conditions of Vaisala Group.

This product may contain open source software (OSS) components. In the event this product contains OSS components, then such OSS is governed by the terms and conditions of the applicable OSS licenses, and you are bound by the terms and conditions of such licenses in connection with your use and distribution of the OSS in this product. Applicable OSS licenses are included in the product itself or provided to you on any other applicable media, depending on each individual product and the product items delivered to you.

Table of contents

1. About This Document	11
1.1 Version information	11
1.2 Related documents	11
1.3 Documentation conventions	12
1.4 Trademarks	12
2. Product Overview	13
2.1 Introduction to IRIS Utilities	13
2.2 Radar and Antenna	14
2.2.1 Configuring Antenna	14
2.2.2 Monitoring Antenna	15
2.2.3 Testing Antenna	15
2.3 Radar Signal Processor	16
2.3.1 Configuring Signal Processor	16
2.3.2 Calibrating Signal Processor	16
2.3.3 Monitoring Signal Processor	17
2.3.4 Testing the Signal Processor	17
2.4 Viewing IRIS Documentation	17
3. Running IRIS Utilities	18
3.1 Running IRIS Utilities Overview	18
3.2 Running Utilities Locally from a Terminal Window	18
3.3 Running Utilities Remotely from a Terminal Window	19
4. Antenna Utility	21
4.1 Antenna Overview	21
4.2 Invoking Antenna	21
4.3 Antenna Menu	22
4.3.1 Azimuth and Elevation Section	23
4.3.2 Control Panel	25
4.3.3 Status Panel	26
4.4 Antenna Commands	27
4.4.1 RCP I/O Summary	28
4.5 RCP Serial Line Time Reports	29
4.6 Testing Antenna Safeguards	29
4.7 Running Antenna in Sun Tracking Mode	30
4.8 Stable Platform Display	32
4.8.1 Viewing Stable Platform Parameters	34
4.8.2 Sun Tracking Check of Stable Platform Corrections	35
5. Ascope Utility	36
5.1 Ascope Overview	36
5.2 Invoking Ascope	36
5.3 Ascope Menu	37
5.3.1 Antenna Status	38
5.3.2 Display Status	38
5.3.3 Radar Status	40
5.3.4 Processing Status	42
5.3.5 Filters	45
5.3.6 Calibration	47

5.4	Ascope Plots.....	49
5.4.1	Reflectivity Against Range Plot (T and Z).....	49
5.4.2	Doppler Mean Velocity Against Range Plot (V).....	50
5.4.3	Spectrum Width Against Range Plot (W).....	50
5.4.4	ZDR Against Range Plot (ZDR).....	51
5.4.5	Linear Channel A/D Against Range Plot (I and Q or Mag and Arg).....	51
5.4.6	LOG Channel A/D Against Range Plots (ALOG).....	51
5.4.7	Doppler Spectrum Plot (Spec).....	52
5.4.8	Time Series at a Selected Range (I, Q, and LOG).....	53
5.5	Ascope Commands.....	54
5.6	Data Recording and Playback.....	55
5.6.1	Recording Data.....	55
5.6.2	Playing Back Data.....	58
5.6.3	Format of Recorded Data.....	60
5.7	Digital Signal and Target Simulators.....	62
5.7.1	Using the Digital Target Simulator.....	62
5.7.2	Using the Digital Signal Simulator.....	64
5.8	Ascope Checkup Procedures.....	68
5.8.1	Coarse Adjustment of Gain and Offset Pots.....	68
5.8.2	Phase and Amplitude Stability Checks.....	70
6.	Bitex Utility.....	74
6.1	Remote monitoring with Bitex.....	74
6.2	Invoking Bitex.....	75
6.3	Bitex Window.....	75
6.4	Histograms.....	77
6.5	Bitex Commands.....	78
6.6	Exporting BITE Status Information.....	78
6.7	Customizing Bitex.....	81
6.7.1	General Bitex Customization Options.....	82
6.7.2	Using Bitex Customization Tools.....	83
6.7.3	Bitex Panel Options.....	85
6.7.4	Bitex Data Point Configuration.....	85
7.	Color Setup.....	94
7.1	Color Setup Overview.....	94
7.2	Invoking Color Setup.....	94
7.3	Configuring a Color Scale.....	95
7.4	Configuring a Color Set.....	99
7.5	Configuring Special Colors.....	101
7.6	Configuring HydroClass Names.....	102
7.7	Example Color Setup Values.....	103
8.	Dspix Utility.....	110
8.1	Dspix Overview.....	110
8.2	Invoking Dspix.....	110
8.3	Dspix Commands and Prompts.....	110
8.4	Dspix Plots.....	111
8.5	Dspix Chat Mode.....	112
8.6	Sample Dspix Session.....	114
9.	Overlay Utility.....	116
9.1	Overlay Overview.....	116
9.2	Invoking Overlay.....	116
9.3	Listing and Printing Overlay Files.....	122
9.4	Viewing an Overlay Example.....	123

9.5	Format of Overlay Files.....	125
9.5.1	Overlay Header.....	126
9.5.2	Text Strings and Bitmap Icons.....	127
9.5.3	Map Outlines.....	129
9.5.4	Layer Functions and Commands.....	129
9.5.5	Solid Underlay Regions.....	130
9.5.6	GIF Underlay Regions.....	130
9.5.7	Example of an Overlay File.....	132
9.6	Format of Catchment Files.....	134
9.7	Creating and Editing Overlay Files.....	135
9.8	Assigning an Overlay to a Radar Site.....	135
10.	Real Time Display.....	137
10.1	Real Time Overview.....	137
10.2	Real Time Display Data Handling.....	137
10.3	Launching Real Time Display.....	138
10.4	Real Time Display Menu.....	139
10.5	Configuring Real Time Display Transmitter.....	145
10.5.1	Setup Utility Configuration.....	145
10.5.2	Using Rtd_echo.....	145
11.	Setup Utility.....	147
11.1	Setup Overview.....	147
11.2	Invoking Setup and Built-In Error Checking.....	147
11.3	Running Setup After Upgrade.....	149
11.4	Radar Video Processor Setup.....	149
11.4.1	System Type.....	149
11.4.2	Optional Data Parameters.....	151
11.4.3	System Parameters.....	154
11.4.4	RVP calibration.....	156
11.4.5	Signal Processing Options.....	160
11.4.6	Data Simulations.....	161
11.4.7	Pulse Width Definitions.....	162
11.4.8	Custom Trigger Period Sequences.....	164
11.4.9	Setting-up Real Time Display (RTD).....	164
11.5	Radar Control Processor Setup.....	166
11.5.1	Interface to RCP.....	166
11.5.2	Advanced Interface Features.....	170
11.5.3	Packet and Data Logging.....	171
11.5.4	Radar Site and Antenna Placement.....	172
11.5.5	Antenna Characteristics.....	173
11.5.6	Timing Features.....	174
11.5.7	Control Bit Definitions.....	176
11.5.8	Status Bit Definitions.....	178
11.5.9	Network Status Reports.....	181
11.5.10	Radar Status Timing Mode Requests.....	182
11.6	IRIS Input Setups.....	183
11.7	IRIS General Setups.....	186
11.7.1	Modes and Protocols.....	186
11.7.2	Speech and Signaling.....	187
11.7.3	File and System Quotas.....	188
11.7.4	Run-Time Priorities.....	190
11.7.5	Window Alert Configuration.....	190
11.7.6	Radar Site Names and Site Codes.....	191
11.8	License and Site Information Setups.....	192

11.9	IRIS Ingest Setups.....	195
11.9.1	Data Source Selection.....	195
11.9.2	Signal Processing and Data Storage.....	196
11.9.3	Scanning Options.....	197
11.9.4	DSP Noise Sampling.....	200
11.9.5	Transmitter Control.....	201
11.9.6	Clutter Suppression.....	202
11.9.7	Beam Blockage.....	202
11.9.8	DP Intervening Attenuation.....	203
11.9.9	Z-Based Intervening Attenuation.....	203
11.9.10	Target Detection.....	204
11.9.11	Velocity Unfolding.....	204
11.9.12	Velocity Fallspeed Correction.....	205
11.9.13	Storm Relative Velocity.....	205
11.9.14	HydroClass.....	206
11.9.15	Melting Levels.....	207
11.10	IRIS Product Setups.....	208
11.10.1	Product Generation.....	208
11.10.2	Reflectivity Profile and Wind.....	210
11.10.3	Configuring IRIS Status Products.....	211
11.10.4	Product Transmission and Display.....	213
11.10.5	Product Scheduling Priority.....	215
11.10.6	Protected Areas.....	216
11.11	IRIS Output Devices Setups.....	217
11.11.1	Output Device General Specifications.....	217
11.11.2	Printer Specific Parameters.....	218
11.11.3	Window Specific Parameters.....	219
11.11.4	Network Specific Parameters.....	220
11.11.5	Archive Specific Parameters.....	227
12.	Suncal Utility.....	229
12.1	Suncal Overview.....	229
12.2	Invoking Suncal and Options.....	229
12.3	How Suncal Works.....	230
12.3.1	Antenna Scanning Sequence.....	231
12.3.2	BEAM Product Generation.....	231
12.3.3	Processing BEAM Data into Results.....	232
12.3.4	Interactively Updating Configs from Results.....	232
12.4	Using Suncal Results.....	233
12.4.1	Antenna Beam Width Calculation.....	235
12.4.2	Using Results to Calculate Antenna Gain.....	236
12.5	Suncal Configuration File.....	237
12.6	Configuring syslog.conf for Suncal.....	241
13.	RVP and RCP Network Export Utilities.....	242
13.1	Network Export Overview.....	242
13.2	DspExport Overview.....	242
13.3	Starting and Stopping DspExport and AntExport.....	243

13.4	Example Network Configurations.....	246
13.4.1	Example: Separate PC for RVP8, RCP8, and Host (for example, IRIS).....	246
13.4.2	Example: Separate RVP, Combined RCP8 and Radar Server Computer.....	247
13.4.3	Example: Combined RVP, IRIS Host.....	248
13.4.4	Example: AMR with Separate Main RCP8 and Host.....	249
13.4.5	Example: Separate RVP, RCP8, IRIS and a Remote Workstation.....	250
13.5	Non-Network Antenna Angles to RVP.....	252
13.6	RCP8 on Serial Interface.....	253
14.	Zauto Utility.....	254
14.1	Zauto Overview.....	254
14.2	Invoking Zauto.....	254
14.3	Zauto Menu.....	256
14.3.1	Calibration Parameters.....	256
14.3.2	Zauto Calibration Plot.....	257
14.3.3	Calibrate Pane.....	259
14.3.4	Defining Zauto Configuration Parameters.....	261
14.3.5	Zauto Results.....	263
14.4	Zauto Commands.....	264
14.5	Manually Calibrating Signal Processor.....	265
14.6	Automatically Calibrating the Signal Processor.....	267
14.6.1	Calibrating the Signal Processor from Zauto.....	268
14.6.2	Calibrating the Signal Processor from the Command Line.....	269
14.7	Siggen Calibration File.....	269
15.	Zcal Utility.....	272
15.1	Zcal Overview.....	272
15.2	Invoking Zcal.....	272
15.3	Zcal Commands.....	272
15.4	Changing Calibration Reflectivity.....	274
15.4.1	Changing Reference Values.....	274
15.4.2	Writing the Calibration File.....	275
15.4.3	Switching Polarizations.....	275
16.	Zdrcal Utility.....	276
16.1	ZDR Measurement.....	276
16.2	Zdrcal Utility Overview.....	276
16.2.1	How Zdrcal Works.....	277
16.2.2	Typical Use Cases.....	279
16.3	Running Zdrcal from a Command Line.....	279
16.4	Running Zdrcal as an IRIS Exec Task.....	280
16.5	Using Zdrcal Results.....	281
16.6	Zdrcal Configuration File.....	282
16.7	Configuring syslog.conf for Zdrcal.....	287
17.	Network Manager.....	288
17.1	Network Manager Overview.....	288
17.2	Creating Network Manager Authentication Keys.....	290
17.3	Adding a Radar Site to Network Manager.....	290
17.4	Viewing Radar Status Information in Network Manager.....	292
17.5	Updating Radar Site Information for Network Manager.....	293
17.6	Starting or Stopping the ant2nm Service.....	293
17.7	Radar Status Information Available to Network Manager.....	294
17.8	Example ant2nm.ini File.....	295

18. Information Utilities	296
18.1 Productx	296
18.1.1 Invoking Productx	296
18.1.2 Productx Examples	298
18.2 Rays Utility	300
18.2.1 Invoking Rays	300
18.2.2 Headers only Example	301
18.2.3 Velocity Example	302
18.2.4 Extended Header Example	303
19. Using IRISnet	305
19.1 IRISnet Overview	305
19.2 Starting IRISnet	306
19.3 Checking Network Status	306
19.4 Launching IRIS Applications	307
19.5 Checking Application Status	307
19.6 Configuring Application Tools	308
19.7 Using Drawing Tools	309
19.8 Configuring Network Polling	311
Appendix A: References	313
Glossary	315
Technical support	317
Warranty	317
Recycling	317

List of figures

Figure 1	Typical Antenna Installation.....	14
Figure 2	Antenna Utility.....	22
Figure 3	Antenna Azimuth and Elevation Panes.....	23
Figure 4	Antenna Control Panel.....	25
Figure 5	Antenna Status Panel.....	26
Figure 6	RCP I/O Summary.....	28
Figure 7	Antenna in Sun Tracking Mode.....	30
Figure 8	Stable Platform Parameters.....	33
Figure 9	Ascope Utility.....	37
Figure 10	Spectrum Width Against Range Plot Example.....	50
Figure 11	Doppler Spectrum Plot Example.....	52
Figure 12	Time Series at a Selected Range Plot Example.....	53
Figure 13	Record/Playback Menu.....	55
Figure 14	Digital Target Simulator Display and Ascope View Example.....	63
Figure 15	Digital Signal Simulator.....	65
Figure 16	Bitex Transmitter Screen.....	76
Figure 17	Bitex Customization Tools.....	84
Figure 18	Status Data Point Example.....	86
Figure 19	Status QBITE Data Point Example.....	87
Figure 20	Control Data Point Example.....	87
Figure 21	Color Set Configuration Menu Example for Velocity.....	100
Figure 22	HydroClass Name Editor.....	103
Figure 23	Color Configuration Menu Example for Velocity.....	104
Figure 24	Ps Plot Example.....	112
Figure 25	Sample Overlay Display.....	125
Figure 26	Site Overlay Example.....	136
Figure 27	Real Time Display.....	139
Figure 28	RVP System Type Setup Parameters.....	149
Figure 29	RVP Data Parameters.....	151
Figure 30	RVP System Parameters.....	154
Figure 31	RVP Calibration Parameters - Dual-transmitter radar.....	157
Figure 32	RVP Calibration Parameters - Single-transmitter radar.....	158
Figure 33	RVP Signal Processing Parameters.....	160
Figure 34	RVP Data Simulation Parameters.....	161
Figure 35	RVP Pulse Width Definition parameters: Polarization Diversity disabled.....	162
Figure 36	RVP Pulse Width Definition parameters: Polarization Diversity enabled.....	163
Figure 37	RVP RTD Parameters.....	164
Figure 38	RCP Interface Configuration Parameters.....	166
Figure 39	RCP Advanced Interface Configuration Parameters.....	170
Figure 40	RCP Packet and Data Logging Configuration Parameters.....	171
Figure 41	RCP Radar Site and Antenna Placement Configuration Parameters.....	172
Figure 42	RCP Antenna Configuration Parameters - Vaisala Example.....	173
Figure 43	RCP Timing Configuration Parameters.....	174
Figure 44	RCP Control Bit Configuration Parameters.....	176
Figure 45	RCP Status Bit Configuration Parameters.....	178
Figure 46	RCP Network Status Configuration Parameters.....	181
Figure 47	RCP RST Mode Request Configuration Parameters.....	182
Figure 48	IRIS Modes and Protocols.....	186
Figure 49	License Setup Example.....	193

Figure 50	Suncal Exec Task.....	230
Figure 51	Zauto Utility.....	256
Figure 52	Zdrcal Exec Task.....	281
Figure 53	Vaisala Observation Network Manager Main Components and Interfaces (System Delivery).....	289
Figure 54	Example: IRISnet Menu - Network Manager View.....	305
Figure 55	IRISnet Tools Menu.....	308
Figure 56	IRISnet Drawing Tools.....	309
Figure 57	Configure Menu.....	312

List of tables

Table 1	Document versions (English).....	11
Table 2	Vaisala Weather Radar documentation.....	11
Table 3	IRIS Utilities.....	13
Table 4	IRIS Utilities by Function.....	14
Table 5	Coherency Relationships.....	71
Table 6	Bitex status colors.....	74
Table 7	Bitex Command Line Options.....	75
Table 8	Color Scale Data Parameters.....	95
Table 9	Special Colors.....	101
Table 10	Dspix Commands.....	110
Table 11	Overlay Latitude and Longitude Header Commands.....	126
Table 12	Overlay Map Unit Header Commands.....	126
Table 13	Appearance Statements.....	128
Table 14	Map Unit Justification Statements.....	128
Table 15	Screen-relative Justification Statements.....	128
Table 16	String Location and Content Statements.....	128
Table 17	Icon Command.....	129
Table 18	Map Outline Statements.....	129
Table 19	Layer Definition Commands.....	129
Table 20	Solid Underlay Statements.....	130
Table 21	GIF Underlay Statements.....	130
Table 22	Summary of Supported Projections.....	131
Table 23	Catchment File Commands.....	134
Table 24	Subcatchments.....	135
Table 25	Supported IRIS Input Pipes.....	184
Table 26	IRIS Output File Format Options.....	220
Table 27	Supplied IRIS Output Pipes.....	221
Table 28	Copy Scripts Supplied with IRIS.....	226
Table 29	Suncal Command Line Options.....	230
Table 30	Antenna and Sun Beamwidths.....	235
Table 31	DSP Files.....	242
Table 32	RCP Serial Line Input.....	252
Table 33	RVP Serial Line Input.....	252
Table 34	Zcal Commands.....	273
Table 35	Radar Status Information Sent to Network Manager.....	294
Table 36	Raw Product Parameters.....	296
Table 37	Product File Naming.....	296
Table 38	Ray Options.....	301

1. About This Document

1.1 Version information

This document describes how to use IRIS utilities for configuration, calibration, and monitoring, as well as testing the antenna, IRIS, and signal processor.

Table 1 Document versions (English)

Document code	Date	Description
M211316EN-H	April 2021	Eighth version. IRIS 9.1.0.
M211316EN-G	November 2017	Seventh version.
M211316EN-F	September 2017	Sixth version.
M211316EN-E	March 2017	Fifth version.

1.2 Related documents

Table 2 Vaisala Weather Radar documentation

Document code	Name
M211805EN	<i>Weather Radar WRM100/200 Installation and Configuration Guide</i>
M211849EN	<i>IRIS Focus User Guide</i>
M211850EN	<i>IRIS Focus Administrator Guide</i>
M211904EN	<i>IRIS Focus Release Notes</i>
M211315EN	<i>IRIS and RDA Software Installation Guide</i>
M211318EN	<i>IRIS Programming Guide</i>
M211316EN	<i>IRIS and RDA Utilities Guide</i>
M211319EN	<i>IRIS Product and Display Guide</i>
M211317EN	<i>IRIS Radar User Guide</i>
M211452EN	<i>IRIS and RDA Dual Polarization User Guide</i>
M211322EN	<i>RVP900 Digital Receiver and Signal Processor User Guide</i>
M211320EN	<i>Radar Control Processor RCP8 User Guide</i>

Vaisala encourages you to send your comments or corrections to helpdesk@vaisala.com.

1.3 Documentation conventions



WARNING! Warning alerts you to a serious hazard. If you do not read and follow instructions carefully at this point, there is a risk of injury or even death.



CAUTION! Caution warns you of a potential hazard. If you do not read and follow instructions carefully at this point, the product could be damaged or important data could be lost.



Note highlights important information on using the product.



Tip gives information for using the product more efficiently.



Lists tools needed to perform the task.



Indicates that you need to take some notes during the task.

1.4 Trademarks

IRIS™ is a trademark of Vaisala Oyj.

CentOS™ is a trademark of Red Hat, Inc.

Linux® is a registered trademark of Linus Torvalds.

All other product or company names that may be mentioned in this publication are trade names, trademarks, or registered trademarks of their respective owners.

2. Product Overview

2.1 Introduction to IRIS Utilities

IRIS utilities help you manage IRIS system and software. You can configure, calibrate, monitor and test the signal processor, radar, and antenna separately. You can also configure IRIS separately.

While some you can run some utilities while IRIS is running, this is not recommended and usually unnecessary.

Table 3 IRIS Utilities

Utility	Run with IRIS	Description
Antenna	✓	Provides monitoring and control for the RCP antenna controller. Allows keyboard/mouse control of the antenna and radar transmitter/receiver/servo system for testing and verification.
Ascope	-	General purpose data plotting and radar control program where you can display up to 4 plots from the available parameters: <ul style="list-style-type: none"> • Reflectivity against range • Velocity against range • Spectrum width against range • Log, I and Q RAW A/ D samples against range • Log, I and Q time series at a selectable range • Doppler spectrum at a selectable range Useful for diagnosing problems in the Doppler receiver. Used to align the LOG and LINEAR channel A/D converters, verify the system overall, and provide an alternative radar control program for changing pulse width, PRF, clutter filters and data thresholding.
Bitex	✓	Provides detailed configuration and observation of the information reported by the Built-In Test Equipment (BITE).
DspX	-	Helps to debug interface hardware to the signal processor, or debug new software you are developing using the signal processor.
Overlay	✓	Edit and display overlay maps that you develop, so that you can see how they appear when displayed on the real-time display or other products.
Setup	-	Configures the radar software for the characteristics of the radar, such as the number of pulse widths, the duty cycle limits, the radar wavelength, antenna gain, transmit power, and similar. Run this utility first.
Zauto	-	Calibrates the slope and offset of a test signal within a linear range. This information is stored in a file and used during programmed radar collection.
Zcal	✓	Modifies the calibration file.

Table 4 IRIS Utilities by Function

Function	Radar/Antenna	Signal Processor
Configuration Run configuration utilities after installation or after software and hardware updates.	Setup	Setup, Dspix
Calibration Fine-tune the system so that it generates the most accurate data possible. Run calibration utilities periodically or if there is a change to the system hardware.	-	Ascope, Zauto, or Zcal
Monitoring and Testing Overseeing day-to-day system operation to make sure that it continues to function properly. Monitoring and testing is ongoing. Run these utilities regularly or when problems arise.	Antenna, Bitex	Ascope, Dspix

2.2 Radar and Antenna

The radar system connects to IRIS workstations through the RCP (radar control processor). RCP resides in an RVP902 computer that is networked to other computers.

You must configure the relationship between the radar/antenna, RCP, and IRIS during installation. Then you must monitor and test it to make sure it continues to function properly.




Figure 1 Typical Antenna Installation

2.2.1 Configuring Antenna

IRIS utilities and menus let you control the antenna's position and velocity from a remote workstation. For these utilities and menus to work, you must first configure the antenna using the **Setup** utility.

Some of the information you supply in the **Setup** utility comes from the manufacturer's specifications, such as:

- Minimum and maximum elevation that the antenna can reach.
- Maximum azimuth and elevation velocities.
- Warm-up and settle times.
- RCP serial line format.

The **Setup** utility must also know information about the antenna's location, such as:

- Height of the ground in meters.
- Height of the antenna in meters.
- Latitude and longitude of the antenna site.

To save time during configuration, gather this information before running **Setup**.

After the antenna is configured, run the **Antenna** utility to test the connection between the antenna and IRIS.

You should also use the **Antenna** utility to test the antenna's built-in safeguards. These safeguards ensure that the antenna does not exceed its elevation limits. It may require 2 people: 1 to run the utility, and 1 to watch the antenna.

More information

- [Antenna Overview \(page 21\)](#)
- [Setup Overview \(page 147\)](#)

2.2.2 Monitoring Antenna

The **Antenna** utility gives you access to the radar control features, including:

- Setting the azimuth and elevation position and velocity.
- Turning on the transmitter radiate, servo power, and transmitter power.

The **Antenna** utility also displays antenna status information, including:

- Airflow
- Waveguide pressure
- Magnetron current
- Transmitter radiate on, off, and warning status

After installation or routine maintenance, use the **Antenna** utility to test the interface between the antenna and IRIS.

Do not run the **Antenna** utility when IRIS is running because it may interfere with commands that IRIS sends to the radar control processor. Instead, use the **Radar Status** menu, which gives you access to the same antenna status information without interfering with IRIS commands. See *IRIS Radar User Guide*.

2.2.3 Testing Antenna

When analyzing antenna problems, start with the **Antenna** utility's **RCP I/O Summary** menu. It can help diagnose problems on the serial line. For example:

- If the output count is frozen, the computer is not transmitting data.
- If the input count is frozen, there is no I/O coming from the RCP.
- If the error count is incrementing rapidly, you may be using the wrong antenna format or baud rate.

If the I/O and error counts appear normal, the problem is not with the serial line. You should then look at the Antenna status panel, which may show an error or fault for one or more antenna controls.

You can also run the **Bitex** utility to see if the BITE packets are coming across the line. Information in the BITE packets can further pinpoint the cause of the problem.

More information

- [Remote monitoring with Bitex \(page 74\)](#)

2.3 Radar Signal Processor

Radar signal processor (RVP) software triggers radar measurement by producing the trigger signal for the transmitter using the intermediate frequency digital receiver (IFDR) unit in the receiver.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

2.3.1 Configuring Signal Processor

After you install the IRIS hardware and software and before you run the signal processor, you must run the **Setup** utility. This utility provides commands with which you define the parameters of the radar transmitter, so that the signal processor can process the radar information that it receives.

In the Radar Signal Processor (RVP), you define the parameters of the radar transmitter/receiver, including:

- Wavelength
- Pulse width
- Minimum, maximum, and default PRF
- Transmitter, receiver and test signal losses

This information is available in the manufacturer's specification.

More information

- [Setup Overview \(page 147\)](#)
- [Ascope Overview \(page 36\)](#)

2.3.2 Calibrating Signal Processor

When the signal processor is configured, each of the connections between the transmitter/receiver, signal processor, and IRIS must be adjusted and calibrated to ensure the most accurate results.

The RVP Digital Receiver alignment does not require the radar utilities for installation, except for the **Zauto** (or manual **Zcal**) utilities which are used for calibration.

The alignment can be done using the **Dspix** utility.

More information

- [Dspix Overview \(page 110\)](#)
- [Zauto Overview \(page 254\)](#)
- [Zcal Overview \(page 272\)](#)

2.3.3 Monitoring Signal Processor

You can use the **Ascope** utility to monitor the signal processor. It lets you control the antenna position and velocity, sample data either once or continuously, and plot from one to four output parameters in a graphical display. For example:

- Plot the reflectivity and Doppler spectrum to determine how much dynamic range is available in the linear channel for clutter correction.
- Plot the mean velocity against range to make sure the velocity sign is correct.
- Plot the Doppler power spectrum at a selected range to examine weather targets in detail.

2.3.4 Testing the Signal Processor

The RVP signal processor performs a series of self-tests when it is powered up.

The **Dspix** utility can help troubleshoot problems with the signal processor, especially when developing new hardware or software interfaces to the signal processor.

See *RVP900 Digital Receiver and Signal Processor User Guide* .

More information

- [Dspix Overview \(page 110\)](#)

2.4 Viewing IRIS Documentation

To read IRIS product documentation, use the Adobe™ **acroread**™ reader.



For more information on using the reader, select **Help** in the reader window.

1. Launch the **Manuals Menu** by doing one of the following
 - In an **IRIS Menu**, select **Help > IRIS Help**.
 - In IRISNet, select **Manuals > Manuals Menu**.
 - In a terminal window, type: `$ manuals &`
2. Select a document.
The document is context sensitive. Depending upon where you are in the user interface, the document opens either to the table of contents or to the chapter describing the menu.
3. Use PAGE UP, PAGE DOWN, arrows, links, and search to navigate within documents.
4. Use the **Manuals Menu** to switch between documents.

3. Running IRIS Utilities

3.1 Running IRIS Utilities Overview

Utilities can be run in a terminal locally or over the network for remote operation and maintenance.



CAUTION! You must be a radar operator to run the IRIS Utilities. Observers cannot run any utilities that may affect the system configuration or operation.



IRIS and RDA utilities can affect the calibration and operation of the radar system and can only be run by IRIS operators (**radarop**). All the utilities are available on both IRIS and RDA systems.



You can access utilities that use the signal processor without quitting the IRIS program (**service iris stop**).

You can access utilities that use the signal processor without quitting IRIS by setting **IRIS Radar Status Menu > Radar Process** off.

Alternatively, use the **-demo** option which is available for many utilities. This allows you to change and store values. Changes do not take effect until you restart IRIS (**service iris stop** and **service iris start**).

3.2 Running Utilities Locally from a Terminal Window

Use the terminal window if the workstation is connected directly to the signal processor through the Ethernet.

RCP often runs on the same machine. If it is on a separate machine, it is connected the workstation through an Ethernet or serial line.

- ▶ 1. To start a terminal on the local workstation, right-click the desktop and select **New window**.

2. Type the name of the utility followed by any options (for example, **-demo**). Type **&** after the utility name to free-up the terminal after the utility is started. For example:

```
$ ascope -demo &
```

Type utility names in lower case. To view a list of available options, type the name of the utility and the option **-help**. For example:

```
$ ascope -help
```

3.3 Running Utilities Remotely from a Terminal Window

If you are working from a network workstation, you can export a utility display over the network to your workstation.

For example, if you are at a central maintenance facility, you can calibrate or configure a system remotely.



Make sure your communications bandwidth is adequate.
The **Ascope** utility is the most demanding in terms of bandwidth.

1. To start a terminal on the local workstation, right-click the desktop and select **New window**.
2. Use **ssh** to log in to the workstation where you want to run utilities. For example:

```
ssh -X nodename
```

where **nodename** is the host name of the network node you want to go to.



Depending on your security set-up, you may be prompted for a password, or denied access depending. For more information, contact your system manager.

3. Assign the display to show your system by typing:

```
$ export DISPLAY= mynodename:0.0
```

where **mynodename** is the host name of the workstation that you are on.

4. Type the name of the utility followed by any options (for example, **-demo**). Type **&** after the utility name to free-up the terminal after the utility is started. For example:

```
$ ascope -demo &
```

Type utility names in lower case. To view a list of available options, type the name of the utility and the option **-help**. For example:

```
$ ascope -help
```

4. Antenna Utility

4.1 Antenna Overview

The **Antenna** utility allows you to manually control and monitor the radar and antenna. The radar host computer communicates with the Radar and Antenna system over a serial line connected to the radar/antenna control processor (RCP). The **Antenna** utility allows you to communicate easily with the RCP to test the features of the RCP and its interface to the radar system, including:

- Setting both the Azimuth and Elevation positions or velocities.
- Turning the servo and the transmitter radiate and cabinet powers on and off.
- Checking the Computer/Local switch position.
- Checking the status of the cooling airflow, waveguide pressure, transmit Radiate/OFF/Warning status, magnetron current, and time stamp.
- Tracking the movement of the sun.



Not all of the readouts and controls, described in this chapter, are available on all systems.

At a new installation, or after extensive maintenance, you should run the **Antenna** utility before running IRIS to test the interface between the IRIS host computer and the RCP.

4.2 Invoking Antenna

Antenna is an operator privileged program for experienced maintenance personnel. IRIS observers and others are not permitted to run this utility.



CAUTION! Use caution before running the antenna. Make sure the area surrounding the radar antenna is clear of personnel, who may be injured by the antenna motion or exposed to radiation.



CAUTION! To avoid damage to the antenna, use **Setup** to configure the antenna limits and signal processor pulse widths.

Do not run the **Antenna** utility while IRIS is running because of the possibility of interference with IRIS commands to the RCP.

During IRIS operation, most of the monitoring information available in the **Antenna** utility is shown in the **IRIS Radar Status** menu.

- 1. In the command line type: **antenna&**

4.3 Antenna Menu




Figure 2 Antenna Utility

Azimuth and Elevation panes

Controls the azimuth and elevation positions and velocities for the antenna.

Control Panel

Turns the transmitter, radiate, servo, signal generator, and continuous wave powers on and off.

Status Panel

Displays the status of the radar and RCP.

The title bar contains the current date and time so that this information can be saved on menu printouts.

4.3.1 Azimuth and Elevation Section




Figure 3 Antenna Azimuth and Elevation Panes

Azimuth Position Indicator

To set the azimuth position, move the arrow along the edge of the position indicator. The pointer displays the movement of the antenna to the new position.

Elevation Position Indicator

To set the elevation position, move the arrow along the edge of the position indicator. The pointer displays the movement of the antenna to the new position.

Mode

The **Antenna** utility can operate in the following modes:

- **Position**
Enables setting the azimuth or elevation position.
- **Velocity**
Enables setting the azimuth or elevation velocity.
- **Sun Tracking**
Invokes a sun tracking procedure, which computes the direction to the sun from the radar location, and positions the antenna there. See [Running Antenna in Sun Tracking Mode \(page 30\)](#).

Stop

Select **Stop** to stop antenna movement, regardless of the current mode. The antenna slows to a stop as indicated by the pointer within the position indicator.

The stop light is red when the antenna is stopped and green when the antenna is running.

Sun Tracking

The blue and yellow **Sun Tracking** button puts the antenna into the Sun Tracking mode.

Select this button again to exit **Sun Tracking** mode.

Sun Tracking

While in **Sun Tracking** mode, before moving the antenna you can enter an offset to be added to the sun's position the **Error** field allows.

Sliding Scale

The sliding scales set the requested velocity for either the Azimuth or Elevation position. The scale has a "tick" at velocity 0. For the Azimuth velocity, positive speeds are for clockwise scanning while negative speeds are for counterclockwise scanning. For the Elevation velocity, positive speeds are for upwards scanning (toward the zenith), while negative speeds are for downward scanning (away from the zenith).

Position: Actual and Requested

The screen displays both the actual and requested position of the antenna, as they may differ.

When the antenna is in the Position mode, you may enter a position (in degrees) in the **Request** field. Both the Azimuth and Elevation positions can be observed to change and ultimately end up at or near the requested positions:

- Azimuth positions range from 0 ... 360°
- Elevation angles beneath the horizon are displayed as negative numbers.



The RCP has its own "soft" elevation limits. If the antenna elevation does not move all the way up or down, to fulfill a position request, the request may be outside the limits imposed by the RCP. Consult with your manufacturer if you are unsure.

Some RCPs cannot move both axes of the antenna, in a velocity servo, at the same time. On these systems, the following message may be displayed at your request:

WARNING: Bad Combination of Servo Types.

Velocity: Actual and Requested

The screen shows both the actual and requested velocities of the antenna, as they may differ.

When the antenna is in the Velocity mode, you may enter a velocity in the **Request** field. Enter the speed as a signed number (in degrees) per second. Six degrees per each second is equivalent to 1 RPM:

- For the Azimuth velocity, positive speeds are for clockwise scanning while negative speeds are for counterclockwise scanning.
- For the Elevation velocity, positive speeds are for upwards scanning (toward the zenith), while negative speeds are for downward scanning (away from the zenith).

If a velocity request exceeds the maximum velocity allowed by the configuration, set in the **Setup** utility, then the maximum velocity is substituted.

For example: If the upper limit in the **Maximum Elevation** field of the RCP section is 80° and you enter an elevation position of 90°, the **Request** field displays 80° and the antenna increases to that elevation. See [Antenna Characteristics \(page 173\)](#).

During installation, you must test this feature to verify that the protection is functioning properly. See [Testing Antenna Safeguards \(page 29\)](#).

Velocity and Increment

To set the **Velocity** field with the sliding scale, click inside the scale to move the slider.

To make fine adjustments, set the **Increment** field to 0.1 and click until the correct value appears in the **Request** field.

Platform Parameters

Use these parameters to manage the setting for moving platforms such as the pitch, the roll, and the heading angles and velocities.

More information

- [Stable Platform Display \(page 32\)](#)

4.3.2 Control Panel




Figure 4 Antenna Control Panel

The **Control Panel** controls the transmitter receiver and radiate, the servo, and the signal generator powers. The indicator lights changes from red to green, indicating if the power is off or on.

TR Power

Requests the RCP to turn the main power on or off to the transmitter/receiver. When the power is off, many of the sensed status fields are reported as faults.

Radiate



CAUTION! Do not turn on radiation until you are sure personnel cannot be exposed to microwave radiation.

Requests the RCP to turn the transmitter radiate on or off. If there is a problem with a subsystem, such as the waveguide pressure or cooling airflow, the RCP may not grant a radiate request.

Servo Power

Requests the RCP to turn the antenna servo amplifier on or off. When the servo power is turned off, the antenna position cannot be controlled.

Signal Generator

Toggles the calibration signal generator on or off while the sliding scale sets the power level. Status fields display the current state of the **Signal Generator**, such as **ON** and **OK**. Other status fields indicate the power-level setting.

Continuous Wave

Toggles between continuous and pulse mode.

Noise Source

Turns the noise source on and off within the radar receiver. This is usually done for testing purposes only.

4.3.3 Status Panel

Status Panel			
Antenna Mode	N/A	TR Mode	Computer
Standby	Ready	Interlock	Normal
Magnetron	Normal	Waveguide	Normal
Air Flow	Normal		
Pulse Width	1.0 1.0	RCP Status	Computer
Polar	H&V H&V	RCP Reset	RESET

Figure 5 Antenna Status Panel

Ant Mode and TR Mode

The antenna and transmitter modes show the position of the control switch on the radar console and indicate when IRIS is collecting radar data:

- **Computer**
The computer controls the antenna and RCP.
For normal operation, set the **TR Mode** to **Computer** and the **Antenna** mode to local mode.
- **Local**
Antenna control requests from the computer are ignored, and the antenna is controlled manually using handwheels or a terminal connected to the RCP.
This mode is used for testing though, on some systems, you may record manual scans and run **Ascope** in local mode.
- **IRIS**
Status when IRIS is controlling the antenna to record data. The control switch is set to **Computer**.

Other Status Indicators

Other status indicators report OK, Ready, or Fault. Not all systems have the same status indicators, but the following are typical on most systems:

- **Air Flow** refers to the flow of cooling air in the transmitter/receiver cabinets. This is usually sensed by a vane switch.
- Waveguide pressure is usually sensed by a pressure transducer.

- **Interlock** refers to the interlock on a door that protects a high-voltage or radiation hazard.
- **Magnetron** displays whether or not the magnetron current is within normal limits.

During installation, check the **Antenna** utility to verify that the sensors are properly installed and reporting to IRIS.

Pulse Width

- The first number is the pulse width that is currently being requested by the host computer.
- The second number is the pulse width status reported back from the RCP to the host computer.

The pulse widths here are referred to by index rather than microseconds. IRIS supports up to 4 pulse widths and the indices are labeled 0, 1, 2, 3. Most systems only use 2 pulse widths (0 and 1).

In most systems the RCP controls the pulse width. In this case you can use the control button next to the pulse width status field to change the pulse width. The selection menu displays both the index and the value in microseconds.

For systems where the signal processor controls the pulse width, this button cannot be used to change the pulse width. The proper request and status is reported however. Note that in this case the **Ascope** utility can be used to change the pulse width.

RCP Status

Indicates whether the RCP has shut down by displaying either **OK** or **Shutdown**.

RCP Reset

The **RCP** button resets the antenna controller. The button takes the antenna controller out of the shutdown state.

4.4 Antenna Commands

The **Antenna** utility provides the following commands:

Options

I/O Summary shows a summary of antenna I/O operations.

Time Set sets the system clock.

Stable Platform Params adds a center portion to the display which shows information such as heading, pitch, roll related to shipboard or airborne applications.

Print

Print creates an X-window dump of the menu you are running, as follows:

- **Print > to Printer** sends the output to the postscript or color printer specified in the **Printer Setup** menu.
- **Print > to File** sends the output to a file in your default home directory.

- **Print > Setup** lets you configure the printer on your system.

Exit

Exit exits the utility.

Help

On Utility displays information about the utility.

Contents and **Index** provide access to the online help.

More information

- [Stable Platform Display \(page 32\)](#)

4.4.1 RCP I/O Summary

Select **Options > I/O Summary**, the **Antenna** utility displays a summary of the information gathered by the antenna process.

When the IRIS or **Antenna** utilities first run after boot-up, an internal antenna process starts in the IRIS host computer. This process monitors I/O to the RCP, runs until it is stopped by a **qant** command or until the computer shuts down.




Figure 6 RCP I/O Summary

RCP Status

The status of the RCP, either **OK** or **Shutdown**.

Update Time

The time in seconds since the last update was received from the RCP by the antenna process.

Input Count

The total number of bytes read by the antenna process since it was started.

Output Count

The total number of bytes written.

Error Count

The total number of bytes received that were discarded because of an error.

4.5 RCP Serial Line Time Reports

The RCP serial line can receive time reports. You can check the time sent from the RCP and the time error between the host system time and the RCP time. You can also reset the system time to match the time reported from the RCP or configure automatic time updates.



All automatic updates by IRIS are made only if the time error is 2 ... 5 seconds. This compensates for the slow drifts that are typical of computer clocks. However, when automatic time setting is first invoked, there is usually an error greater than 5 seconds. In this case, the **Time Set** menu is a convenient way to force synchronization, after which the automatic time resetting tracks the time.

- ▶ 1. For the question **Operating system's time**, select **Setup > General**.
See [IRIS General Setups \(page 186\)](#).
2. To show RCP time settings, select **Options > Time Set**.
 - Last Reported Time**
The last time report that was received from the RCP.
 - Seconds from Last Report**
The number of seconds elapsed since the last time report.
 - Time Error**
Defined as the system clock minus the RCP time, for example, for positive numbers the system time is fast.

If the fields are blank, then you are not receiving the time from the RCP. Check with your system manager to see if your RCP has this feature.
3. If the time is received from the RCP, select the **Set Time** button to reset the system time to match the RCP time.

4.6 Testing Antenna Safeguards

The host computer provides no elevation limit protection in the velocity servo mode. Protection is provided by the RCP. You must use the **Antenna** utility to verify with the that the RCP provides limit protection.

All antenna systems are equipped with safeguards against damaging the antenna during elevation scanning. During installation these safeguards may not be in place.

After installation, you must test the safeguards with the **Antenna** utility.

- ▶ 1. The first time you use elevation velocity scanning, position an observer safely near the antenna to watch and listen for signs that the antenna drive is trying to push against the stops.
2. In the terminal prompt, type **antenna&**
3. Set the antenna controls as follows:
 - a. Set the elevation position to 75.
This positions the antenna elevation close to the upper limit.
 - b. Set the **Elevation Velocity** field to 5° per second (first + then -) to move the antenna slowly up, then down.



CAUTION! For the safety of the observer, be ready to stop the antenna if there is a problem.

4. Start the antenna and be prepared to stop.
5. Make sure you hear the antenna drive stop when the RCP soft limit is encountered. The soft limit must be encountered before the limit switch is encountered. If the antenna tries to power up past the soft limit, you must signal the operator to stop the antenna.

4.7 Running Antenna in Sun Tracking Mode




Figure 7 Antenna in Sun Tracking Mode

In sun tracking mode, the **Antenna** utility computes the direction to the sun from the radar location and positions the antenna there.

The purpose of the sun tracking mode is to test the alignment of the radar pedestal.

Because the sun is a black body radiator, it transmits microwaves that you can detect with your radar, even through the clouds.

The test consists of moving the antenna until you get the maximum return from the sun and then comparing the pedestal angles with the known position of the sun.

- ▶ 1. Stabilize and tune the antenna.
The antenna must accurately go to a requested position to within less than 0.2°.
2. Set your system time.
Vaisala recommends that you set the time to within a second of the correct time, though a 10 second error gives only a 0.05° error.
If you are using time synching, such as **ntp**, set the time on the server system or turn synching off.
3. Verify that your latitude and longitude are set correctly.
For a shipboard radar:
 - a. Run **Antenna**.
 - b. Select **Options > Stable platform params**.
 - c. For systems without an INU, check **setup/rcp**.
See [Radar Site and Antenna Placement \(page 172\)](#).
4. Perform the test when the sun is low in the sky.
At high elevations, the sun is so wide in azimuth that you cannot measure the azimuth offset accurately.
5. Configure and save a sun-track mode for **Ascope**.
We recommend turning off range normalization, displaying T only, sample size of 256.
6. In **Antenna**, start sun tracking mode by selection the sun icon.
In sun tracking mode, the position indicators are yellow circles displaying the sun's current azimuth and elevation positions.
 - a. Using the **Increment** menus, set the azimuth and elevation steps to 0.5°.
 - b. Select either side of the yellow dot on the control panes to change the azimuth and elevation offsets until you find the sun.
The power displayed on **Ascope** should be several dB above the noise.
 - c. Check the **Request** field that displays the azimuth and elevation settings of the antenna.
The utility updates the position every 10 seconds, which usually produces a change of about 0.01° on both axes.
 - d. If needed, use the **Errors** field to specify an offset to add to the sun's position before moving the antenna so you can correct for errors.
7. Set the step to 0.2°.
 - a. Make a pass through each axis.
 - b. Make a table of the power against angle error.
You should be able to determine the error at the peak.

8. Repeat the same test with the sun in a different azimuth direction (morning against afternoon).
This allows you to differentiate a tip in the pedestal from a fixed offset.
9. Enter the measured errors in your antenna controller.
If you are unable to find the sun manually with small offsets, it may be because of a large unknown offset.
If the weather is clear, you may be able to spot the sun on the antenna to indicate the correct direction.
Alternatively, configure an IRIS sector scan centered on the sun and see if you can spot it on the real-time display. For RCP:
 - a. Enter TTY setups
 - b. Enter the **axis azimuth** command and set the **Input offset from true orientation**.
 - c. Type the measured error value.
 - d. Do the same thing for the axis elevation.
If there was a non-zero offset before, you must add the new error to it.

4.8 Stable Platform Display

Antenna > Stable Platform Parameters parameters are for shipboard or airborne applications where the antenna is stabilized by a radar control processor that is connected to an inertial navigation unit (INU).

The INU provides high-speed accurate information on the attitude (heading, roll and pitch) and position (East-West, North-South and height) of the ship.

The RCP uses this information to correct the antenna scanning for the ship motion, that is, the RCP moves the antenna in 'earth-relative coordinates' just as if the antenna were not on a moving platform. The concept of 'pedestal-relative coordinates' refers to how the antenna is moving relative to the pedestal, or since the pedestal is mounted on the ship, relative to the ship.

Since the motion of the ship effects the Doppler velocity, the **Antenna** utility also calculates the velocity correction that is required to remove the effect of ship motion.




Figure 8 Stable Platform Parameters

Attitude and Change

Train-order and elevation-order angles are displayed including the platform-relative pointing angles of the antenna pedestal.

- **Heading**
The angle in which the bow of the ship points measured positive toward true North. Positive angles are clockwise.
- **Pitch**
The up/down angle of the bow of the ship relative to the horizon. Positive angles are bow down.
- **Roll**
The up/down angle of the side of the ship (normal to the long axis of the ship) relative to the horizon. Positive angles are port (left looking forward) side down.

Each of the above parameters are associated with rates of change in degrees/second.

Position and Velocity

The motion of the INU is described in the middle section of the display as shown below.

- **Long/EW and Lat/NS**
Standard conventions are used for North/South and East/West.
- **Height (m)**
The height of the INU rather than the antenna in meters above sea level.
- **Ship Vel m/s**
The speed (vector (3D) velocity) of the INU, or the center of the ship in meters per second.
The first entry is positive east, the second entry is positive north and the third entry is positive up.

- **Ant Vel m/s**

The 3D vector velocity of the antenna feed in meters per second. Generally different from the INU velocity.

The difference between the ship velocity and the antenna velocity is because the INU and the antenna feed are usually not co-located, that is, there is a moment arm between them. When the ship pitches, rolls and yaws, this moment arm induces a velocity.



The INU is not assumed to be at the center of rotation of the ship. If you imagine yourself on a tall mast of a ship where antennas are typically mounted, the rocking of the ship is amplified by the mast. If the INU is located on the deck and the antenna is aloft, this difference is important.

Pedestal Angles and Velocity Correction

Although the RCP corrects the antenna scanning for the motion of the ship, sometimes it is important to see the antenna position relative to the pedestal.

When the ship motion is severe, the antenna may be unable to achieve an earth relative elevation because the antenna encounters an elevation limit of the pedestal.

- **AZ**

The azimuth angle of the antenna relative to the bow of the ship. Positive values are clockwise from the bow.

- **EL**

The elevation angle of the antenna relative to the deck of the ship.

- **VCOR**

The Doppler velocity correction required to compensate measured Doppler velocities for the ship motion.

The displayed velocity correction (**Vcor**) represents the velocity correction in meters per second that must be applied to the Doppler rate.

The **Vcor** computed by a dot product of the antenna velocity with a unit vector pointing in the direction of the antenna.

More information

- [Antenna Commands \(page 27\)](#)
- [Azimuth and Elevation Section \(page 23\)](#)

4.8.1 Viewing Stable Platform Parameters

Invoke the display if your system is configured for shipboard operation with an inertial navigation unit (INU), that is, the RCP data format **RCV03** with shipboard information is selected in the **Setup** utility.

- ▶ 1. Select **Options > Stable Platform Params.**
- The **Antenna** utility display changes to show:
- **Stable Platform Parameters** panel
 - On the **Azimuth** panel, a small yellow triangle on the outside of the compass ring denotes the ship's heading.
In the example, the triangle is at 290°.
 - On the **Elevation** panel:
 - The solid red arrows show the earth relative antenna positions. This is the same as if the antenna were not on a moving platform.
All antenna scan velocity and position requests are made in earth-relative coordinates. This means that the **Antenna** utility for a moving platform behaves in a manner identical to the fixed platform case.
The RCP makes the necessary corrections to the scanning.
 - The yellow outline arrows show the pedestal relative antenna positions.
In the example, the ship is heading 290.85° and the earth relative position is 217.62. The pedestal (ship) antenna position is 283.97°.



Shipboard features on the **Azimuth** and **Elevation** panels are display-only.

4.8.2 Sun Tracking Check of Stable Platform Corrections

In sun tracking mode, the antenna should track the sun regardless of the ship motion.

You can use the **Ascope** utility, digital power meter, or oscilloscope to monitor the received power.

This is an excellent final check on the stabilization of an antenna system on a moving platform.

5. Ascope Utility

5.1 Ascope Overview

The **Ascope** utility is a diagnostic and test utility for aligning and testing the radar and signal processor.

Ascope also provides a standalone radar display and control capability. Displays of the signal processor output data, such as a single Doppler spectrum, time series, or raw A/D samples are generated against range in a graphical format.

During **Ascope** operation, the antenna is usually controlled by hand wheels or the **Antenna** utility to select interesting targets.

5.2 Invoking Ascope



CAUTION! Before running **Ascope**, you must run the **Setup** utility to install the proper wavelength and pulse width configurations. The latter is especially important for duty cycle limit protection.

1. In the command line, type: **ascope&**
If needed, use one of the available command options:

Option	Description
<filename>	Preload a saved configuration.
-demo	Runs Ascope without the signal processor, for testing and demonstration purposes.
-step	Start Ascope in single-step mode.
-stats	Display additional signal statistics.
-delay millisec	Set delay between rays (default 200).
-display DispName	Move ASCOPE to another display device.

If **Ascope** cannot communicate with the signal processor (for example, if the signal processor is not turned on), it displays an error message.
If this happens, repair the problem and restart **Ascope**.

5.3 Ascope Menu




Figure 9 Ascope Utility

Antenna Status

Shows information about the antenna status.

Display Status

Freezes and resumes the display and set display parameters, such as the plotted data.

Radar Status

Shows radar status information, such as the PRF and pulse width settings.

Processing Status

Shows information about the processing mode and other processing options.

Filters

Sets the Doppler, LOG, Speckle, and Threshold filters.


Calibration

Shows information about DSP calibration. You can take noise samples or set A/D converter offsets and gains.

More information

- [Ascope Plots \(page 49\)](#)

5.3.1 Antenna Status



Antenna

Displays the antenna status as one of the following values:

- **OK**

The antenna is functioning properly.

- **Dead**

No data has been received from the RCP for at least five seconds.

Select the button to start the **Antenna** utility. See [Antenna Overview \(page 21\)](#).

Time

Shows the time between successive frames of the display.


Azimuth

Shows the current azimuth of the antenna. Tag lines must be wired for this.

Elevation

Shows the current elevation of the antenna.

5.3.2 Display Status



Freeze/Resume

Freezes or unfreezes the display, and stops or starts the signal processor. The green light indicates that the display is not frozen and the signal processor is running; the red light indicates that the display is frozen and the signal processor is not running.

Plot Parameters

Shows the currently selected plot parameters. Select the button to launch the **Plot Parameters** menu, where you can select from one to four plots displayed in the order you choose.

You can set up to 8 parameters can be selected at once. The first 4 are plotted on the display. See [Data Recording and Playback \(page 55\)](#).

Plot vs Range				Bin Plots
Tot.Z <input checked="" type="checkbox"/>	LDRH <input type="checkbox"/>	Tot.Zhv <input type="checkbox"/>	LOG <input type="checkbox"/>	LOG <input type="checkbox"/>
Cor.Z <input type="checkbox"/>	LDRV <input type="checkbox"/>	Cor.Zhv <input type="checkbox"/>	I <input type="checkbox"/>	I <input type="checkbox"/>
Vel <input checked="" type="checkbox"/>	PhiH <input type="checkbox"/>	PMI <input type="checkbox"/>	Q <input type="checkbox"/>	Q <input type="checkbox"/>
Width <input type="checkbox"/>	PhiV <input type="checkbox"/>	LOG <input type="checkbox"/>	Mag(IQ) <input type="checkbox"/>	Mag(IQ) <input type="checkbox"/>
SQI <input type="checkbox"/>	RhoH <input type="checkbox"/>	CSR <input type="checkbox"/>	Arg(IQ) <input type="checkbox"/>	Arg(IQ) <input type="checkbox"/>
SNR <input checked="" type="checkbox"/>	RhoV <input type="checkbox"/>	CCOR <input type="checkbox"/>		Mag Spec <input type="checkbox"/>
ZDR <input type="checkbox"/>	Flags <input type="checkbox"/>	Ah <input type="checkbox"/>		Arg Spec <input type="checkbox"/>
KDP <input type="checkbox"/>	HClass <input type="checkbox"/>	Av <input type="checkbox"/>		
PhiDP <input type="checkbox"/>	Tot.Zv <input type="checkbox"/>	Azdr <input type="checkbox"/>		
RhoHV <input type="checkbox"/>	Cor.Zv <input type="checkbox"/>			

Choose the plot parameters you want to display.

If you specify fewer than 4, the specified plots are displayed.

If you specify more than 4, only the first four are displayed.

If you select **Clear**, no parameters are selected and **Ascope** displays one plot: the reflectivity against range plot.

Max Range

Shows the maximum range plotted for the selected plot parameters. You can also specify a new maximum range by entering any number or choosing from a menu. If the specified **Max Range** exceeds the unambiguous range, then the unambiguous range is substituted. The maximum range is constrained to be an integer multiple of the signal processor resolution multiplied by the number of range bins.

Menu choices are: 20, 40, 60, 120, 240.

Range Strobe

Shows the value of the selected range for the spectrum and time series plots, as well as the range for the numerical values displayed in the parameter against range plots. This range is also used for noise samples. The **Range Strobe** is displayed in the plots as a vertical red line. You can change the value of the **Range Strobe** field and the position of this line in a number of ways:

- Enter a value directly in the field, and the line is moved to the new position. If the range you enter exceeds the Max Range, then the value for the **Max Range** field is substituted, and the vertical line is displayed at the far edge of the plot.
- Click the left mouse button in the plot. The vertical line moves to that location and the value of the **Range Strobe** field is updated to the new value.
- Use the right or left arrow keys to move the line to the right or the left. The value of the **Range Strobe** field is updated to the new value.

The **Range Strobe** is rounded to exactly hit the nearest processed range bin.

Number of Bins


Shows the number of range bins being plotted. Select the button to select the number of acquired bins.

The maximum value that this field can have depends on the signal processor.

The number of bins determines the number of points plotted on the parameter against range plots, including the Z, T, V, W, AI, AQ, and ALOG plot parameters.

Reducing this value can increase the update rate because less data needs to be transferred. This is useful when more rapid updates are required, especially for serial line graphics displays.

5.3.3 Radar Status



PRF

Shows the current PRF selection in pulses per second.

- The left box shows the requested PRF.
- The right box shows the measured PRF.

You can set these fields to any number between the minimum and the duty cycle limit, or choose a value from the menu (Options are: 250, 300, 500, 600, 1000, 1200).

In configurations using an external trigger these numbers may differ.

The value shown is the higher PRF if dual PRF is selected.

The PRF should be set to 300 or greater when using alternating polarization.



Ascope automatically limits the PRF to be within the duty cycle limit of the transmitter as configured in the **Setup** utility.
You must run the **Setup** utility before running **Ascope**.

Dual PRF

For automatic velocity unfolding. This field shows **None**, **3:2**, **4:3**, or **5:4**.

When you change this value, the velocity limits on the data plot are changed appropriately. Note that the PRF displayed as part of the status is the higher PRF rate.

If any plots require time series, **Dual PRF** is set to **None** (no unfolding). There is no unfolding when **I**, **Q**, **L**, **AI**, **AQ**, **ALOG**, or **Spec** displays are plotted.

Pulse Width

Shows the current pulse width in microseconds. You can change the pulse width can be changed by selecting an option from the menu.

Note that this uses the pulse width signal lines of the signal processor and/or the antenna controller to set the pulse width. When switching longer pulse widths,

Ascope automatically lowers the PRF as required to stay within the duty cycle limits established in Setup.

Gain Control

Shows type of gain control used.

Select this field to change the gain control scheme. In the **Gain Control** menu, select one of the following:

- **AGC**
Automatic gain control
- **STC**
Sensitivity time control
- **Fixed dB**

Gain at a fixed level of attenuation.

When you choose **Fixed dB** when you are running in IAGC mode, you can enter 1 ... 3 dB levels. **Ascope** cycles between these settings.

Select **OK** to close the menu.


Polarization (available with ZDR option)

Displays the transmitted polarization and lets you set the polarization and switching scheme. Box is desensitized on single polarization systems.

Options: **Horizontal**, **Vertical**, **H+V**, or **Alternating**.

5.3.4 Processing Status

Processing



Gen Setup

Pulse Samp

Range Avg/Smth

LOG Rng Norm ☐

Spect Size


Spect Avg

Spect Win

General Setup

Shows a menu displaying the current processing mode and options. You can use this menu to switch between major modes of the RVP (such as PPP and FFT), and to select other processing options.

- **R2 Algorithms** button
Selects whether the computation for spectral width uses three correlation lags (R0, R1, and R2), or only 2 (R0, and R1).
- **Clutter Microsuppression** button
Enables the algorithm for removing suspected clutter bins from a run of range averaged samples.
- **16-Bit Time Series** button
Instructs **Ascope** to read extended precision samples during the time series modes. It should generally be pressed ON. The OFF position causes 8-bit fixed point data to be read.
- **Spectra from DSP** button
Causes the **Ascope** spectrum plot to be drawn from spectral components that are read directly from the DSP, rather than internally computing those components from the raw time series.
The DSP spectra are often interesting during major modes that employ spectral filtering (such as the FFT and Random Phase modes).
- **Type of Spectra** button
Is sensitized only in Random Phase major mode and only if spectra are being read directly from the DSP. This button pops up a menu of 8 power spectra and lets you view the data as they progress through the RVP processing stages.



The buttons in this menu are "live" and take effect immediately. You may keep the menu up on the screen to compare the results with different settings.

Select **Exit** when you are finished. The **Major Mode** remains visible in the button on the main screen.

Pulse Samples

Shows the current number of pulses for averaging of the spectrum moments or for time series. You can also select the number of samples (pulses) to be averaged into each of the V, W, Z or T plots; or the number of I, Q or L time series points to be plotted. The valid range is from 4 to 256. This field also sets the **Spectrum Size** field. Menu choices: 8, 16, 32, 64, 128, 256.

Range Average or Smoothing

Sets the number of consecutive range bins to average within the DSP before displays. Choose **None** for no range averaging. Smoothing performs an average in range, but does not reduce the number of recorded range bins. An entry such as **1/4** means no range averaging, but do range smoothing over 4 bins. Menu choices: None, 2, 4, 8, 1/2, 1/4. Other values available by type in.

LOG Range Normalization

Toggles range normalization of the LOG channel on and off. In some cases, you may want to disable the LOG channel range normalization algorithm in the signal processor. In this case, the reflectivity against range plot displays dBm above threshold rather than radar reflectivity factor.

Spectrum Size

Shows the number of samples used for a Doppler spectrum. This is always the greatest power of two less than or equal to the **Pulse Samples** field. That is, the Spectrum Size is the value of **Pulse Samples** field rounded down to the nearest of 4, 8, 16, 32, 64, 128 or 256. For alternating polarization, this number is the sample size at each polarization, and the maximum value is 128.


Spectrum Average

Shows the averaging constant for spectrum averaging. The time constant for spectrum averaging affects only the spectrum display (the Spec plot parameter). The argument **None** corresponds to no averaging. The number 8 corresponds to maximum averaging. This number is the time constant of an exponential average in CPIs. Thus, a value of 1 means that after spectrum is computed, the previous data has weight $1/e$. You should allow ample time for the spectrum to settle after changing the averaging. Changing the spectrum size zeroes the averaging. The annotation numbers displayed in the spectrum plot are also averaged. Menu choices: None, 1, 2, 3, 4, 6, 8.

Spectrum Window

Select the window to be applied to the time series before the spectrum is computed. The window dramatically affects the spectrum and can affect the computed SQI shown on the plot. The choices are: **Black** (Blackman), **Hamm** (Hamming), and **Rect** (Rectangular).

5.3.5 Filters



Doppler Filter, LOG Filter

These fields show the current filter selection.

You can select the clutter filter by number. RVP has filters numbered 0 ... 7.



Filter 0 is equivalent to no clutter filter.

See *RVP900 Digital Receiver and Signal Processor User Guide* .

2D Speckle Filter and 1D Speckle Filter

The speckle remover thresholds a data bin for which the bin before and after are already thresholded.

Use this toggle button to clean random data from the display.

Point Clutter

Turns on/off the point clutter remover.

This is a NEXRAD algorithm which runs on the I/Q stream before the data moments are computed. If it sees a sudden spike in power, it replaces the average values from before and after in range.

Thresholds

		LOG	SIG	CSR	SQI
ZT	LOG	0.8 dB	5 dB	18 dB	0.40
Z	LOG & CSR	0.8 dB	5 dB	18 dB	0.40
V	CSR & SOI	0.8 dB	5 dB	18 dB	0.40
W	LOG & SOI & SIG	0.8 dB	5 dB	18 dB	0.40
Dual Pol	LOG	0.0 dB	0 dB	0 dB	0.00
Other	All Pass	0.8 dB	5 dB	18 dB	0.40

Criteria: [Slider]

OK Default

The signal processor uses thresholding to remove range bins that have weak signal power or unreliable estimates of the Doppler parameters.

- Select **Thresholds** to turn thresholding on and off.
- Select **Levels** to set threshold criteria and levels.

See [Antenna Overview \(page 21\)](#) and *RVP900 Digital Receiver and Signal Processor User Guide*.

Criteria for thresholding are set for each data parameters (ZT, Z, V, W, Dual Pol, and Other). You can choose to discard the data when one or more of the following threshold parameters are weak:

- **LOG**
LOG receiver signal-to-noise ratio.
- **SQI**
Doppler channel signal quality index.
- **CSR**
Doppler channel clutter-to-signal ratio.
- **SIG**
A measure of the power from weather targets, excluding noise.

You can select, or enter any Boolean equation using the variables **SQI**, **LOG**, **CSR**, and **SIG**, separated by **and** and **or**.

Choose or enter **All Pass** to accept any value, in effect turning off thresholding.

To select thresholding levels, enter a value directly or move the sliding scale until the value you want appears in the field.

LOG

Sets the LOG receiver threshold in dB above noise.

If thresholding is turned on and the LOG video signal is below this threshold level, reflectivity is thresholded on the reflectivity plots.

Enter a value of 0 ... 5 dB.

SIG

Sets signal power threshold level in dB above noise.

Often this is used to threshold widths.

If the LOG video signal power is below this threshold after removal of clutter power, the widths are thresholded.

Enter a value of 0 ... 20 dB.

CSR

Sets the clutter-to-signal ratio threshold.

If the ratio exceeds this threshold, and thresholds are enabled, the Doppler data are thresholded.

Enter a value of 0 ... 50 dB.

SQI

Sets the Doppler threshold level.

Similar to the **LOG** threshold level except that it is for the Doppler channel signal quality index.

If the processor computes an **SQI** less than the threshold defined here, the velocity and width data for that range bin are not plotted.

You can enter a value of 0 ... 1.

A value of 0 causes nearly all data to be plotted; 1 causes nearly nothing to be plotted. A value of 0.3 generally eliminates the weak signals and passes signals that have good mean velocities.



The "noise points" that get by the threshold correspond to speckles on the color display.


This is useful for reducing the amount of data that is transferred to serial line graphics displays.

After you have entered your thresholding criteria and levels, select **OK** to apply your settings and exit the menu.

To reset the values to their defaults, select **Default**.

5.3.6 Calibration

In **Ascope**, you can measure the current noise level for use during radar calibration.



Sample


Takes a new signal processor noise sample at the range specified in **Ascope > Display > Range Strobe**.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

Noise

Select **Noise** to measure the current noise level by selecting the calibration parameters used when processing noise sample data.

The parameters are set in RVP or in the calibration information that comes in the **IQ** stream metadata.



Do not to take a noise sample when a test signal is present, or the test signal level is interpreted as the noise level. This leads to erroneous displays of reflectivity.

When you are satisfied with these settings, select **Exit**.

ZDR Offsets

Shows the ZDR calibration offset, or **N/A** for systems without ZDR.

You can also use this field to set the ZDR offset. The number you enter is added to the differential reflectivity to correct for differences in the receiver chain.

More information

- [Display Status \(page 38\)](#)

5.4 Ascope Plots


Ascope can plot 1 to 4 parameters at a time.

The plots are scaled so that when only one plot is requested, it is zoomed to fill the left side of the menu.

More information

- [Ascope Menu \(page 37\)](#)

5.4.1 Reflectivity Against Range Plot (T and Z)



This plot is generated when you choose the T and Z plot parameters.

T is the total reflectivity without clutter correction; Z is the reflectivity with clutter correction. These are the equivalent radar reflectivity factors and are fully calibrated estimates.


You must calibrate your radar system before the values are correct. See [Zauto Overview \(page 254\)](#) and *RVP900 Digital Receiver and Signal Processor User Guide*.

The **Ascope** utility lets you temporarily change the slope and offset of the calibration without modifying the calibration file used for the IRIS system.

The data are plotted in -32 ... 96 dBZ decibel values between 0 and the selected Max Range. The numerical value in the upper right of the plot shows the reflectivity at the selected range, indicated by the vertical red line.

See also the **Pulse Samples**, **LOG Filter**, **Thresholds**, **Number of Bins**, **LOG Range Norm**, **Calibration ZCAL**, and **Calibration Slope** fields.

5.4.2 Doppler Mean Velocity Against Range Plot (V)



This plot is generated when you choose the V plot parameter.

The mean velocity corresponds closely to the peak velocity in the Doppler spectrum display. Velocity is displayed in m/s on the unambiguous velocity interval. **T** indicates toward, and **A** indicates away.

Similar to the reflectivity plots, the value of the mean velocity in m/s (and normalized to the interval [-1, +1]) at the selected range is displayed in the upper right corner of the plot.

See also the **Pulse Samples**, **Threshold Levels**, **Doppler and LOG Filter**, **Thresholds**, and **Number of Bins** fields.

5.4.3 Spectrum Width Against Range Plot (W)




Figure 10 Spectrum Width Against Range Plot Example

This plot is generated when you choose the W plot parameter. The spectrum width is the standard deviation of the Doppler spectrum. (The Doppler spectrum display itself always appears broader than the indicated width, because the spectrum is on a log scale).

Width is displayed in m/s up to the unambiguous velocity value. Broader widths are difficult to measure.

Similar to the mean velocity, the numerical value of the width is displayed in m/s and for the normalized velocity interval [-1, +1] for the selected range (as indicated by vertical yellow line).

See also the **Pulse Samples**, **Threshold Levels**, **Doppler** and **LOG Filter**, **Thresholds**, and **Number of Bins** fields.

5.4.4 ZDR Against Range Plot (ZDR)

If you have the ZDR option, this plot is generated when you choose the ZDR plot parameter.

The differential reflectivity is the ratio of the reflectivity at vertical polarization to the reflectivity at horizontal polarization. The range displayed is roughly -8 ... +8 db.

Similar to the spectrum width, the numerical value of the ZDR in dB is displayed for the selected range (as indicated by vertical yellow line).

See also the **Polarization**, **Plot Samples**, **ZDR Offsets**, and **Number of Bins** fields.

5.4.5 Linear Channel A/D Against Range Plot (I and Q or Mag and Arg)

This plot is generated when you choose the I and Q plot parameters against range.

The A/D values are -128 ... 127. The range is 0 ... Max Range. The number of points plotted is determined by the **Number of Bins** field.

The **I** and **Q** DC offsets (if any) and average amplitudes are displayed in the status display. These are important for the signal processor A to D converter alignment. Note that the **I** and **Q** A/D values should never be allowed to saturate (Hit the top of the box). If you observe saturation, adjust the gain of the converters as described in:

- [Coarse Adjustment of Gain and Offset Pots \(page 68\)](#)
- *RVP900 Digital Receiver and Signal Processor User Guide*

The **Mag** and **Arg** choices represent **I** and **Q** in polar form as a phaser. These plots are sometimes more intuitive than the **I** and **Q** plots.

- The magnitude is the $\text{SQRT} (I^2 + Q^2)$.
- The phase is $\text{ATAN} (Q / I)$.

5.4.6 LOG Channel A/D Against Range Plots (ALOG)

This plot is generated when you choose the **ALOG** plot parameter.

This plot is similar to the linear channel **AI** and **AQ** plots, but the values correspond to the **LOG** channel analog to digital converter. The values are 0 ... 255.

The **Z** offset is displayed in the status section. This is the average value of the **LOG A/D** samples and should be approximately 10 ... 30 A/D units. If it is not, align the A/D converter according to the instructions in:

- [Coarse Adjustment of Gain and Offset Pots \(page 68\)](#)
- *RVP900 Digital Receiver and Signal Processor User Guide*

5.4.7 Doppler Spectrum Plot (Spec)




Figure 11 Doppler Spectrum Plot Example

This plot is generated when you choose the **Spec** plot parameter. This is the most useful plot for monitoring the alignment and performance of the Doppler channel.

The Doppler spectrum is computed from the **I** and **Q** time series for the selected range. See [Time Series at a Selected Range \(I , Q , and LOG \) \(page 53\)](#).

The FFT mode spectrum can be displayed directly. The scale is in dB marked with 20 dB divisions. Zero velocity is indicated by a vertical line. This is the velocity of ground clutter targets. The Doppler spectrum plot is always given twice as much vertical height on the screen as the other plots.

The numerical values in the display are as follows:

- Top left
Linear channel power in dB. This is uncalibrated on an absolute scale. However it is very accurate on a relative scale as long as the linear receiver is not saturated.
- Top right
Signal quality index or **SQI** ($|R1|/R0$). This is a value between 0 (white noise) and 1 (pure tone). This is useful in determining the coherency of the radar system. See [Ascope Checkup Procedures \(page 68\)](#).
- Top right (beneath SQI)
RMS phase noise in degrees. This includes noise contributions caused by both amplitude and phase errors, and is computed directly from the SQI as follows:

$$PhaseNoise = \frac{180}{\pi} \times \sqrt{-1n(SQI)}$$
- Time series are clutter-filtered. You can use the filter fields to see the effect of various filters on the Doppler spectrum.

The typical Doppler spectrum contains white noise at all velocities, a ground clutter spike at 0 velocity, and a weather spectrum. Some points to note:

- With the clutter filter set to **None** (no filter), you can observe a strong clutter target to determine the linear dynamic range of the system. Observe the dB difference between the peak of the clutter and the white noise.
- Coherent artifacts are caused by leakage of other signals, such as 50 or 60 cycle line power into the transmitter/receiver system. These appear as peaks located symmetrically about 0 velocity.
To obtain the best Doppler measurements, minimize coherent artifacts by reducing the leakage of stray signals.
- Image spectra occur when a weather spectrum has a mirror image on the other side of zero velocity. Usually the image is smaller than the primary weather peak. Image spectra are typically caused by the following:
 - Saturation of the A/D converters
 - Gain imbalance of the **I** and **Q** channels

To correct these problems, see:

- [Coarse Adjustment of Gain and Offset Pots \(page 68\)](#)
- *RVP900 Digital Receiver and Signal Processor User Guide*

The number of points that are plotted are 4, 8, 16, 32, 64, 128, or 256 as indicated by the **Spectrum Size** field.

You can change the number of points in the **Pulse Samples** field. If a number other than a power of 2 is entered, the next lowest allowable value is accepted (for example, a **Pulse Sample** of 126 sets the **Spectrum Size** field to 64 points).

When selecting the range for the spectrum, it is useful to display a velocity against range (**V**) or reflectivity against range (**Z**) plot. These plots can show you where there are targets of interest.

Because spectra can be very noisy, **Ascope** has a spectrum averaging feature for detecting weak signals. Averaging causes the update rate to slow down. A value of **None** corresponds to no averaging. 8 is the maximum value.

See also the **Pulse Samples**, **Spectrum Average**, **Spectrum Window**, **Doppler** and **LOG Filter**, and **Range Strobe** fields.

5.4.8 Time Series at a Selected Range (I, Q, and LOG)




Figure 12 Time Series at a Selected Range Plot Example

These plots are generated when you select the **I**, **Q** and **LOG** plot parameters.

I and **Q** correspond to the linear channel in-phase and quadrature signals, and **LOG** corresponds to the **LOG** channel video signal.

These plots are similar to the **AI**, **AQ**, and **ALOG** plots except that the samples at a single range are plotted versus time. Each point represents a different pulse.

The **Pulse Samples** field sets the number of points that are plotted. As with the spectrum display, the velocity or reflectivity against range plots can help you select a range where there are interesting targets.

An alternative way to show **I** and **Q** is to use the **Mag** and **Arg** displays (the phased form of **I** and **Q**). The numerical value displayed in the upper right is the RMS value of the fluctuations. When viewing a clutter target, these values can be used to assess both the phase and amplitude stability of the transmitter/receiver.



The RVP time series are clutter filtered. When using the time series plots remember that the clutter filter removes low velocity signals. This can be perplexing when a test signal is inserted and no signal time series is observed. It may be that the clutter filter is effectively removing the signal.

See also the **Pulse Samples**, **Range Strobe**, and **Doppler and LOG Filter** fields.

5.5 Ascope Commands

The **Ascope** utility provides the following commands:

File

Load shows a list of configuration files. Choose the one you want to load..

Save As... lets you save your configuration under the same name or under a new name that you specify.

Print creates an X-window dump of the menu you are running, as follows:

- **Print > to Printer** sends the output to the postscript or color printer specified in the **Printer Setup** menu.
- **Print > to File** sends the output to a file in your default home directory.
- **Print > Setup** lets you configure the printer on your system.

Exit exits the utility.

The named **Ascope** configurations are stored in the files **.ASCOPE* in the *config* directory. The default startup configuration is named *DEFAULT.ASCOPE*

Options

Simulator shows a menu for defining a digital signal. See [Digital Signal and Target Simulators \(page 62\)](#).

Plots Only removes the plot parameters from the **Ascope** menu, so that the plots can take up the entire window.

Plots/Params shows the plots on the left and the parameters on the right.

Reset Plots

Help

On Utility displays information about the utility.

Contents and **Index** provide access to the online help.

5.6 Data Recording and Playback

The **Ascope** utility can record live DSP data directly to a disk file so that users may develop their own off-line application programs for custom data analysis. The recording procedure is interactive and may be invoked any time that interesting data are observed on the display.

You can also play the files back in **Ascope** to review their contents or check the integrity of the values.



After you have recorded files to disk, you can archive them to tape using UNIX tar.

5.6.1 Recording Data




Figure 13 Record/Playback Menu

- ▶ 1. Configure **Ascope** normally, so that the weather phenomenon is shown on the screen. When the **Record** menu first appears on the screen, **Ascope** operates the DSP in the usual continuous manner
To create the configuration that you would like to record, you can modify and all menus, including the **Record** menu.
 - a. Select a maximum range and bin spacing that captures the event at an adequate resolution.
 - b. Setup the PRF, clutter filters, range averaging, spectral averaging, and so on, so that the weather target's characteristics are nicely captured.



You cannot change the **Ascope** menus during recording.

- 2. Select **File > Rec/Play...**
The menu launches in record mode.

3. In the **Plot Parameters** menu, select the parameters you want to record.
 You can choose up to 16 parameters to be recorded to disk at once. The first 4 parameters are plotted on the screen, and all the selected items are archived.
 For example, if you select: **Z, T, V, W, I, and Q** in that order, **Ascope** displays the first 4 parameters versus range, and records all 6 as soon as the **Rec** button is pressed.
 If the time step and number of rays were setup for a long interval of recording, you can monitor the plotted parameters by eye and discontinue recording if the weather event changes or becomes less interesting.
 - a. Power spectra:
Ascope can record power spectra, either in place of or in addition to the **I** and **Q** data from which the spectra are derived.
 If spectra are recorded on their own, then the size of the data files is reduced by approximately a factor of 2. This may be significant when many bins of data are being recorded.
 Another advantage that spectra offer is that they can be averaged prior to being recorded, and thus could supplement the **I** and **Q** data in a useful way. For example, if **I, Q, and Spec** rays were recorded every 10 seconds, and if the spectral averaging were set to approximately 10 seconds, then the archived data would contain highly averaged spectra plus occasional instantaneous time series.
 - b. Data parameters:
 Each data parameter (**T, V, Zdr**, and so on) is recorded over the full range interval specified by the maximum range and bin count in the **Ascope** main menu.
 - c. Single pulse data samples:
 The single pulse **AI, AQ, and AL** data samples are recorded over the full range interval.
 However, time series and spectra are recorded only at the limited number of bins specified in the **TS Bins** field, and centered at the distance of the range strobe.
 When the **Record** menu is visible, this secondary range interval is shown as a pair of dotted vertical lines drawn on either side of the range strobe. To record time series and/or spectra, you must choose a nonzero value for **TS Bins**, and must select **I, Q, and/or Spec** from the **Plot Parameters** menu.



The **MAG** and **ARG** parameters are not available for recording to disk. This is because these parameters are merely computed at display time and are completely redundant with **I** and **Q**. They would not add any averaging or data reduction possibilities if recorded.

If you press the **Rec** button while a **MAG** and **ARG** plot is selected a warning message reminds you that you may not be recording exactly what you think. However, the data file still contains all the other selected parameters.

4. Select the recording directory in which data files are recorded.
The default is `/usr/iris_data/ascope`. You can change it to any writable directory.
Ascope creates the file names automatically in form `WWWYYMMDDHHMMSS.ASC` where `WWW` represents the 3-character local site code, and the remaining characters are the 2-digit year, month, day, hour, minute, and second at the start of recording.
5. Define the number of **TS Bins** at which time series and/or power spectra are recorded (0 ... 128).
The chosen bins are centered on the range strobe selected in the **Ascope** main menu.
6. In **Num of Rays**, define the number of rays of data to record.
Each ray represents the data from one complete iteration of the basic **Ascope** loop, that is, one acquisition of the set of all data types that are selected in the **Plot Parameters** menu.
The maximum number of rays that can be recorded is 10000.
7. Define the **Time Step** between rays.
This is the time in seconds between successive recorded rays (0 ... 600 seconds (10 minutes)).
Set this value to 0 for a continuous data recording. Use larger values to record over a longer time interval without creating too large a data file.
For example, a time step of 10 seconds would record 6 rays per minute to disk, even though the DSP and display still update continuously.
8. Select **Rec**.
During the recording session, the progress bar indicates the progress.
Recording stops when the full number of rays are recorded and the slider has reached 100% or when you select **Stop**.
When recording is complete, the **Ascope** environment returns to normal operation.
9. Select **Cancel** to return to normal **Ascope** operation.

5.6.2 Playing Back Data

Use this menu is to review the contents of the recorded data files, and to check on the entire recording process. You can select any file for viewing, and display the rays individually or as a continuous loop.

You can invoke the **Playback** menu when **Ascope** is in its normal operation mod, that is, acquiring live data from the DSP. It may also be used off-line (in a system with no DSP) by initially starting the utility with the `-demo` option. Each time you start the menu, the playback directory is rescanned for files that match the **Ascope** naming convention. This collection of files is then displayed in the scrolling list with timestamps.

Each time a new ray is requested from disk, the data values displayed in the plotting area and all other numeric fields are updated using information contained in the header files consisting of the time, **TAG** bits and **GPARM** information. Also, the azimuth and elevation angles are displayed, along with the current PRF, error bits, and so on, that were originally measured with each ray.

- ▶ 1. Select **File > Rec/Play...**
The menu launches in record mode.

2. Select **Record to > Playback**.
The **Playback** menu appears.



3. Directory from which data files are played. By default, this is the same directory used for recording. If needed, change to any readable directory containing **Ascope** data files.

4. In the list of files, select the file you wish to playback.
The most recently recorded data are always at the top.
 - a. Stretch the menu vertically to view the entire menu.
 - b. Use the slider to select the ray number to be displayed.
The left and right limits correspond to the first and last ray within the selected file.
The ray number (starting from 0) is displayed on top of the slider.
Left-click either side of the slider to increase or decrease the ray number by 1.

When you select a file, the **Ascope** configuration is reloaded from the header of the data file. This causes all menus and displays to return to the appearance that they had at the time the recording was made. The name displayed in the top title bar of the main menu changes to the name of the selected file.

- All **Ascope** menus are grayed out, except for the **Play** button and slide pots of the **Playback** menu. **Ascope** is now bound by the original selections of the highlighted data file.
 - The data from the first ray are loaded from the file and plotted on the screen. The ray selection slide bar is initialized to its left edge (ray #0), and the time shown in the top title bar changes to the time of this first ray.
 - **Ascope** waits in this state until the file is deselected or you exit the **Playback** menu. You can browse the recorded data set using the ray slide bar or the **Play** function.
5. Select **Play** and **Stop** to manage the movie loop playback mode.
When you select **Play**, **Ascope** loops continuously through all the rays in the data file. This is useful for watching a phenomenon evolve over time.
 6. Select **Pause** and **Speed** to adjust the end-of-loop pause and frame rate during playback.
The pause at the end of each loop can be up to 10 seconds, and the delay between successive rays can be up to 2 seconds.
 7. Select **Cancel** to return to normal **Ascope** operation.

5.6.3 Format of Recorded Data

The data files are organized as a 1280-byte `asc_stats` configuration structure, followed by the individual ray data in their original order of arrival.

For an explanation of the structure, see the public header file `ascope.h`.

Ascope Data File Headers

Each ray is prefaced with a 200-byte `asc_ray_header` structure that holds additional information from the exact moment that each ray was acquired.

To check **Ascope** data file headers, type the following command:

```
dd < RVP8040722170814.ASC bs=1280 count=1 | structmap asc_stats -recursive -data
```

Reading an Ascope Data File

To process the contents of an **Ascope** data file, begin by opening the file and reading the first 1280-bytes into an `asc_stats` structure.

Use the actual ray count `irec_rays_actual`, and ray data length in bytes `irec_ray_size`, to divide the remainder of the file into fixed length blocks. Each block consists of an `asc_ray_header` structure followed by the ray data itself.

Ray Data

The ray data are defined by the `iplottypes[]` array, which lists up to 16 different data parameters that were recorded.

Each parameter is stored in its native format as read from the DSP. For information on the data formats, see *IRIS Programming Guide* and the **PROC** command section in *RVP900 Digital Receiver and Signal Processor User Guide*.

The length of each data parameter array is rounded up to the next multiple of 4 bytes to make sure that successive elements within the file are aligned on 4-byte boundaries if they need to be.

There is no difference between **I** and **AI**, **Q**, and **AQ**, and so on in terms of data format. However, the **A** terms span the full range, and the non-**A** terms span the full pulse count.

The "derived parameters" **MAG_AIQ** (10), **ARG_AIQ** (11), **MAG_IQ** (15) and **ARG_IQ** (16) are not recorded on the archive disk, since doing so would not add any more information than that in the original (**I,Q**) data. **Ascope** can plot these parameters (because that is often handy). If you want to archive this data, include the raw (**I,Q**) parameters themselves.

Example

Suppose that a recording is made with the following settings:

- In the main menu: 30 bins and 10 pulses
- In the **Plot Parameters** menu: **T** reflectivity and **L** time series
- In the **Record** menu: 5 TS-Bins and 7 ray
- In the **General Setup** menu: 16-bit time series

Then the data file is 3604 bytes long and consists of:

- A 1280-byte `asc_stats` header
- Seven ray blocks, each 332-bytes long, comprised of a 200-byte `asc_ray_header` structure, followed by 32 bytes of **T** data, and 100-bytes of 16-bit **L** samples. The length of the **T** data was rounded up to the next multiple of four, and that the **L** sample length is based on:

$$\left(10 \frac{\text{pulses}}{\text{ray}}\right) (5 \text{ bins}) \left(2 \frac{\text{bytes}}{\text{bin} \times \text{pulse}}\right) = \left(100 \frac{\text{bytes}}{\text{ray}}\right)$$

5.7 Digital Signal and Target Simulators

To test the signal processor, evaluate its performance in response to weather targets, and train personnel, **Ascope** provides a digital simulators, which allow you to:

- Simulate weather and clutter targets in the host workstation using **Ascope** in order to develop operational processing strategies.
You can configure the operational configuration in **Ascope**, then test it using signals from the simulator.
- Automatically download the simulated **LOG**, **I**, and **Q** signals to the signal processor where they are processed as usual.
- View the processed results in **Ascope**.

Only one range bin is simulated and the resulting **I**, **Q** and **LOG** time series are loaded in every range bin that is processed.

The technique is based on Sirmans and Bumgarner's (1975: *Jour. Appl. Meteor.*, 14, 991-1003) signal simulation approach. A Doppler spectrum is constructed with magnitudes that have Poisson statistics and random phases. This is inverted to provide digital **I** and **Q** values. The **Ascope** simulation approach is extended to include ground clutter, transmitter/receiver instabilities, and second trip echoes.

More information

- [Using the Digital Signal Simulator \(page 64\)](#)
- [Using the Digital Target Simulator \(page 62\)](#)
- [Data Simulations \(page 161\)](#)

5.7.1 Using the Digital Target Simulator

Use the digital target simulator with **Ascope** to simulate weather and clutter targets in the host workstation.

The digital target simulator can simulate up to 4 point targets. You can set the parameters of each target independently.

1. Select **Options > Target Simulator**.
The simulator and its control panel start.




Figure 14 Digital Target Simulator Display and Ascope View Example

Cx

Select **Cx** to indicate that the target impacts the data from the cross-polarization Rx channel (vertical polarity).

Co

Select **Co** to indicate that the target impacts the data from the co-polarization Rx channel (horizontal polarity).

Range (km)

How many km it will affect after the starting range

Length (km)

How far away from the radar the object is.

In the example plot, this is shown in the trapezoid changes. A range of 50 and a length of 10 km indicates the target occupies the range bins between 50 ... 60 km.

Power (dB)

Signal power of the target.

Gradient

How much the power changes over the range of the target.

For example, a **Targ-1** target between 50 ... 60 km with the **Power** of 10 and the **Gradient** of -13 dB starts at the signal power of 10 dB @ 50 km and then drops 13 dB down to -3 dB at 60 km.

Doppler (Hz)

Doppler frequency of the target in Hz.

Gradient

How much the frequency changes over the range of the target.

5.7.2 Using the Digital Signal Simulator

You can use the signal simulator to simulate one or two targets that can occur both in the first trip or the first and the second trip to test the random phase range unfolding feature of RVP.

The simulator creates a time series across all range bins with the same statistics.




Figure 15 Digital Signal Simulator

Signal

Sets the signal power of the meteorological target (dB).

As you raise this value, the Doppler spectrum of weather increases in power.

If the **Signal** value is larger than the minimum slider value (---), the **Signal**, **Velocity**, and **Width** parameters define the Doppler Power Spectrum of a weather target with a Gaussian / Normal distribution.

Velocity

Sets the mean radial velocity (m/s) of the weather target normalized between [-1, +1] to correspond to the Nyquist interval (fold point).

As you change this value, the Doppler spectrum moves horizontally.

Width

Sets the spectrum width (standard deviation of velocity) in m/s.

As you change this value, the spectrum become broader.

Clutter

Sets the power (dB) of the clutter signal which has a mean velocity of 0.

As you increase this value, the clutter peak at 0 velocity increases.

The power is calibrated in the same way as the signal power. For example, if both the **Clutter** and **Signal** powers are the same, the clutter-to-signal ratio is 0 dB.

Noise

Sets the power (dB) of the white noise present. If --- then no noise added.

Raising this value causes the noise floor to increase.

Tx. Phase

Sets the sequence of phases used to modulate the time series from pulse to pulse:

Coherent - no phase modulation.

Random - random phase sequence.

For more information, see **CFGPHZ** host computer command in *RVP900 Digital Receiver and Signal Processor User Guide*.

Second Trip

Adds a second trip to **Target #2**.

If **Target #2** is in the second trip echo (**Second Trip** is enabled), the **Tx. Phase** parameters to give **Target #2** a phase shift from **Target #1**.

RMS Phase

Simulates phase noise. Increasing the phase noise increases the white noise level in the Doppler spectrum.

If the phase from pulse-to-pulse is the same, this setting defines amount of pulse-to-pulse Tx phase modulations of the simulated signal.

Typically, a magnetron radar has between 1 ... 3° of phase noise.

A Klystron system can have as little as 0.1° of phase noise.

RMS Power

Defines the pulse-to-pulse amplitude modulations of the simulated signal.



1. Select **Options > Signal Simulator**.

The simulator starts and the control panel is shown.

2. Configure **Target #1**.

Disable **Target #2** by setting all of the **Target #2** slide pots to the far left. This makes it easier to interpret your results.



Vaisala recommends that you display a Doppler spectrum with 128 samples so that you can see the results of any changes that you make.

When you are satisfied with the Doppler spectrum that you have constructed, you can switch to other types of displays.

3. Configure **Target #2**.

- a. Define **Target #2** settings.
- b. Leave the **Second Trip** button out (disabled) so that **Target #2** is in the first trip.
- c. Select **Second Trip**.
You can see the power from **Target #2** put into the white noise of the first trip spectrum.



The signal, clutter, and noise signals for **Target #1** and **Target #2** are added together to form a single time series.

5.7.2.1 Velocity, Width, and Intensity Display Features for Testing

The digital signal simulator (DSS) lets you input signals of known properties, then view the results in the **Ascope** displays.

Effects of clutter filters, time averaging, and PRF can be determined using the spectrum display.

The following moment display features are designed to simplify testing:

- The velocity against range plot shows the numerical value (in parentheses) of the mean velocity normalized to the interval $[-1, +1]$. This can be compared directly to the value set in the DSS.
- The width against range plot also shows the normalized value of the width for direct comparison with the DSS.
- With no clutter power in the DSS and **LOG Range Normalization** turned off, the **Z** or **T** readouts are 80 dB greater than the DSS setting for signal power (for signal powers >10 dB).
- With no clutter power in the DSS the **MAG (IQ)** plot are 3 dB less than the DSS setting for signal power.

When making comparisons, note that the natural fluctuations of weather echoes are also simulated. This means that you can see fluctuations in the values, particularly if the spectrum width and/or the noise power are large.



After you set the DSS, the same time series is loaded into the signal processor every time. To get a new "realization" select on any of the slide pots that you are using. A fresh time series is created.

5.7.2.2 Random Phase 2nd Trip Echo Testing

You can use the digital signal simulator (DSS) for testing random phase for 2nd trip echo recovery.

Random phase processing filters and recovers second trip echoes, which can be a serious problem when operating at high PRF. See *RVP900 Digital Receiver and Signal Processor User Guide*.



To use this feature, random phase features of the RVP must be licensed on your system.

- ▶ 1. Verify that RVP non-volatile setup (under **Mb**) has digital phase locking enabled. See [Sample DspX Session \(page 114\)](#) on the **dspX** utility chat mode.
2. Select **Plot Params > Spectrum Display**.
3. Select **General Setup > Major Mode > Random Phase**.
4. Select **General Setup > Type of Spectra > Raw #1**.
5. On the DSS panel, turn **Digital Locking** on (button in).
6. On the DSS panel, set **Second Trip** off (button out).
7. Use the DSS to configure Target #1 and Target #2.
8. Set **Second Trip** on (button in) to put Target #2 in the second trip.
9. To verify the stages of the algorithm, select **General Setup > Type of Spectra > Raw #1, #2, and similar**.
10. Set up moment plots (Z, V, and so on versus range) to verify the moments.
11. Trace the filtering steps of the random phase algorithm and experiment with different set-ups for the whitening filters.

5.8 Ascope Checkup Procedures

5.8.1 Coarse Adjustment of Gain and Offset Pots



CAUTION! Perform this procedure when you have adjusted all signal line drivers and you have checked the **I**, **Q**, and **LOG** video signals with a scope to make sure that they are within the proper limits of the signal processor A/D converters.

The analog-to-digital converter section of each DSP contains 2 potentiometers for each digitized video signal. Nominally, **I** and **Q** signals should be between ± 1 V and the **LOG** channel 0 ... 2 V. The potentiometers allow the A/D converter span and offsets to be adjusted around these nominal values so that the full span of A/D values is available to the signal processor.

These pots are on the outside edge of the RVP. When signal processors are used for reflectivity-only processing, then only the **LOG** video channel must be adjusted. Otherwise the signal processor could be damaged if an inappropriate voltage is applied.



For information on the location and use of the adjustment pots, see the section on A/D alignment in *RVP900 Digital Receiver and Signal Processor User Guide*.



There are two ways of setting these controls. The recommended procedure is to use the **Ascope AI, AQ, and ALOG** plots to view the raw time series against range. For information on setting these controls without Ascope, see *RVP900 Digital Receiver and Signal Processor User Guide*

- ▶ 1. Run **Zauto** and check the value of the calibration slope.
Typical values are 0.3 ... 0.5. The default is 0.5.
If the calibration slope is 0, set it to the correct value.
2. Disconnect the gain control output from the processor.
This makes sure that the linear receiver is operating at full gain. If the processor gain is not used on your system, check with your manufacturer to see how the receiver can be set to full gain at close range.
3. In the terminal prompt, type: **ascope&**
4. Set up **Ascope** as follows:

PRF	250
Max Range	100
Number of Bins	100
Plot Parameters	AI AQ ALOG

5. While running **Ascope**, turn on the transmitter and point the antenna in a direction so that the main bang of ground return can be observed.
Sometimes it helps to scan the antenna very slowly to get a representative sample of targets.
 - a. Make sure all test signals are off.
 - b. Adjust the **LOG** offset pot so that the far range noise is approximately 10 % off the bottom of the plot (as compared to the full range of A/D values).
 - c. Select **Noise** to invoke a new noise sample and verify that the Z offset in the status section is 15 ... 30 units.

6. Adjust the **LOG** gain pot so that the saturated main bang at close range is below the high limit.
 - a. If there is difficulty observing the saturated main bang close to range 0, reduce the **Max Range** field to 10 km (6.2 mi).
 - b. Readjust the offset as required, because changing the gain can affect the offset.



Another technique is to use an RF test signal generator to adjust the A/D range to correspond to the dynamic range of the receiver (typically 80 dB). To do this, use **Ascope** to observe the LOG channel A/D against range plot (ALOG). Do not select **Noise** or leave the Sample Offset Noise Sampling Mode set to Continuous. Use the signal generator in CW mode. The transmitter is usually turned off to avoid damage to the signal generator while it is connected. Now starting from the minimum value of the signal generator output, increase the signal level until the LOG A/D values just start to increase. This is the approximate noise level. Adjust the gain so that, for example, the LOG A/D values are at approximately 250 when the signal generator level is increased to 80 dB above the noise level.

7. Adjust the **I** and **Q** pots until the signal is approximately centered in the display.
 - a. Select **Noise** to verify that they are within ± 5 units of 0.
 - b. If not, adjust accordingly.
8. Make sure the gain control is disconnected or otherwise disabled so that the receiver is operating at full gain for this test.
 - a. Adjust the **I** and **Q** gain pots so that the strongest clutter targets at close range are just below saturation.
 - b. Adjust the amplitude of the **I** and **Q** signals with the gain pot so that they are equal. Slight saturation on the very strongest clutter targets is tolerable because no useful weather information can be obtained in the vicinity of these anyway.
 - c. Recheck and readjust the offsets as required.

5.8.2 Phase and Amplitude Stability Checks

This test establishes how much dynamic range is available in the linear channel for clutter cancellation. This is useful for determining the maximum clutter correction that can be achieved.



Disconnect or otherwise disable the gain control so that the linear receiver is at full gain during these test.

1. Set **Ascope** to run as follows:

Parameter	Value
Pulse Width:	0.5
PRF:	Highest value
Plot Parameters:	T Spec
Doppler Filter:	None
LOG Filter:	None
Thresholds:	Off
Max Range:	20
Pulse Samples:	128
Spectrum Window:	Rect

This creates a Doppler spectrum with a fairly rapid update for searching.

2. Use the Reflectivity against Range plot (Total dBZ) to select a range where there are strong clutter targets and observe the peak-to-noise level for the strongest clutter targets. You may want to scan the antenna very slowly, stopping at strong clutter targets. Estimate the peak-to-noise level ratio by eye (20 dB per division) for several of the strongest targets by estimating the average noise level. Spectrum averaging helps to reduce the fluctuations. For a 128-point spectrum (**Pulse Samples:** 128) the clutter to total noise power in dB is the observed peak-to-noise ratio minus $10 \log(128)$, that is:

$$\text{dB(Clutter-to-noise)} = \text{dB(Peak-to-noise)} - 21 \text{ dB}$$

This is a measure of the available dynamic range of the system. If the value is 20 dB, (typical for a magnetron system), then the maximum clutter correction that can be achieved is approximately 20 to 30 dB depending on the number of samples averaged together.

Another way to assess the coherency of the system is to use the SQI and phase noise values displayed in the upper right corner of the spectrum display. The SQI is a number between 1 (perfectly coherent) and 0 (perfectly incoherent) which is related to the pulse-to-pulse phase noise, the peak-to-noise and the clutter-to-noise. The following table summarizes these relationships. Note that the calculations in the table assume you are looking at a pure clutter target with no weather or coherent artifacts such as 50 or 60 Hz or image spectra. For example, an SQI of 0.9800 corresponds to a phase noise of 8.1°, a clutter-to-signal ratio of 16.9 dB and a 128-point peak-to-noise (observable in the spectrum plot) of 37.9 dB.

Table 5 Coherency Relationships

SQI	Phase Noise (Degrees)	Clutter-to-Noise (dB)	128-Point Peak-to-Noise (dB)	256-Point Peak-to-Noise (dB)
0.99998	0.26	47.0	68.0	71.0
0.99996	0.36	44.0	65.0	68.0

SQI	Phase Noise (Degrees)	Clutter-to-Noise (dB)	128-Point Peak-to-Noise (dB)	256-Point Peak-to-Noise (dB)
0.99994	0.44	42.2	63.2	66.2
0.99992	0.51	41.0	62.0	65.0
0.99990	0.57	40.0	61.0	64.0
0.99988	0.63	39.2	60.2	63.2
0.99986	0.68	38.5	59.5	62.5
0.99984	0.72	38.0	59.0	62.0
0.99982	0.77	37.4	58.4	61.4
0.99980	0.81	37.0	58.0	61.0
0.99970	0.99	35.2	56.2	69.2
0.99960	1.15	34.0	55.0	58.0
0.99950	1.28	33.0	54.0	57.0
0.99940	1.40	32.2	53.2	56.2
0.99930	1.52	31.5	52.5	55.5
0.99920	1.62	31.0	52.0	55.0
0.99910	1.72	30.5	51.5	54.5
0.99900	1.81	30.0	51.0	54.0
0.99800	2.56	27.0	48.0	51.0
0.99700	3.14	25.2	46.2	49.2
0.99600	3.63	24.0	45.0	48.0
0.99500	4.06	23.0	44.0	47.0
0.99400	4.44	22.2	43.2	46.2
0.99300	4.80	21.5	42.5	45.5
0.99200	5.13	20.9	41.9	44.9
0.99100	5.45	20.4	41.4	44.4
0.99000	5.74	20.0	41.0	44.0
0.98000	8.14	16.9	37.9	40.9
0.97000	10.00	15.1	36.1	39.1
0.96000	11.58	13.8	34.8	37.8
0.95000	12.98	12.8	33.8	36.8
0.94000	14.25	11.9	32.9	35.9
0.93000	15.43	11.2	32.2	35.2
0.92000	16.54	10.6	31.6	34.6

SQI	Phase Noise (Degrees)	Clutter-to-Noise (dB)	128-Point Peak-to- Noise (dB)	256-Point Peak- to-Noise (dB)
0.90000	18.60	9.5	30.5	33.5

6. Bitex Utility

6.1 Remote monitoring with Bitex

Bitex is the built-in IRIS software for monitoring and managing radar components remotely. Remote managing includes resetting faults, starting equipment, switching power systems, and so on.

Vaisala configures **Bitex** factory settings before shipping the radar.

Bitex displays status information reported by Built-In Test Equipment (BITE) integrated in the radar and associated systems and reported through the Radar Control Processor (RCP). Operator-initiated commands are sent to BITE units through RCP.

BITE typically connects to the RCP through interfaces such as contact closures, analog voltages, or serial communications. RCP integrates this information and sends it to IRIS for display in the **Bitex** utility. These packets are mingled with the RCP antenna controller commands on the same network port.




RCP can also decode button pushes into control variables for use in logic equations for complex functions.

Bitex can handle up to 256 pieces of data from up to 16 separate BITE units. For example, the antenna sub-assembly may be one BITE unit, the transmitter a second, the radar controller a third, and facility equipment (power equipment, building alarms, and similar) a fourth.

For more information, see *Radar Control Processor RCP8 User Guide*.

For information on setting up and configuring the **Bitex**, see *IRIS and RDA Utilities Guide* and the project documentation.

Table 6 Bitex status colors

Color		Meaning
	Green	Normal operation
	Yellow	Warning
	Red	Alarm



This manual shows the default **Bitex** views for dual polarization weather radars. **Bitex** content varies depending on your system configuration.

6.2 Invoking Bitex

You can invoke graphically **Bitex** from the **Radar Status Menu**.


To invoke **Bitex** from the command line, type: **bitex&**.

You can also use one of the **Bitex** command line options.

Table 7 **Bitex** Command Line Options

-setup	Lets you customize the BITE menu contents and layout.
-upgrade	Upgrades old format bitex configuration files to the current format.
-version	Prints the version number.

6.3 Bitex Window



Bitex Main Screen

The **Bitex Main Screen** shows each Bite Unit.

Sub Panels

Select an option on the **Bitex Main Screen** to show its sub-panel, such as the **Transmitter** sub panel.

You may have many or no sub-panels. It is convenient to have a few sub-panels accessible from the main panel, where each sub-panel represents a different functional area of your radar BITE.

You can also nest sub-panels, so that from one sub-panel, you can open other sub-panels.




















File		Customize		Commands		Help	
Transmitter							
	Transmitter reset						
	NO	TX Ready			REMOTE	Local/Remote	
	OFF	Radiate			OFF	Transmitter power	
	OK	Power supply cur.			OK	Filament voltage	
	OK	Magnetron peak cur.			OK	Magnetron airflow	
0.0 V		Filament voltage		92 V		Power supply volts	
0.0 mA		Magnetron lave					
Peripherals							
	Peripherals reset						
	OK	Waveguide arc			Arc detector test		
	OK	Waveguide pressure			H+V	Waveguide switch	
	OK	WG switch status					
	OK	Power Monitor					

Figure 16 Bitex Transmitter Screen

6.4 Histograms



Histograms of the **bitex** status data may be viewed in a graphical display format. The output data points can be analog or digital. The histogram may be opened by right clicking on any of the bitex panels. You cannot pop up the histograms if you started **bitex** in **-setup** mode. The graphical display can be a valuable tool when assessing the frequency and endurance of faults.

The time scale for viewing the histogram is adjustable from 10 minutes to 96 hours using the Time Span slider. The y-axis scale for analog output is also adjustable with the Vertical Span slider. Each circle represents the time a status packet was received. The graphical display may be printed to a printer or file.

The histogram data files are created in the $\${IRIS_LOG}$ directory. A new log file is generated each day at midnight. An IRIS **setup** question allows the operator to choose how many days of antenna log files to retain at any given time. Keeping old log files preserved is helpful for post analysis of problems.

6.5 Bitex Commands

File

Save applies the current settings and writes them to disk file called *bitex.conf* and *bitex_wgt.conf*. **Save** available only if you invoke **Bitex** with the setup option.

Print creates an X-window dump of the menu you are running, as follows:

- **Print > to Printer** sends the output to the postscript or color printer specified in the **Printer Setup** menu.
- **Print > to File** sends the output to a file in your default home directory.
- **Print > Setup** lets you configure the printer on your system.

Exit exits the utility.

Customize

General launches the **Bitex Customization Menu**, which allows you to set up the serial stream parameters for each BITE unit.

Tools launches **Bitex** tools for creating, deleting, and positioning sub panels and data point items.

Panel Options allows you to set the current panel name to be set to specify a background GIF image for this panel.

Display IO Count places a network traffic count in bytes on the top of the **Bitex** display .



General, **Tools**, and **Panel Options** are only available if you start **Bitex** with the `-setup` option.

Help

On Utility displays information about the utility.

Contents and **Index** provide access to the online help.

6.6 Exporting BITE Status Information

The `bite_export` program reads the **Bitex** configuration and exports configured status information to a CSV file in ASCII format. The program listens to the multicast UDP messages and retrieves data from there.

You can set `bite_export` to run in the background as a service using the `/etc/init.d/bite_export` script.

- ▶ 1. To configure the tool, type a command similar to the following example:

```
${install_root}/bin/bite_export -port 30785 -interval 2 -history -  
output /usr/iris_data/log/bite_ascii.csv &
```

Use this command to configure the history option, logging interval, and the output file. In the example the command logs **Bitex** status to the defined output file every 2 seconds (`-interval 2`).

If you change the multicast port, update the configuration here.

2. To use the **-history** option, you must configure **logrotate**.
The **-history** option does not overwrite the file. Instead, it appends the data to the end of the file.



If you do not use the **-history** option, only the latest data is saved to output file and old values are overwritten.

- a. Create and edit the `/etc/logrotate.d/sigmet-bite_export` file.
The default file contents are:

```
/usr/iris_data/log/bite_ascii.csv {
    copytruncate
    missingok
    notifempty
    daily
    rotate 5
    su root users
}
```

This copies the contents of the output file once a day to `/usr/iris_data/log/bite_ascii.csv.1`, from `.1` → `.2` and so on. It leaves the original output file empty.

This configuration stores 5 days of history, each in its own file and deletes log files older than 5 days.

- b. You can configure the **rotate 5** parameter to save more history data.
For example, to save 100 days of history, change the value to **rotate 100**.
This creates files:

```
/usr/iris_data/log/bite_ascii.csv.1
/usr/iris_data/log/bite_ascii.csv.2
...
/usr/iris_data/log/bite_ascii.csv.100
```

- c. As **root**, add file permissions **644** to the **logrotate sigmet-bite_export** configuration file with the following command:

```
# chmod 644 /etc/logrotate.d/sigmet-bite_export
```

- d. To check the **logrotate** configuration, run the debug command:

```
# logrotate -d/etc/logrotate.conf
```

Look for the **bite_export** in the command output and check for errors. This command indicates what would have happened if the rotate had been run. It does not rotate the actual log files.

- e. To force **logrotate** to run, type the following command:

```
# logrotate -f /etc/logrotate.conf
```

This rotates the log files.

3. To manage how **bite_export** starts and stops, login as **root** and use the following commands.

Command	Description
# chkconfig --add bite_export	Enable bite_export to start automatically during boot-up.
# chkconfig --del bite_export	Disable bite_export from starting automatically during the boot-up.
# service bite_export start	Start bite_export if it is not already running.
# service bite_export stop	Stop bite_export .

6.7 Customizing Bitex

- Invoke **Bitex** with the **-setup** option.
See [Invoking Bitex \(page 75\)](#).
- In the customization menu, make the necessary changes to the configuration.
The customization menus are scratch pads. Changes do not take effect until they are applied and saved.
- Select **OK**.
This applies the changes and closes the menu.
- Select **File > Save**.
- Select **File > Exit**.

The configuration is used the next time the antenna driver starts.

6.7.1 General Bitex Customization Options

BITE Customize Menu

Number of BITE Units: 4

Unit 1

Unit 1 Action: Receive Status Bits

Unit 1 Alias: RCP8 Internal

Unit 1 Hex ID Number: 01 I/O: 00000000

Unit 1 Packet Byte Count: 13 Age: 9999.99

Unit 2

Unit 2 Action: Receive Status Bits

Unit 2 Alias: RCP8 Status

Unit 2 Hex ID Number: 02 I/O: 00000000

Unit 2 Packet Byte Count: 13 Age: 9999.99

Unit 3

Unit 3 Action: Transmit Control Bits

OK Apply Cancel

To display the BITE Configuration menu, choose **Customize > General**. This menu is used to change the format of the BITE packet transmission and reception over the network communications stream. In normal operation, this menu is not needed. To protect against inadvertent changes, you must be in setup mode to make changes.

Number of BITE Units

Select from 1 to 16 BITE units. The number of units and the characteristics of each unit displayed in the menu changes reflecting the setting of the Number of Units.

Unit Action

The choices for Unit Action are **Receive Status Bits**, **Receive Status QBITE**, or **Transmit Control Bits**. Each of the units is configured independently. If the RCP is configured to send status information to IRIS for this unit, the Unit Action in Bitex should be **Receive Status Bits**. Any data point configured for this unit then displays status information.

If the RCP is configured to receive control information from IRIS for this unit, the Unit Action in **bitex** should be **Transmit Control Bits**. Any data point configured for this unit is a button for sending actions to the RCP.

Unit Alias

This name is used on the **Interrogate** menu to identify the purpose for the different BITE units.

Unit Hex ID Number

Each BITE unit has an identification byte (displayed in hex) which determines the meaning of this packet. **Unit IDs** configured in **bitex** should match **Unit IDs** configured on the RCP. Transmit **Unit IDs** are independent of Receive **Unit IDs**, thus they may share the same **Unit IDs**. But within Transmit IDs or Receive IDs, the unit numbers must be unique.

Unit Byte Count Packet

For each BITE unit, you must specify the number of bytes expected in each packet, from 4 to 128. These numbers must match those configured on the RCP for each BITE unit.

I/O

A display-only field showing the number of characters received from or sent to that particular BITE unit.

Age

A display-only field showing the time in seconds since the last packet for this particular unit was received or transmitted.

6.7.2 Using Bitex Customization Tools

The **Bitex** customization **Tools** allow you to create, delete, or move sub panels and data points.




Figure 17 Bitex Customization Tools

- ▶ 1. To access the tool bar, in any **Bitex** panel, select **Customize > Tools...**
2. Edit your panels using the options in the tool bar:
 - Erase Tool: Erases the next data point or sub panel.
 - Move Tool: Click, hold and drag the next data point or sub panel.
 - Cut / Paste: Cut the next data point or sub panel. When mouse is put over an unoccupied area and click again, pastes the object just cut.
 - Add Data Point: Add a new data point object to the next clicked position.
 - Add Sub Panel: Add a new sub panel data object to the next clicked position.
3. To exit the tool, select the Pointer Tool in the tool bar.

6.7.3 Bitex Panel Options



Use the **Bitex Panel Options** to configure the following:

Panel Title

The **Panel Title** value is shown on the title bar of this panel.

Background Image

All panels may optionally have a GIF image to be used as the background.

This image may be simple (such as a solid color), or complex (such as pictures of cabinets and sub-assemblies, and similar).

To use a GIF background image, type its file name here, or use the selection button to browse to an image.

The images must be in the */usr/sigmet/config/images/* directory.

6.7.4 Bitex Data Point Configuration

Bitex supports the following types of data points:

- Status data points (information received from the RCP)
- Status QBITE point (from the RCP)
- Control data points (information sent to the RCP)

Status points are passive (accept no user input). They graphically display status information as reported by the RCP.

Control data points are active and include a button for toggling the status. The status of the button is sent to the RCP. The RCP decodes this uses this state to affect electrical outputs.

Status Bit Definitions		Help
Pulse Width Status	<input type="checkbox"/> Enabled	
Polarization Status	<input type="checkbox"/> Enabled	
Servo Power Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Transmit Radiate Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
T/R Power Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Signal Generator Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Siggen Cont.Wave Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Siggen Fault Status	<input type="checkbox"/> Disabled	
RCP Shutdown Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: HIGH	
	<input type="checkbox"/> Type: Normal	
Low Airflow Status	<input type="checkbox"/> Disabled	
Low Waveguide Pressure Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: LOW	
	<input type="checkbox"/> Type: Normal	
Antenna Local Mode Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Local: HIGH	
T/R Local Mode Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Local: HIGH	
Safety Interlock Status	<input type="checkbox"/> Disabled	
Standby Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Standby: HIGH	
Magnetron Current Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: LOW	
	<input type="checkbox"/> Type: Normal	
Azimuth Encoder Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Cal: HIGH	
Elevation Encoder Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Cal: HIGH	

Figure 18 Status Data Point Example



Figure 19 Status QBITE Data Point Example




Figure 20 Control Data Point Example

6.7.4.1 Configuring Status Data Points

- ▶ 1. Start **Bitex** with the `-setup` option.
- 2. Right-click the data point.

3. In the **Status Field Configuration Menu**, update the configuration.



The image shows a 'Status Field Configuration Menu' dialog box. It contains several configuration options:

- BITE Address**: Three spin boxes for Unit (1), Byte (6), and Bit (2).
- Field Name Text**: A text box containing 'Duty Cycle Fault'.
- Condition Text if Low**: A text box containing 'OK'.
- Condition Text if High**: A text box containing 'Fault'.
- Warning Flag**: Two radio buttons, 'High' (selected) and 'Critical'.
- Disable Warning if Field**: A text box containing 'Radiate'.
- is set**: A radio button labeled 'Low'.

At the bottom, there are three buttons: 'Apply All', 'Undo', and 'Cancel'.

BITE Address

The BITE address specifies which byte and bit in the BITE packets from the RCP corresponds to this status item. The BITE address has 3 parts:

- **Unit**
Corresponds to the one of the **Received Status Bits** units defined in the **Bite Customization Menu**.
- **Byte**
For this unit, what byte is used for this data point. Limited to a range between 3 and a customized number of bytes (N) minus 1 for this Unit (bytes 1, 2, and N are reserved).
- **Bit**
Corresponds to the bit (in the **Unit** and **Byte** numbers) that this data point is mapped to. Limited to the range 0... 6.

Field Text Name

The text string that appears on this data point that defines its meaning (up to 19 characters).

Select the button on the left of the field to choose a pre-defined text string. If a pre-defined field name is used, the allows **Antenna** utility recognizes this data point as a "special meaning" data point, and the **Antenna** utility displays the setting of this data point. This is only applicable to systems that require an INU (moving platform radars).

Condition Text if Low / High

Allow the display of optional text depending on the reported state of this data point.

If entered, this text is displayed on the left side of the actual data point display. This text can be up to 9 characters long.

Warning Flag

Controls fault generation. This can be set to **None**, **Low**, or **High**.

None means not to generate a fault based on this bit, otherwise the warning flag indicates the level considered a fault. If a fault is possible, the fault can be further conditioned with the **Disable Warning** field.

If the warning flag is set (value other than **None**), then if the data point is in the unfaulted state, the LED indicator is green. If the data point is in the faulted state, the data point is displayed as either yellow (non-critical), or red (critical) depending on the state of the **Critical** button (next to the **Warning Flag** selection).

If the warning flag is set to a value other than **None**, then this data point is or'ed into the overall status of this site. Thus this data point could cause this site to be considered faulted, or critically faulted. This information can be used by the RCP to allow channel changing in system employing redundancy.

Disable Warning

Lets you override a warning if a particular field is set to **Low** or **High**.

Use this when a condition should generate a warning only some of the time.

For example, a **High Voltage Missing** condition does not require a warning if the transmitter is turned off. By specifying this additional BITE condition, you disable the warning.

4. Select **Apply All**.

6.7.4.2 Configuring Control Data Points

- ▶ 1. Start **Bitex** with the **-setup** option.
- 2. Right-click the data point.

3. In the **Control Field Configuration Menu**, update the configuration.

BITE Address

The BITE address specifies which byte and bit in the BITE packets from the RCP corresponds to this status item. The BITE address has 3 parts:

- **Unit**
Corresponds to the one of the **Received Status Bits** units defined in the **Bite Customization Menu**.
- **Byte**
For this unit, what byte is used for this data point. Limited to a range between 3 and a customized number of bytes (N) minus 1 for this Unit (bytes 1, 2, and N are reserved).
- **Bit**
Corresponds to the bit (in the **Unit** and **Byte** numbers) that this data point is mapped to. Limited to the range 0... 6.

Field Text Name

The text string that appears on this data point that defines its meaning (up to 19 characters).

If Field

Allows for the button color to change based on some condition.

Select the button to the right of **If Field** and choose the conditional data point, **low**, **high**, or **None**.

To disable this feature, select **None**.

To change the color that the button changes, select the button next to **set color to**.

Button IN / OUT Text and Color

Allow text information to be displayed next to the button depending on if the button is pressed in or out.

You can also change the color of the button depending on its position.

In the example, no text is desired, so the information is blank.

Button IN control bit level

Sets the polarity of the data bit corresponding to this button.

The polarity is dependent on if the button is in or out.

This field selects the IN polarity, the OUT polarity is the opposite.

Momentary Button / Toggle Button

Configure buttons to be momentary (you must be applying pressure for the button to stay in) or as toggle buttons.

Normally Out / Normally In

Selects the normal position of the button.

IRIS Flag

When set to **Yes**, a message is sent to IRIS when the state of the button changes.

The message is put into the message log and status product.

4. Select **Apply All**.

6.7.4.3 Configuring Status QBITE Points

In QBITE, a quantitative value is passed. It is a packet in the an integer number of bytes in the data packet, using 7 bits/byte.

- ▶ 1. Start **Bitex** with the **-setup** option.
2. Right-click the data point.

3. In the **QBITE Status Field Configuration Menu**, update the configuration.

QBITE Status Field Configuration Menu

	Unit	First Byte	Byte Count
BITE Address	4 - Xmt Qbite	3	2
Field Name Text	Xmtr Temperature		
Units Text	Deg C	Unsigned	
Cal Slope	0.1000	Cal Offset	0.0000
Num Format	3 . 1	Example	xxx.x Deg C
Alarm Thresholds		> Greater	
Non Critical		Critical	
0.0 Deg C		0.0 Deg C	

Apply All Undo Cancel

BITE Address

The BITE address specifies which byte and bit in the BITE packets from the RCP corresponds to this status item. The BITE address has 3 parts:

- **Unit**
Corresponds to the one of the **Received Status Bits** units defined in the **Bite Customization Menu**.
- **Byte**
For this unit, what byte is used for this data point. Limited to a range between 3 and a customized number of bytes (N) minus 1 for this Unit (bytes 1, 2, and N are reserved).
- **Bit**
Corresponds to the bit (in the **Unit** and **Byte** numbers) that this data point is mapped to. Limited to the range 0... 6.

Field Text Name

The text string that appears on this data point that defines its meaning (up to 19 characters).

Units Text

A short string to display next to the QBITE value.

Cal Slope, Offset, and Signedness

The QBITE value is computed by first concatenating all the bytes together from the data packet. We then interpret this number as either a signed or unsigned integer, which is then multiplied by a slope, and an offset is added. Specify this here.

Num Format

Specify how many digits to show when displaying the QBITE value.

Alarm Thresholds

Controls fault generation. You can configure the system to generate both a critical and a non-critical fault based on the QBITE value.

Specify the threshold values and whether it should alarm above or below the threshold.

7. Color Setup

7.1 Color Setup Overview



This utility is a legacy feature used when viewing radar data with IRIS Analysis. When possible, Vaisala recommends viewing radar data with IRIS Focus.

The colors in the IRIS graphical displays are configured using the **Color Setup** utility. The displays use the following color classes:

- Data colors
For displaying data values as color coded levels.
- Special colors
Used for overlay lines, text, centroids, wind barbs, and so on.

When configuring the colors, be aware of the following concepts:

- Color set
A group of up to 16 colors used for displaying data. A color set can be used for several different data types and color scales.
IRIS supports up to 8 different color sets. For example, one may be used for positive data such as reflectivity or rainfall rate, while another may be used for signed data such as velocity of shear.
- Color scale or legend
A user defined set of numeric values for the color scale, as well as which color set to use. Each data parameter (**dBZ**, **R**, **V**, **TOPS**, and so on) can have up to 8 custom color scales.

Typically, you do not need to change the color sets and color scales very frequently. Access to **Color Setup** requires operator privilege. Observers can select different color scales and make their own uniformly-spaced color scales in the **Quick Look Menu**.



CAUTION! Changes to the color palette, color sets and color scales affects all displays. Operators should coordinate changes with the system manager.

7.2 Invoking Color Setup

1. Login as **radarop**.
2. In the terminal window, type: **color_setup**
The **Color Configuration** menu appears.
3. Select **ConfigColor Set Editor**.

4. Select **File** to save, list, or print **Color Setup** configuration settings.

Print creates an X-window dump of the menu you are running, as follows:

- **Print > to Printer** sends the output to the postscript or color printer specified in the **Printer Setup** menu.
- **Print > to File** sends the output to a file in your default home directory.
- **Print > Setup** lets you configure the printer on your system.

7.3 Configuring a Color Scale

Use the **Color Configuration Menu** to configure the numerical data values that are associated with each color band.



To see an example color scale, select **File > Open Example**.

This loads an example color scale for the selected data parameter (for example, velocity or dBZ). The numerical values of the color seams for the examples correspond to the suggested default values.

Table 8 Color Scale Data Parameters

Parameter	Signed (+_) or Positive	Description, Units, and Method
dBZ	Positive (Z)	dB of radar reflectivity factor in $\text{mm}^6 \text{m}^{-3}$
R	Positive	Rainfall rate in mm/hr or inches/hr
V	Signed	Velocity in m/s
W	Positive	Spectrum width in m/s
VIL	Positive	Vertically integrated liquid in mm
Height	Positive	Echo top height in km
Rain	Positive	Rain accumulation in mm
Shear	Signed	Wind shear in (m/s)/km
VILDen	Positive	Density of VIL
ZDR	Signed	Differential reflectivity (optional) in dB
KDP	Positive	Specific differential phase in degrees/km
User		
PHI	Positive	Differential phase in degrees
RHO	Positive	Cross-correlation scalar (0..1)
SQI		Signal Quality Index scalar (0..1)
LDR	Positive	Linear Depolarization Ratio in dB
Time	Positive	Time
Turb	Positive	Turbulence

Parameter	Signed (+_) or Positive	Description, Units, and Method
Temp	Signed	Temperature
Albedo	Positive	Albedo
HClass		Enumerated Echo Classification method dependent indexing (0..8)

- ▶ 1. Select the data parameter for which you would like to make a color scale. The **Units** field shows the quantities and range of values. The table shows if these quantities are treated as signed or positive only numbers, or as enumerated class identifiers.



dBZ can be negative if Z is less than 1 since it is a dB value.

2. Select **Levels** to define the number of levels in the color scale (2 ... 16). When you change the number of levels to be less than the maximum of 16, the unused levels are desensitized. Also, the top end point indicator shifts.

3. Select **Color Scale** to select existing color scales or to edit or to create new ones.

a. Select an existing **Color Scale** name to examine or edit it.

b. **New** creates a new name.

Up to 8 color scales are allowed for each data parameter, one must be named **Default**.

Set the **Default** scale to be something that you use frequently.



You can rename a **Color Scale** by editing an existing name. The old name is replaced by the new name.



When you first enter the **Color Configuration Menu**, the **Default** color scale is always loaded.

You can change the values of the **Default** scale but you cannot delete it.



If you already have 8 **Color Scale** names, you must to delete one before creating a new one.

c. Select **Delete** to delete a color scale.

Restrictions are:


- The current color scale name cannot be deleted.
- The **Default** color scale name cannot be deleted.

4. Select **Color Set > Signed** and the Color Set name.

The **Color Set** determines the order of colors from top-to-bottom. There are 4 available Color Sets, one of which must be named **Default**.

See [Configuring a Color Set \(page 99\)](#).

5. At the end points of the scale (top and bottom) toggle thresholding/saturation choice by selecting the arrow sign:



- **Saturate**
Displays all values outside the last seam as the boundary color. The left example above shows both the bottom and the top using saturation. This is indicated by the > and < signs.
- **Threshold**
Uses a fixed value as the outside limit. Values beyond the fixed value (either too high or too low) are not displayed. The right example above shows the case for thresholding at the top and the bottom.

If you select thresholding, type in the appropriate boundary value. The top and the bottom behavior can be specified separately.



For positive-going scales (dBZ, TOPS, VIL, R, and so on) use thresholding at the bottom and saturation at the top. Eliminates weak echoes from the display, while allowing you to see the very strong echoes.



You can configure the uniform step color scales in the **Product Configuration Menu** and the **Quick Look Menu** using the end-point behavior that you specify for the **Default Color Scale**.

6. Enter the color scale values:

- Entering the lower left value first (if you are using thresholding).
- Entering the remaining seam values starting at the bottom right and working upwards in the right column. Note that the values in the left column are filled automatically.

If a data value exactly matches a color scale seam, it is displayed as if it was above the seam. Everything \geq the lower seam and $<$ the higher seam is included in a color interval.

The values that are entered are formatted in the same manner as they are for the actual legends in the color display. The formatting is automatic to make numeric displays readable:

- Trailing zeroes are suppressed when possible. If there is a value with 10ths such as 1.1, then the trailing zeroes are used (for example, 5.0 rather than 5).
- In most cases 2 significant figures are shown in the legend, provided that the data type supports it and that it does not cause incidental trailing zeroes.

7. Select **Save All**.
The modifications to the current color scale are saved. You must restart the applications for which you changed the color scale for changes to take effect.
8. To start over, select **Restore All**.
This restores the last saved values.
9. Select **Exit** to exit the utility.

More information

- [Example Color Setup Values \(page 103\)](#)

7.4 Configuring a Color Set

Each color cell can be either a solid color, or a gradient color which changes continuously to the next value.

For gradient colors, the color at the top seam is set to the same value as the bottom color of the cell above.

There can be up to 8 color sets, one of which must be named **Default**.



To create, rename, or delete color sets, see [Configuring a Color Scale \(page 95\)](#).




Figure 21 Color Set Configuration Menu Example for Velocity

- ▶ 1. Check the currently shown color set.
The **Color Set** menu shows the current color set.

2. Select **File** to view the available color sets, including example color sets for common IRIS data types, one for gradient colors and one for solid colors.
3. To toggle between solid or gradient colors, select the buttons to right of the colors. If the button is pressed in, then the color cell is gradient.
4. To change a color set or create a new one (with a new order of colors) select **Config > Change Color Set**.
The **Color Set Configuration Menu** opens. If you had made changes to the color scale, you are prompted to save or cancel your changes.
5. To change the colors in the color set, highlight the color level that you want to change and use the scroll bars at the top to change the RVB values.
Your change are shown immediately in the color set (and in the color scale in the main menu).
You can select either the top or bottom of each color cell to adjust. For solid colors, either selection changes the whole cell.
6. Select **File > Close**.

7.5 Configuring Special Colors

You can use special colors for non-data items in the display such as overlays and legends.

Table 9 Special Colors

Name	Description	Default	R	G	B
Legend Background	Background behind the legend text	Black	0	0	0
Legend Text	Text on the legend background	White	255	255	255
Drop Shadows	Shadows cast underneath echoes for 3D look	Black	0	0	0
Overlay Level 1	Layer 1 lines typically used for geography	Black	0	0	0
Overlay Level 2	Layer 2 lines, for example, rivers, roads, political	Gray	128	128	128
Overlay Level 3	Layer 3 lines, for example, rivers, roads, political	Green	0	255	0
Overlay Text Background	Background color for text on the overlay	Tan	196	196	128
Underlay #1	To overlay areas, typically land color	LtBrn	212	155	95
Underlay #2	To overlay areas, typically sea color	Blue	117	117	199
Underlay #3	To overlay areas, typically special areas	Tan	170	155	95

Name	Description	Default	R	G	B
Centroid Ellipses	Fill color for warning centroids, typically bold	DkPink	200	100	220
Blink	Blinking data alternates with this color	Red	255	0	0
Track Line	Track lines drawn in this color	Black	0	0	0
Highlight	Forecast arrows and protected area hits	White	255	255	255
Shear Line	Shearlines drawn in this color	Black	0	0	0
Wind Barb Color	Wind barb displays	Black	0	0	0
Range Ring Color	Range ring overlays	Black	0	0	0

- ▶ 1. Select **Color Configuration > Config > Set Special Colors**.
The color configuration menu appears.
2. Use **File > Open > Example** to get the sample values that are listed in the table.

7.6 Configuring HydroClass Names

For the color scale for **HydroClass** data, each numerical value corresponds to an index of a discrete class.

You can customize the class indices displayed in the **HydroClass Name Editor** by defining a name for each class (text to display on the legend).

The meanings (associations with a class) of the **HClass** numerical values is specific to each classification method, as described in *sig_data_types.h*.




Figure 22 HydroClass Name Editor

- ▶ 1. In the **HydroClass Name Editor**, select the IRIS default name on the left column, and type your own custom name on the right.
Names are limited to 8 characters. You can name a new class or change the language of an existing class.

7.7 Example Color Setup Values

To make it easier to start your operation, example values are supplied for all menus. These are intended as examples only. You can use these until you get a feeling for the climatology and your particular application. The examples are summarized below.

Color Scales




Figure 23 Color Configuration Menu Example for Velocity

The default color scales are loaded in the **Color Configuration Menu**. First select the data parameter (dBZ, R, and so on), then select **File > Open Example**. The table below gives the examples for each data type.

Reflectivity - dBZ (mm ⁶ /m ³)				Rainfall - Rate R (mm/hr)		
Level	Start	Stop		Level	Start	Stop
16	66	>72		16	500	>800
15	60	66		15	200	500
14	55	60		14	100	200
13	53	55		13	80	100
12	50	53		12	50	80
11	44	50		11	20	50
10	39	44		10	10	20
9	37	39		9	8	10
8	34	37		8	5	8
7	28	34		7	2	5
6	23	28		6	1	2
5	21	23		5	0.8	1
4	18	21		4	0.5	0.8
3	12	18		3	0.2	0.5
2	7	12		2	0.1	0.2
1	2	7		1	0.05	0.1

Rain Accumulation - Rain (mm)				Vertically Integrated Liq - VIL (mm)		
Level	Start	Stop		Level	Start	Stop
16	800	>1100		16	32	>34
15	500	800		15	30	32
14	200	500		14	25	30
13	100	200		13	20	25
12	80	100		12	15	20
11	50	80		11	8	15
10	20	50		10	6	8
9	10	20		9	4	6
8	8	10		8	2	4
7	5	8		7	1	2
6	2	5		6	0.8	1
5	1	2		5	0.6	0.8

Rain Accumulation - Rain (mm)				Vertically Integrated Liq - VIL (mm)		
Level	Start	Stop		Level	Start	Stop
4	0.8	1		4	0.4	0.6
3	0.5	0.8		3	0.2	0.4
2	0.2	0.5		2	0.1	0.2
1	0.1	0.2		1	0.05	0.1

Velocity -V (+ is away in m/s)				Spectrum Width (W in m/s)		
Level	Start	Stop		Level	Start	Stop
16	30	>35		16	5.5	>6.0
15	25	30		15	5.0	5.5
14	20	25		14	4.5	5.0
13	15	20		13	4.0	4.5
12	10	15		12	3.5	4.0
11	5	10		11	3.0	3.5
10	2	5		10	2.5	3.0
9	0	2		9	2.0	2.5
8	-2	0		8	1.5	2.0
7	-5	-2		7	1.0	1.5
6	-10	-5		6	0.8	1.0
5	-15	-10		5	0.6	0.8
4	-20	-15		4	0.4	0.6
3	-25	-20		3	0.2	0.4
2	-30	-25		2	0.1	0.2
1	<-35	-30		1	<0.0	0.1

Wind Shear - Shear (m/s/km)				Echo Tops - Height (km)		
Level	Start	Stop		Level	Start	Stop
16	20	>25		16	???	???
15	15	20		15	16	>17
14	10	15		14	15	16
13	8	10		13	14	15
12	6	8		12	13	14

Wind Shear - Shear (m/s/km)				Echo Tops - Height (km)		
Level	Start	Stop		Level	Start	Stop
11	4	6		11	12	13
10	2	4		10	11	12
9	0	2		9	10	11
8	-2	0		8	9	10
7	-4	-2		7	8	9
6	-6	-4		6	7	8
5	-8	-6		5	6	7
4	-10	-8		4	5	6
3	-15	-10		3	4	5
2	-20	-15		2	3	4
1	<-25	-20		1	2	3

Specific Differential phase - Kdp (deg/km)				Differential Phase - PHI (deg)		
Level	Start	Stop		Level	Start	Stop
16	20	>33		16	169	>180
15	7.0	20		15	157	169
14	3.1	7.0		14	146	157
13	2.4	3.1		13	135	146
12	1.7	2.4		12	124	135
11	1.1	1.7		11	112	124
10	0.75	1.1		10	101	112
9	0.50	0.75		9	90	101
8	0.33	0.50		8	79	90
7	0.22	0.33		7	68	79
6	0.15	0.22		6	56	68
5	0.10	0.15		5	45	56
4	-0.10	0.10		4	34	45
3	-0.20	-0.10		3	23	34
2	-0.40	-0.20		2	11	23
1	<-0.80	-0.40		1	<0	11

Signal Quality Index - SQI (no units)				Depolarization Ratio - LDR (dB)		
Level	Start	Stop		Level	Start	Stop
16	0.94	>1		16	0	>2
15	0.87	0.94		15	-2	0
14	0.81	0.87		14	-4	-2
13	0.75	0.81		13	-6	-4
12	0.69	0.75		12	-8	-6
11	0.62	0.69		11	-10	-8
10	0.55	0.62		10	-12	-10
9	0.50	0.55		9	-14	-12
8	0.44	0.50		8	-16	-14
7	0.38	0.44		7	-18	-16
6	0.31	0.38		6	-20	-18
5	0.25	0.31		5	-22	-20
4	0.19	0.25		4	-24	-22
3	0.13	0.19		3	-26	-24
2	0.06	0.13		2	-28	-26
1	<0.00	0.06		1	-30	-28

ZDR (db)				HydroClass		
Level	Start	Stop				
16	5.0	>6.0		16		
15	4.0	5.0		15		
14	3.5	4.0		14		
13	3.0	3.5		13		
12	2.5	3.0		12		
11	2.0	2.5		11		
10	1.5	2.0		10		
9	1.0	1.5		9		
8	0.8	1.0		8		
7	0.5	0.8		7		
6	0.2	0.5		6	6	Hail
5	0.0	0.2		5	5	Graup

ZDR (db)			HydroClass			
Level	Start	Stop				
4	-1.0	0.0		4	4	Snow
3	-2.0	-1.0		3	3	WSnow
2	-3.0	-2.0		2	2	Rain
1	<-4.0	-3.0		1	1	NoMet

Color Set and Palette Examples

Select **Color Set Configuration Menu > File > Open Example** and choose either the velocity example or dBZ example.

This loads both a color palette and a color set. Note that the color palette is the same for both examples.

The velocity example shows a convenient color set for signed data. The dBZ example shows a convenient color set for positive data. You may want to save these as **Signed** and **Positive**.

The RGB values for the default color palette are given in [Figure 23 \(page 104\)](#).

Special Color Examples

Select **Special Color Editor Menu > File > Open Example**.

This loads examples for all special colors.

8. Dspx Utility

8.1 Dspx Overview

You can use the **Dspx** utility to debug the interface hardware to the RVP signal processor and to help develop new software that uses the signal processor.

You can also use **Dspx** to localize a problem when the DSP does not perform as expected.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

8.2 Invoking Dspx

1. In the command line, type one of the following commands

```
dspx -nochat
```

or

```
dspx
```

The **Dspx** prompt opens.

8.3 Dspx Commands and Prompts

When started with the **-nochat** option, **dspx** displays a prompt such as:

```
[110] :
```

For parallel interfaces, the prompt shows (in binary form) the three status lines coming from the DSP. The least significant prompt bit, when 1, indicates that data is available in the DSP output FIFOs. The other bits are unused.

Table 10 Dspx Commands

Command	Description
*	Perform a complete power-up restart of the DSP.
*f	Clear the DSP output FIFO.
*n	Clear the measured noise levels.

Command	Description
chat	Access DSP setup terminal information. The terminal behaves as if it were a TTY plugged into the DSP through the serial edge connector.
d [n [m]]	Display n words starting at location m . The data are shown in both Hex and Signed Decimal format. Variations on the d command are: <ul style="list-style-type: none"> • du which displays entirely in Unsigned Decimal • dx which displays entirely in Hex
q or e	Exit
f n m [#]	Fill, write n , m times, using DMA size #
gparm	Read the current GPARM values, and print them in a format that is easy to read.
? or h	Help, print command summary
r [n [#]]	Read up to n words, DMA size #
rays	Display history for the last 40 rays that were processed. The table shows the starting and ending Azimuth and Elevation, the number of samples, and the processing time for each ray.
repeat [n]	Repeat line n times
w n [n n ...]	Write word
~ [t]	Sleep t milliseconds (default 1000)
! [n]	Re-execute last line n times
;	Command separator

8.4 Dspix Plots

Dspix generates an X-Window version of the oscilloscope plots that are produced by the RVP plot commands.

You can access the **P** plot commands through the DSP chat mode. For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

The scope window appears when you enter a plot command.




Figure 24 Ps Plot Example

8.5 Dspix Chat Mode

You can use the `chat` mode to access the internal setup information in the signal processor (RVP).

- ▶ 1. Enter `chat` mode directly by starting **dspix** without the `-nochat` argument. Alternatively, enter chat mode using the **chat** command.

2. To begin the dialog with RVP, press **ESC**.

In **chat** mode, you can access the TTY setup commands from the host computer, as if it were a terminal plugged directly into the DSP.

When you are in **chat** mode, the normal square-bracket prompt disappears.

For information on TTY setup commands, see *RVP900 Digital Receiver and Signal Processor User Guide*.

Command List:

```
F: Use Factory Defaults
S: Save Current Settings
R: Restore Saved Settings
M: Modify/View Current Settings
Mb - Burst Pulse and AFC
Mc - Board Configuration
Mf - Clutter Filters
Mp - Processing Options
Mt<n> - Trigger/Timing <for PW n>
Mz - Transmitter Phase Control
M* - Stand-alone Settings
M+ - Debug Options
P: Plot with Oscilloscope
Pb - Burst Pulse Timing
Ps - Burst Spectra and AFC
Pr - Receiver Waveforms
P+ - Visual Test Pattern
V: View Jumpers and Status

?: Cmd list (?? Settings list)

*: Power-Up Reset

Q: Quit
```

3. To disconnect the terminal from the DSP, type: **q**

Dspix waits for you to press **Ctrl/C**, then returns to the **dspix** prompt:

```
> q

Exiting Setups...

^C

[110] :
```

8.6 Sample Dspx Session

You can use the commands in the following sample session to manually request the internal processor parameters, and display them in numerical format.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

```
$ dspx -nochat

Digital Signal Processor Examiner (DSP#1)

[110] : w 9

1 Words were written.

[111] : r

64 Words were received.

[110] : d

0000/ 0: e000 0096 07d1 e13e -8192 150 2001 -7874
0004/ 4: 00b6 0780 0514 0000 182 1920 1300 0
0008/ 8: 0000 0280 0000 0000 0 640 0 0
000c/ 12: 002d a7d6 001e 0096 45 -22570 30 150
0010/ 16: 0096 0000 00fa 7530 150 0 250 30000
0014/ 20: 07d0 1770 2ee0 5dc0 2000 6000 12000 24000
0018/ 24: 842b 0000 2710 2710 -31701 0 10000 10000
001c/ 28: 07d0 07d0 0017 0666 2000 2000 23 1638
0020/ 32: 000d fedf 0066 0050 13 -289 102 80
0024/ 36: fd89 0005 001e 0000 -631 5 30 0
0028/ 40: 0000 0000 0000 b3f6 0 0 0 -19466
002c/ 44: 0033 007a 0000 0780 51 122 0 1920
0030/ 48: 8000 0000 0000 0000 -32768 0 0 0
0034/ 52: 0000 0000 0000 0000 0 0 0 0
0038/ 56: 0000 0000 0000 0000 0 0 0 0
003c/ 60: 0000 0000 0000 0000 0 0 0 0
```

You can also view the corresponding results of a **gparm** command:

```

[110] : gparm

===== GPARM Read Back =====

Code Revision 14 Serial #: None

L-Status: 0x0000 I-Status: 0x0280 Diagnostics: 0x0000 0x0000

Current A/D Samples: I:5 Q:0 LOG:30

Requested Trigger: 600.00Hz Trig-Out: 600.00Hz Trig-In: 599.40Hz

Last PROC Starting and Ending rates: 600.00Hz, 600.00Hz

Maximum Trigger Rates: 3000.00Hz, 1000.00Hz, 500.00Hz, 250.00Hz

Trigger Count: 2014614 Wave: 0 PW: 0 PW-patterns: 0x842b

Bins in Range Mask: 150 Range Averaging: 1

Last AQ Bin Count: 150 Last Valid Bin Count: 150

AZ Tags: 0x6539 (142.34) EL Tags: 0x00b6 (1.00)

Noise Range: 250km Noise PRF: 200.00Hz

LOG Noise: 30.00 LENM: 30.00 LENS: -512.00

I-Mean: 5.08 I-STD: 0.25 Q-Mean: 0.00 Q-STD: 0.03

SOPRM Flags: 0x0017

Thresholds: LOG: 0.81dB WSP: 5.00dB SQI: 0.40 CCOR: -18.06dB

LOG Slope: 0.400 Cal Refl: -39.44dBZ Sample Size: 45

```

9. Overlay Utility

9.1 Overlay Overview



This utility is a legacy feature used when viewing radar data with IRIS Analysis. When possible, Vaisala recommends viewing radar data with IRIS Focus.

You can use the IRIS **Overlay** utility to draw overlays or maps for display on top of other IRIS/Open products. Overlays are used for product output and the real-time display.

An overlay can consist of the following:

- Geographical and political boundaries displayed with or without latitude and longitude lines or range rings.
- Text strings to label areas of interest, such as cities.
- Bitmap Icons that can be constructed by the user and applied to the overlay. Icons can represent any feature, for example, airports, train stations, and similar.
- The lines, text and icons mentioned above can be separated into different layers within the overlay file. Then at display time, either all or only a subset of these layers may be displayed giving yielding overlays that appear different based on which layers are active. Layers can be drawn in different colors.
- Underlays are filled regions of color displayed under the radar images where there is no weather data. Underlays are typically used to indicate areas of water.

Each overlay is defined in an ASCII file using a connect-the-dots approach (sometimes called a vector approach). This allows overlays to be drawn to any scale factor.

You use the **Overlay** utility to create and modify your own overlays in a window on your workstation.


Typically, you get the basic map (coastlines, borders, rivers) from Vaisala and then customize it to meet your needs. It is often convenient to make separate layers for different interests (river catchments, airports). IRIS supports up to 20 overlay files.

IRIS overlays are ASCII files so you can edit them with any text editor (**vi**, or **emacs** which is distributed with IRIS).

9.2 Invoking Overlay

- ▶ 1. Invoke the **Overlay** utility by typing: **over`lay&**
Overlay starts as a default with an empty window on your workstation. Settings from your previous session are still valid when you restart.

2. Open an overlay (*.ovr*) file from the */usr/sigmet/config/overlay* directory.



3. To see the latitude and longitude of your cursor, select **File > Display Lat Lon**.
You can move your cursor around your map with the mouse. To find a precise point, use the arrow buttons of the keyboard to move pixel by pixel.
4. To define the mode to show latitude and longitude, select **File > Lat Lon Units**.
You can display the values as degrees and decimals or degrees, minutes and their decimals.

5. To define the map display, select **File > Options**.
The **Options** window is shown.



- a. In the top pane, define the following:
- Display size in km**
Defines the horizontal size of the map in km.
 - North/East offset in km**
Move around your original map and create subareas.
 - Layers to draw**
Defines if you want to work with all of your map layers or only a subset.
- b. In the bottom pane, define the following:
- Fill points**
Indicate the areas, typically lakes, you want to be colored with a certain color.
 - Range Rings**
Centered at a predefined point, typically a radar site
 - Protected**
The areas you use with the **WARN** product
 - Lat Lon**
Displays a latitude-longitude grid


NoUnderlay

Do not use an underlay.


- c. Select the map projection.

Typically, **Azimuthal** is used in one-radar applications, **Mercator** in composites in the tropical areas and **Polar Stereographic** in the composites near the poles.

6. To create or modify a layer, select **File > Add/Modify Layer**.
Everything you add to an overlay goes to a layer. You can add or delete text, icons and fill points. You can also select a "pointer" which gives you position of you cursor.



- a. Assign each layer a color from a predefined set, shown in a box next to the layer name.
To define more colors, use the **Color** utility.
- b. To add content to a new or existing layer, select **Create New Layer**.
The **Add/Delete Tool** appears.



- To add icons, you must include a text next to the icon.

When you use icons, Vaisala recommends that you justify them right or left, because the icon goes to the point and the text should be next to the icon. You can highlight the text to give it a colored background.

- When adding text, most users want to justify text to center, so that the point shown with latitude and longitude in the upper column is under the middle character of your text.
- c. To merge 2 layers, in the **Add/Modify Layer** window, select target layer and ---.
 - d. To prevent the filled color from leaking around the edge of the overlay limits, use the **RANGE** command to tell **Overlay** how far you have drawn your overlay.
 - e. Define your underlay fill points.
Fill points are used to make an underlay. An underlay can contain up to 400 fill points. **Overlay** starts from each of the specified fill points and fills all contiguous areas, stopping at overlay lines.
You can enter many fill points for the same filled region. In fact, this is required for a coastline with deep bays, so that the region fills correctly at all scales. Many overlays contain coastline and use a blue underlay for ocean.
 - f. To delete items from a map, select a **Kill** option.
When you select a **Kill** option, your cursor becomes a killer tool and you can delete items from the map by pointing and clicking them. There is a separate kill tool for text, icons and fill points to minimize the risk you kill something you didn't want to kill. If you can't kill what you want, you are probably working with a wrong layer.
7. Select **Header** to check the overlay file header.

Header Info	
Site	fin
Fill Range	1170.00
Fill Center	66° 0.0'N/ 26° 0.0'E
Draw Center	64° 0.0'N/ 26° 0.0'E

See [Overlay Header \(page 126\)](#).

9.3 Listing and Printing Overlay Files

Overlay files in use on are stored on disk in a directory called *IRIS_OVERLAY*. The product output process always looks for overlay files in that directory.

To see a list of the overlay files stored on your system, issue the following commands from the operating system prompt:

```
$ cd $IRIS_OVERLAY  
  
$ ls
```

Overlays for many IRIS sites are included in the release in the *IRIS_ROOT/config_template/overlay* directory. **Overlay** defaults to the *IRIS_OVERLAY* directory, unless you specify a path in the file name.

The overlay directory should contain only overlay files. Do not use it to store any other kinds of file. In addition, Vaisala recommends that you follow these file naming conventions for any overlay files that you create:

- Use the *.ovr* suffix or file extension to denote overlays. The product output process uses only these files. The **Overlay** utility uses files with this extension by default. That is, if the file has the *.ovr* suffix, you do not need to type the suffix when you display it using **Overlay**.
- Use *.xbm* to denote bitmap overlay icons that are referenced within the overlay files.

Because overlays are ASCII files, you can print them on your system printer.

9.4 Viewing an Overlay Example

The overlay template directory contains a file called *sample.ovr*. It contains some text strings, a simple overlay area, and an underlay area.

To display *sample.ovr*:

- ▶ 1. Run the **Overlay** utility, specifying the name of the overlay file, as follows:

```
$ cd ${IRIS_ROOT}/config_template/overlay

$ overlay ./sample
```

Overlay processes the file, which may take several seconds. If you supplied the **-v** option, it responds with summary statistics as follows:

```
12 (max 40) icon files, using 311 (max 12000) bytes:

0: dot9.xbm      1: dot7.xbm      2: dot13.xbm
3: airport.xbm   4: beacon.xbm    5: test.xbm
6: building.xbm  7: golf.xbm      8: hospital.xbm
9: park.xbm      10: poi.xbm      11: train.xbm

Processing Overlay file.
10 (max 200000) points, 25 (max 400) strings, 9 (max 4000) fill points and
0 (max 10) gifs
1 (max 32) named layers:
0: Default
Site Draw center: 42°24.0'N 71° 6.0'W
Fill center: 42°24.0'N 71° 6.0'W
```

This summarizes the icon files found, then the number of end points, text strings, and fill points in the selected overlay. Finally the latitude and longitude of the draw and fill center are shown.

Overlay always draws range rings centered at the draw center, while the **Product Output** menu aligns it with the radar.

2. **Overlay** displays the overlay on the screen in using the colors specified in **Color Setup**, as shown in the following figure. Optional range rings or a latitude and longitude grid are drawn in green. Filled areas have a maximum range, which is specified in the file. A circle is drawn at that range, the underlay areas are filled, then the circle is removed.

3. When you have finished looking at the overlay file, return to the terminal or window where you invoked **Overlay** and press **CTRL/C**.




Figure 25 Sample Overlay Display

9.5 Format of Overlay Files

When creating an overlay, you must transfer the points from a map to an overlay file.

There are 2 major paths available to you when building an overlay file: absolute or relative coordinates.

Overlay files are defined with a special syntax. A small set of simple statements specify the location of the radar and place the text or lines on the map. A semicolon (;) marks the beginning of a comment line.

The **END** statement marks the end of the map. Anything that appears in the file beyond the **END** statement is ignored.



It is sometimes helpful during editing to put an **END** in the middle of a file, so that **Overlay** plots only the map lines and text up to that point.

9.5.1 Overlay Header

Absolute Coordinates

If the overlay is defined in absolute coordinates, all points in the overlays are given in terms of a longitude, latitude coordinate pair. This sets an absolute position for each point.

The following header commands must be included at the top of the overlay file:

Table 11 Overlay Latitude and Longitude Header Commands

Command	Description
PROJECTION latlon	Informs system overlay is in absolute coordinates.
DRAW_CENTER lon lat	Tells Overlay where to center the image. Generally this is the either the coordinates of the radar site, or a nearby special area of interest such as an airport.
FILL_CENTER lon lat	Specifies center of fill area. Typically this is the center of the array of data points you have generated.
FILL_RANGE range	Sets the maximum range that the underlay covers, in km. Overlay draws a circle at this distance from the fill center before filling the underlay.

Relative Coordinates

If the overlay is defined in relative coordinates, all points are defined in terms of map units. Map units are any arbitrary unit of measure that is E/W and N/S of an origin (0,0), which can be anywhere on the map.

Often millimeters from graph paper are used to designate the points on a map. The map must be in azimuthal equidistant projection, with the specified reference point. A scale factor specifies the conversion between these map units and distance on the surface of the Earth.

The following header commands must be included at the top of the overlay file:

Table 12 Overlay Map Unit Header Commands

Command	Description
PROJECTION aed	Informs system overlay is in relative coordinates.

Command	Description
SCALE scale	Sets the scale factor in km/map unit. The SCALE n command must be used to specify how many kilometers each map unit specifies. For example, if a RADAR 100 200 and a SCALE 0.5 command are used, then if later a point is specified as POINT 110 200 , this point is exactly 5 km due east of the reference position.
RADAR x y	Sets the projection point in map units and specifies the location of the reference point in the map units.
REFERENCE lon lat	Sets the projection point in absolute coordinates.
DRAW_CENTER lon lat	Same as lat lon projection.
FILL_CENTER lon lat	Same as lat lon projection.
FILL_RANGE range	Same as lat lon projection.

For backwards compatibility, the old **MIDDLE** command still has the meaning of setting both the draw center and the fill center.

9.5.2 Text Strings and Bitmap Icons

Text

You can place many strings of text on the overlay. Use the full ROMAN8 character set. If you wish to include embedded spaces, enclose the string in double quotes ("").

You can place text on the overlay in terms of map units, specifying the justification: left, center, right, top, or bottom. The justification remains in effect for all subsequent strings until another justification is specified.

You can also place text on the overlay relative to the edge of the display screen. In these cases, the position is in 10 000 ths of the screen measured from the lower left corner. For example, a location of (5000, 500) is in the middle near the bottom.

Bitmap Icons

The bitmap icons supported by IRIS are black and white icons (*.xbm* files). Color icons are not supported (*.xpm* files).

Icons of any size are supported, but using large icons is not practical. If icons are larger than 16 by 16 pixels, they take up too much of the screen.

You can edit icons using the icon editor that comes with the UNIX system.

Once icons are edited in the icon editor, place the *.xbm* files in the **\$IRIS_OVERLAY** directory and overlay files can make reference to them by name.

Statements and Commands

Table 13 Appearance Statements

Command	Description
SIZE #	Set the text size in pixels, range 7 ... 26.
HIGHLIGHT	Use highlighted text (reverse video).
NORMAL	Use normal video text.

Table 14 Map Unit Justification Statements

Command	Description
TOP	Text is top-justified.
BOTTOM	Text is bottom-justified.
LEFT	Text is left-justified.
RIGHT	Text is right-justified.
CENTER	Text is centered.

Table 15 Screen-relative Justification Statements

Command	Description
SCN_CENTER	Text is centered relative to the screen.
SCN_LEFT	Text left-justified relative to the screen.
SCN_RIGHT	Text is right-justified relative to the screen.

Table 16 String Location and Content Statements

Command	Description
TEXT x y str	Places the text str at the specified location.
ICON_TEXT str	Same as above TEXT command, but str is placed next to the bitmap icon specified in the most recent ICON command.
TEXT x y str1 str2	Places the text str1 at the specified locations. The text str2 is available in the tabulation key in the display options menu. Generally str1 is a short abbreviation that fits cleanly on the screen and str2 is the full string that is not printed on the screen, but is available in the tabulation.
ICON_TEXT s1 s2	Same as the above TEXT command, but s1 is placed next to the bitmap icon specified in the most recent ICON command.

Table 17 Icon Command

Command	Description
ICON <i>x y name</i>	Places bitmap icon specified by name at position <i>x y</i> .

9.5.3 Map Outlines

An overlay typically consists of many lines. You draw a line by specifying the beginning and ending points.

Table 18 Map Outline Statements

Statement	Description
POINT <i>x y</i> or <i>x y</i>	Places a point at the specified coordinates along an overlay line; expressed in map units.
GAP or *	Marks a break or the end of an overlay line.

9.5.4 Layer Functions and Commands

Overlay files can be composed of a single layer, or divided into up to 32 different layers.

- When a single layer is used, the complete overlay is always displayed (this includes all lines, text and icons).
- When multiple layers are defined, any combination of layers can be displayed at runtime.

For example, there may be a main layer called coastlines that is always displayed and other layers such as roads, rivers, power plants, that can be turned on or off individually. Each layer can contain lines, text and icons.

When defining layers in an overlay file, all entries in the file that occur after the initial layer command are applied to that layer. This continues sequentially through the file until the file ends, or another layer command is encountered.

Table 19 Layer Definition Commands

Command	Description
LAYER <i>name</i>	Defines a layer called name . All commands following in the overlay file (until another LAYER command is encountered) are applied to this layer. You can enable this layer at run time by selecting its name in the display options menu.
LAYER_COLOR <i>name color</i>	All lines defined in the layer called name are drawn in the color . The color must be overlay1 , overlay2 , or overlay3 . The colors are defined in color_setup .

9.5.5 Solid Underlay Regions

An underlay is a range with outer boundaries, a filled area, and a color number specifying the color to use for the filled area.

We use the term *underlay* to indicate that this color is visible only when there is thresholded radar data, so it seems to be under the data.

Overlay starts from each of the specified fill points and fills all contiguous areas, stopping at overlay lines. You can enter many fill points for the same filled region. This is required for a coastline with deep bays, so that the region fills correctly at all scales.

Many overlays contain coastline and use a blue underlay for ocean. To prevent the filled color from leaking around the edge of the overlay limits, use the **RANGE** command to tell **Overlay** how far you have drawn your overlay.

Table 20 Solid Underlay Statements

Statement	Description
FILL_COLOR color	Sets the color of the underlay region. Color should be <code>underlay2</code> or <code>underlay3</code> .
FILL x y	Marks the starting point for the fill area.

9.5.6 GIF Underlay Regions

A GIF underlay is a full color picture used to fill the background between overlay lines and features.

Like solid underlays, this is visible only when there is thresholded radar data. Areas outside the radar coverage circle are displayed with a darkened version of the GIF underlay.

Do not mix GIF underlays and filled solid underlays.

Table 21 GIF Underlay Statements

Statement	Description
UNDERLAY_CENTER lon lat	Selects the center location of an underlay file.
UNDERLAY_PROJECTION AED	Selects the projection of the underlay file.
UNDERLAY_REFERENCE lon lat	Selects the projection reference location.
UNDERLAY_STDPAR par1 par2	Optional standard parallels.
UNDERLAY_ELLIPSOID rad 1/flat	Selects the equatorial radius (km) and flattening of the earth. 1/Flattening of 0 means circular.
UNDERLAY_SCALE x y	Selects the projection scale in km/pixel.
UNDERLAY_FILE file.gif	Selects the name of an underlay file. The file must reside in the <code>{IRIS_OVERLAY}</code> directory.

The following table shows a summary of supported projections.

Table 22 Summary of Supported Projections

AED	Azimuthal Equidistant
EDC	Equidistant Cylindrical
GAUSS	Gauss Conformal
GNOMONIC	Gnomonic
LAMBERT	Lambert Conformal Conic
MERCATOR	Mercator
POLSTEREO	Polar Stereographic
UTM	Universal Transverse Mercator
PERSPECTIVE	View from geosynchronous satellite

9.5.6.1 Installing Gif Image in Your Overlay

- ▶ 1. Copy your *.gif* file to the overlay directory.
2. Create a new layer called **Underlay** using the **Add/Delete** menu.
3. Go back to the **Options** menu to turn on the new **Underlay layer**, so you can see it later.
4. In the **Add/Delete** menu:
 - a. Select **Add underlay**
 - b. Select **Underlay layer**, then
 - c. Fill in the underlay properties box.
 The projection type is **Equidist Cylinder**.
 The center and projection reference should be the center of your image.
 - d. Sometimes the downloaded image seems to be 1° or 1 minute off from the expected value. To compute the underlay scale, first compute the range scale, which is the number of km/degree at your center latitude, with the following equation:

$$RangeScale = \frac{\pi}{180} \times 6371km \times \cos(Latitude)$$
 - e. Divide by the GIF scale (in pixels/degree) to give you the underlay scale in km/pixel. For example, an overlay centered at 45° north, has a range scale of 78.62 km/degree (48.9 mi/degree), and at 120 pixels/degree, yields 0.65522 km/pixel (0.4 mi/pixel).
5. Apply and save.

9.5.7 Example of an Overlay File

```

; This is a sample overlay to demonstrate the overlay features.
; Put this in ${IRIS_ROOT}config/overlay and call it sample.ovr
;
; The semicolon ";" is used at the beginning of comment lines.
;
; All distances are in arbitrary "map units" with coordinate points
; denoted with E-W first and N-S second. See overlay description.
;
PROJECTION AED
; The scale factor in km per "map unit":
SCALE 1.000
;
; The radar location in map units:
RADAR 0 0
REFERENCE -71.100 42.400
;
FILL_CENTER -71.100 42.400
DRAW_CENTER -71.100 42.400
; Next come the text strings:
; First the text size (Height in pixels, range 7 through 25)
SIZE 16
;
; Next the text justification (left, center or right)
SCN_CENTER
;
; Then the text location and text string (E-W first, N-S second)
HIGHLIGHT
TEXT 5000 8450 Examples
TEXT 5000 8000 Of
TEXT 5000 7550 Text
;
; Here are font and justification examples for many sizes
; First do the size 7
SIZE 7
RIGHT
TEXT -150 85 7Right
; The two lines above cause the text "7Right" to be positioned with
; its right at map unit position (250, 350).
CENTER
TEXT -150 70 7Center
; For center, there is no position dot and text "7Center" is centered
; at the specified location.
LEFT
TEXT -150 55 7Left
; For left, the dot is to the left of the text "7Left"
;
SIZE 9
RIGHT
TEXT -50 90 9Right
CENTER
TEXT -50 70 9Center

```

```

LEFT
TEXT -50 50 9Left
;
; Now change the size to 10 and repeat the examples:
SIZE 10
RIGHT
TEXT 50 95 10Right
CENTER
TEXT 50 70 10Center
LEFT
TEXT 50 45 10Left
; Now change the size to 13 and repeat the examples:
SIZE 13
RIGHT
TEXT 150 100 13Right
CENTER
TEXT 150 70 13Center
LEFT
TEXT 150 40 13Left
; Now change the size to 16:
SIZE 16
RIGHT
TEXT -150 -35 16Right
CENTER
TEXT -150 -70 16Center
LEFT
TEXT -150 -105 16Left
SIZE 20
RIGHT
TEXT -10 -30 20Right
CENTER
TEXT -10 -70 20Center
LEFT
TEXT -10 -110 20Left
SIZE 25
RIGHT
TEXT 130 -25 25Right
CENTER
TEXT 130 -70 25Center
LEFT
TEXT 130 -115 25Left
;
; Here is a message in the lower left corner of the screen
SIZE 13
SCN_LEFT
TEXT 200 200 File:sample.ovr
; And finally the points for the map lines in map units:
; Example of a small rectangle to enclose text examples:
; E-W first, N-S second.
-230 -180
-230 180
230 180
230 -180
-230 -180
GAP

```

```

; The word "gap" above is used to denote the last point of a map line.
;
; To start another map line, continue entering map coordinates and
; put "GAP" after the line is complete.
;
; Put "END" at the end of the file. Note that it is sometimes
; helpful during editing to put "END" in the middle of a file
; so that overlay will only plot the map lines and text up to
; that point.
;
; Here is a large rectangle around everything:
-250 -250
-250 250
250 250
250 -250
-250 -250
; Here are some underlay fill points. These points are used to start a
; region fill, and should be spaced about the area of concern.
RANGE 0
FILL_COLOR underlay2
FILL -240 -200
FILL -240 -100
FILL -240 50
FILL -240 150
;
FILL 240 -150
FILL 240 -50
FILL 240 50
FILL 240 150
FILL_COLOR underlay3
FILL -50 -50
END
; End of SAMPLE

```

9.6 Format of Catchment Files

Catchment files are similar in format to overlay files. They contain a series of points connected by vectors. They also support a ";" for comments, and **END** to mark the end of the file. There is only one file header command.

IRIS supports a maximum of 20 catchment files.

Table 23 Catchment File Commands

Command	Description
DRAW_CENTER lon lat	Tells overlay where to center the image. Generally this is either the coordinates of the radar site, or the center of the catchment area.
SIZE size	Sets the size to draw subcatchment names. This is the height in pixels, and it applies until the next size command in the file.

Command	Description
WARNING threshold	Specifies warning threshold in mm. An alert is issued if this is exceeded, and it applies until the next warning command in the file. A value of 0 means no alerts.

Catchment files are divided into a series of subcatchments. Each starts with a header specifying the name and label location followed by the data points. The datapoints must define a closed polygon. Make sure the last point matches the first one. There can be a maximum of 512 subcatchments defined in each catchment file.

Table 24 Subcatchments

Subcatchment	Description
START number name	Tells the number and name of the subcatchment area.
LABEL lon lat	Specifies the location to draw the name when labeling the subcatchment. This location must be inside the region.

9.7 Creating and Editing Overlay Files



Creating and editing overlay files should be done only under the supervision of the system manager.

- ▶ 1. Use a computerized geographic database to get the array of coastlines and political boundaries you want.
2. Manually add the header commands, display it with overlay and make needed repairs.
3. Add the desired text and icon features.
4. Add underlay fill points. When doing this you may discover more breaks in the overlay lines which need to be repaired.
5. Test the underlay filling by displaying over a broad range of image sizes, for example 50, 100, 200, 400, and 800 km (31.1, 62.1, 124.3, 248.5, 497.1 mi). It is usually necessary to add fill points in lakes and bays pointing towards the display center.
6. When you are satisfied with your overlay, place it in the **\$IRIS_OVERLAY** directory.

9.8 Assigning an Overlay to a Radar Site

The IRIS system manager associates a default overlay file for each site connected to the system. You can assign a different overlay to the site.

- 1. In the **Overlay** menu, highlight the site you want to change.
 A list of available overlays is shown.
 The following figure shows an example with 2 overlays for the **HEL** site: **HELSINKI** and **KARTTA**.




Figure 26 Site Overlay Example

2. Select an overlay from the list.
 The menu also shows the site IDs for which the overlay is valid.
 If you try to display a product with an invalid overlay, IRIS displays the message,
 Overlay origin more than 1000 km from radar location (1000 km = 621.4 mi). If
 you get this message, check that the correct overlay is assigned to the radar site.

10. Real Time Display

10.1 Real Time Overview

Real Time Display (RTD) is a diagnostic and monitoring tool that allows you to instantaneously view data, ray by ray, as they are acquired.

The rays of data (for example, 1°) are shown on the display as the antenna scans with no perceptible delay. Both PPI and RHI display styles are supported.

A real time display is used in a variety of ways:

- *Observers*: View immediate feedback on the weather situation.
- *Manual task operation*: Provides radar operators with immediate feedback during manual antenna control (for example, using handwheels or the **Antenna** utility). This is useful for probing rapidly changing weather features such as a developing hook echo, or weak echo region.
- *System managers*: Provides feedback for tuning signal processor parameters.
- *System managers and radar operators*: Provides ways to verify that the system operates properly and generates high-quality data.

Real time display is not practical for remote unattended radar sites with low-bandwidth network connections (for example, <100 KBytes/sec).

10.2 Real Time Display Data Handling

The real time display (RTD) data are output by the IRIS system at the radar site, or directly by the RVP. Ray-by-ray output packets are sent over the network using UDP broadcast messaging.

Many workstations can monitor the RTD without placing any additional burden on the network traffic. You can tune the number of data parameters and range bins to match the available network bandwidth. For example:

- Transmitted parameters: **Z**, **V**, and **W** only (3 bytes)
- Number of bins: 500
- Scan rate 4 RPM: (24° per second)
- Scan resolution: 1°

In this case the data rate is 36 KBytes/sec or 288 kbps. This means that real time display can easily be done for Ethernet (10 mbps) or T1 (1 mbps) connections.

For slower connections, you must reduce the number of bins, increase the resolution, and/or slow the scan rate.

Note that the radar probably also sends processed or **RAW** products over the network link. You must consider the bandwidth requirement for these products.

More information

- [Setting-up Real Time Display \(RTD\) \(page 164\)](#)

10.3 Launching Real Time Display

- ▶ 1. Do one of the following:
 - Choose **Menus > Real Time Display** from the **IRIS** menu bar.
You do not need to be connected to an IRIS server to start the display.
The real time display appears in the **DEFAULT** configuration with a blank (black) background. If data currently are being sent by the radar workstation, then within 2 seconds, the display starts to paint and the green LED in the upper corner of the display flashes.
 - In the **IRISNet**, select your site (where you are sitting) and then the real time display icon.
 - In a terminal window, type the following:

```
$ rtdisp&
```

2. To view multiple displays simultaneously:
 - a. Create multiple saved configurations with each using a different port number.
 - b. Use the command line option to specify which file to use. For example:

```
$ rtdisp -file port30726&
```

```
$ rtdisp -file port30727&
```

10.4 Real Time Display Menu




Figure 27 Real Time Display

File Menu

The **File** menu allows you to open and save files and print real time display images.

Saved config files are stored in the $\${IRIS_CONFIG}$ directory with names ending in *.rtdisp*.

Note that when *rtdisp* is started without an explicit configuration name, it uses the *DEFAULT* configuration file.



CAUTION! *Save as...* is used to store your custom display configuration. You must select **File > Save as...** to save your changes permanently.

Config Menu


Use the **Config** menu to change some basic parameters.



Ranges

Modifies the list of available display ranges.

RHI Display Opt ...



Sets the appearance of RHI displays:

- **Max Height** can be specified either in km or Kfeet, the latter is used if the horizontal range scale is selected to be nautical miles. The aspect ratio adjusts automatically.
- **Min Height** is normally set to 0. You can set it negative to handle banking on airborne radars.
- **Use RHI for Manual-Type Scans**
By default, IRIS Manual scans are displayed in PPI format. You can override the default to cause manual scans to be displayed in RHI format.
- Depending on the antenna capabilities, select either a standard 90° scan or an "Over the top" 180° scan depending on the antenna capabilities.

Text Colors

Chooses color for text in AZ/EL, and similar display.



The large format numerals in the **Real Time Display** are designed to be read from several meters distance.
You can change the color of the numerals using **Config > Set Colors**.

Sweep Line

Enables/disables a line showing the radar sweep.



Status LED

The LED at the top of the display shows the status of the data stream to the real time display.

- Fixed red on start up indicates that no data are being sent, or that data have not been received for 5 minutes (time-out). For diagnostic information, see [Configuring Real Time Display Transmitter \(page 145\)](#).
- Flashing green indicates that data are currently being received.
- Fixed green indicates that data are not currently being received, but data have been received within the last 5 minutes.



SLT

Site ID Field for Multiple Radars

This field shows the 3 letter radar site ID. For installations that have more than one radar, this field can be used to select which radar is viewed on the real time display.

If you have multiple radars, select the button to the right of the LED to get a list of sites and select the site that you want to display.

Site Status and Selection						
Site Name	Site	SiteID	Task Name	Status	Data	
SIGMET, humid	HUM	20	PPIVOL_C	OK	dBZ	V
SIGMET, sleet	SLT	30	PPIVOL	OK	dBZ	V W

18:17:58

Time Display

The data time (not the local workstation time) is displayed to the nearest second in large format numerals.

This updates approximately once per second when data are arriving.

When no data are arriving, the display time does not update so that the time reflects the data that remain on the screen.

The date of the data is displayed in smaller characters above the time.

323.7 6.0

AZ/EL Display

Azimuth and elevation angles are displayed to the nearest tenth degree in large format numerals.

This updates approximately once per second when data are arriving.

When no data are arriving, the angles do not update so that the elevation angle reflects the data that remains on the screen.

Maximum Range

One of four maximum ranges can be selected by clicking on the numerical field under the AZ/EL display.

To set these ranges and the units, use **Config > Set Ranges**.

Data Selection for Display

Select this field to select the type of data for display. The choices are:

- dBZ
- Velocity
- Width

After you make your selection, the display resets and starts painting the new data type.



CAUTION! If the radar system IRIS is not configured to collect and transmit the selected data type, then no data is displayed. See [Configuring Real Time Display Transmitter \(page 145\)](#).




Overlays

The overlay features for the real time display include:

- Geographic overlays
- Range rings or lat/lon lines

To access these options, select the **Overlays** button to access the **Overlays** menu.



Select **Geographic** to select from a list of available overlays, or **Off**.

Select **Range Rings** to select among:


- Off
- On
- On with numeric labels
- Latitude/Longitude grid (with numeric labels)



Color Scale

You can modify the colors used to represent the data.

Select the **Colors** button to open the **Color** menu. After making a change, the display resets and is painted with the new color scale.



See the Color Scale Tool section in *IRIS Product and Display Guide* .



Entering a level step of 0 for velocity has the special meaning to display the full unambiguous velocity range. This range is not known until data are received. The velocity color scale show all zeroes in this case until data are received.

10.5 Configuring Real Time Display Transmitter

You must have operator privileges to configure the data transmission from the radar site.

10.5.1 Setup Utility Configuration

The **setup/RVP** utility has several questions relating to both the transmitter and receiver ends of the real time display, for example:

- What data are sent (**dBZ**, **V**, **W**) by the transmitter.
- The maximum number of range bins to be transmitted.
- The socket port is used for transmission (typically set to 30730).
- What IP broadcast addresses are to be used for transmission.

More information

- [Setting-up Real Time Display \(RTD\) \(page 164\)](#)

10.5.2 Using Rtd_echo

You can use the **rtd_echo** utility program to help configure real-time display transmissions on complicated networks. This program reads the RTD socket traffic on a computer and retransmits it to another address. It can change both the destination address and port number.

The configuration is available with command line options. To see the choices, run **rtd_echo -?**.

Only one program can read from a socket port. If you are running **rtd_echo** on a machine, then another **rtd_echo**, or the **rtdisp** utility cannot read from the same port.

Typical uses for **rtd_echo** are:

- Transmitting data to a target host which is not directly accessible from the source system (that is no network route, you cannot ping directly).
- Transmitting data through network routers and switches which do not allow broadcast addresses.
- Transmitting data once through a limited bandwidth line, then echoing with a broadcast address, or multiple distinct addresses to lots of machines.

In this case, if you are echoing to a network address which includes the echoing machine, you must use a different port number. This is to prevent **rtd_echo** from reading its own output and producing an infinite loop.

Here is an example of how to configure:

- Radar machine: 2 outputs in setup/RVP: 127.0.0.1 Port 30730, 192.168.45.1 port 30731.
- Echo machine (192.168.45.1): Run **rtd_echo -a:192.168.45.255 -i:30731**

This gives the following features:

- All **rtdisp** programs can be configured the same to read from port 30730.
- **rtdisp** works on the radar machine (using the 127.0.0.1 address).
- **rtdisp** works on all the 192.168.45 network including the echo machine.

Once you have **rtd_echo** working fine from a shell command, add it to your */etc/rc.d/rc.local* file with a trailing **&** so it runs every time you boot.

11. Setup Utility

11.1 Setup Overview

The **Setup** utility configures the software for the characteristics of the radar.

Because information from **Setup** is used by many other utilities, run this utility first.

You must have detailed information about your radar system to answer some of the **Setup** questions.

More information


- [Color Setup Overview \(page 94\)](#)

11.2 Invoking Setup and Built-In Error Checking

When IRIS starts, it performs configuration and bounds checks.

For new users, the **Setup** parameters are typically correctly set and do not cause any configuration errors. If an error does occur, follow these steps.

1. In the terminal window, type: **setup&**
The **Setup** utility launches.



2. Select the part of the system setup you want to check or configure.
3. Make your changes and close the window for the selected part of the system.

4. Select **File > Save**.
The configuration files are now updated.
5. To create a listing file of the **Setup** configuration:
 - a. Select **File > List**.
A listing file called `YYYYMMDDHHMM.setup` is created in the `${IRIS_LISTINGS}` directory.
6. To take the configuration changes into effect, restart the application:
 - a. For changes made to the **Setup > IRIS** section, restart the IRIS daemons by typing:

```
$ sudo /sbin/service qiris  
$ sudo /sbin/service iris start
```

- b. For changes to the **Setup > RVP** section, stop any running utilities and restart RVP by typing:

```
systemctl stop/start iris/rvp900/rcp8
```

- c. If you make changes in **Setup > RVP**, you must also restart IRIS and utilities. RVP has a configuration state accessible through **dspix**. Part of that state is local to the processor and part of it is also visible in **Setup > RVP**.
 - d. For changes to the **Setup > RCP** section, in addition to the above, you must stop RCP8 (if you have one), and stop the antenna daemons, by typing:

```
$ sudo /sbin/service qiris  
$ sudo /sbin/service rvp900 stop  
$ sudo /sbin/service rcp8 stop  
$ qant  
$ sudo /sbin/service rcp8 start  
$ sudo /sbin/service rvp900 start  
$ sudo /sbin/service siris
```

RCP8 has a configuration state accessible through **Antx**. These changes take effect when you return to the top level prompt. You must save your changes.



License changes can affect RVP and IRIS.

7. If an error list is displayed,
 - a. Check the error list for parameters that you have customized and correct these customizations.
 - b. Select **Repair** to make corrections that are necessary for the software but do not need to be customized for your operation.
 - c. Select **File > Save**.

11.3 Running Setup After Upgrade

After upgrading, the **Setup** utility fills in default values for any new questions that were added. It is recommended that you read the release notes, then check the new questions to make sure they are right for your system.


- ▶ 1. Login as **radarop**.
2. Launch the **Setup** utility.
 At startup for an upgrade, **Setup** checks the parameters to verify that they are within reasonable bounds and lists any problems.
 The listing gives the name of the variable in question and prompts the user to consider the repair command. Errors are usually related to new features that have not been addressed or outdated features that do not conform to the current upgrade.
3. In the list dialog, select **Repair** to replace any mismatches with the appropriate default.
4. If you receive errors related to customized fields that are important to your operation, see [Invoking Setup and Built-In Error Checking \(page 147\)](#).

11.4 Radar Video Processor Setup

To configure radar video processor (RVP) parameters, launch the **Setup** utility and select **RVP - Radar Video Processor**.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide*.

11.4.1 System Type



System Type		Help
System has a signal processor	<input type="checkbox"/> Yes	
Interface to RVP	Native	
Processor Type	RVP900	
Check byte order on powerup	<input type="checkbox"/> Yes	

Figure 28 RVP System Type Setup Parameters

System has processor

- Select **Yes** for radar systems. When selected, additional configuration parameters are shown.
- Select **No** for Analysis systems.

Interface type

- **DspExport**
- **Native**
- **SCSI**

For SCSI interfaces, type the SCSI device path in **Device file**.

For **dspexport** interfaces, you see the following questions:

dspexport host name or IP Address

Set the host name with the processor.

dspexport Port

Set the port number, normally 30740.

Processor type

Select your RVP.

Check byte order on powerup

The recommended setting is **No**.

Select **No** for systems with a pre-processor that does not support these opcodes.

11.4.2 Optional Data Parameters

Optional Data Parameters		Help
Polarization Diversity	<input type="checkbox"/> Enabled	
Polarization receiver scheme	<input type="checkbox"/> Dual	
Polarization transmit scheme	<input type="checkbox"/> Dual	
ZDR Tx/Rx gain offset	0.00 dB	
Burst power diff. (v/h) at calibr.	0.00 db	
LDR Rx gain offset	0.00 dB	
HV off time before Polar change	i 0.00 sec	
Max Wait for Polarization change	i 5.0 sec	
XMT Supports Horizontal Only	<input type="checkbox"/> Yes	
XMT Supports Vertical Only	<input type="checkbox"/> Yes	
XMT Supports Simultaneous	<input type="checkbox"/> Yes	
XMT Supports Alternation	<input type="checkbox"/> No	
Differential Phase (PhiDP)	<input type="checkbox"/> Enabled	
Correlation Coefficient (RhoHV)	<input type="checkbox"/> Enabled	
Depolarization Ratio (LdrH&V)	<input type="checkbox"/> Enabled	
Covariance Magnitude (RhoH&V)	<input type="checkbox"/> Enabled	
Covariance Angle (PhiH&V)	<input type="checkbox"/> Enabled	
HydroClass (HClass)	<input type="checkbox"/> Enabled	
Signal Quality Index (SQI)	<input type="checkbox"/> Enabled	
Signal-to-Noise Ratio (SNR)	<input type="checkbox"/> Enabled	
Major mode 'USER1' custom name		
Major mode 'USER2' custom name		
Major mode 'USER3' custom name		
Major mode 'USER4' custom name		

Figure 29 RVP Data Parameters

Polarization Diversity

Select whether your radar supports multiple polarizations.

The figure shows an example with polarization diversity turned on.

Polarization receiver scheme

Select the type of polarization receiver system you have. Choices are **Single** and **Dual**.

Select **Dual** for receivers on both the co- and cross-polarized channels. This allows measurement of depolarized power, for example. For more information, see dual polarization processing algorithms in *RVP900 Digital Receiver and Signal Processor User Guide*.

Polarization transmit scheme

Select whether the radar has a single transmitter or two transmitters.

"Polarization transmitter scheme" field active only when "Polarization Diversity" enabled.

If Polarization transmit scheme: **single**:

- In Calibration:
 - Test signal gen. control in use
 - Test signal level
- In Pulse Width #x:
 - Burst power at calibration
 - Digital filter loss at calibration

If Polarization transmit scheme: **dual**:

- In Optional Data Parameters: Burst power diff. (v/h) at calibr.
- In Calibration:
 - Test signal gen. control in use
 - Horiz test signal level
 - Vert test signal level
- In Pulse Width #x:
 - Transmit power at calibration (V)
 - Burst power at calibration (H)
 - Burst power at calibration (V)
 - Digital filter loss at calibration

Burst power diff. (V/H) at calibr.

This field is active when **Polarization Diversity** is enabled and **Polarization transmitter scheme** is set to **Dual**.

Signal Quality Index

Select if you wish to allow the recording and display of SQI.

This enables **SQI** options in the task configuration menu and in **Ascope**.

Signal-to-Noise Ratio (SNR)

Select if you wish to allow the recording and display of SNR.

This enables **SNR** options in the task configuration menu and in **Ascope**.

Major mode 'User 1' custom name

Use these optional fields to take advantage of the extensibility of the RVP API and specify customized Major modes.

See *RVP900 Digital Receiver and Signal Processor User Guide*.

Single Polarization Radar

Polarization

For fixed polarization radars, enter the type of polarization here. Options are **Horizontal** and **Vertical**.

Dual Polarization Radar



RVP requires a license to produce dual-pol data.

For radars with polarization diversity, the following configuration options are available:

ZDR Tx/Rx gain offset

This is an offset used on systems able to calculate ZDR if there is a difference between the gain at the 2 different polarizations which results in a bias.

This number is added to the ZDRs otherwise computed. It is stored to the nearest 1/16 of a dB.

LDR Rx gain offset

This is an offset used systems able to calculate LDR if there is a difference between the gain at the 2 different polarization receivers which results in a bias.

This number is added to the LDRs otherwise computed. It is stored to the nearest 1/100 of a dB.

Polarization Handling

The following parameters manage polarization handling:

HV off time before Polar change

When the transmit polarization is changed, the **dsp** library turns off the high voltage this much in advance of the switch.

This is needed on some systems to prevent arcing while switching.

For Vaisala systems, the default value is 1.0 seconds.

To disable the feature, enter a value of 0.

Max Wait for Polarization change

Enter the worst case time it could take to switch polarization.

The **dsp** library waits for confirmation of the new polarization, up until this time is exceeded.

If there is no confirmation, then this time is always waited. If the high voltage was turned off before the switch, it is turned back on after the wait.

For Vaisala systems, the default value is 3.0 seconds.

XMT Supports...

Defines which transmit modes the transmitter supports (H only, V only, simultaneous H+V, alternating H+V).

Vaisala radars support H only and simultaneous H+V.

Available Polarization Moments

Use the following parameters to select which types of polarization transmission are available on your radar:

- Differential Phase (PhiDP)
- Correlation Coefficient (RhoHV)
- Depolarization Ratio (LdrH&V)
- Covariance Magnitude (RhoH&V)
- Covariance Angel (PhiH&V)
- HydroClass (HClass)
- Signal Quality Index (SQI)

Enable all polarization parameters that can be measured by your radar system. There is no question for ZDR, because that is available on most dual-pol radars.



HydroClass requires a license in RVP.

11.4.3 System Parameters

Figure 30 RVP System Parameters

Transmit Wavelength

Enter the wavelength in centimeters.

Transmitter Type

Choose the transmitter type of the radar (for example, Magnetron or SSPA). This example illustrates that the phase control option displayed if a magnetron transmitter is used.

Default PRF

Enter the PRF to be used by the utilities if the PRF is otherwise unspecified. Set it below the maximum PRF for the longest pulse width to preserve the transmitter duty cycle regardless of the pulse width setting.

Noise Sample PRF

Enter the PRF in Hz for noise sampling (see *RVP900 Digital Receiver and Signal Processor User Guide*). Typically, a value of 200 Hz is adequate.

Number of Pulsewidths

Enter a number 1 ... 4 for the number of pulse widths that are supported.

HV off time before PW change and Wait time after PW change

Controls behavior if the pulse width and PRF values change by defining the following conditions:

- How long to wait after changing the PW before changing the PRF.
- How long to wait after changing the PRF before changing the PW.
- How long to wait after changing the PW before we are sure we can detect the new PW state.
- How long to wait after changing the PW before we turn on the HV, if it was turned off.

See the following examples.



These delays protect magnetron radar transmitters, which take some time to change their pulse forming networks, and protect systems using the RCP to control the pulse width. When the RCP controls the pulse width, there may be a small variable delay before the command takes effect.

For example, for magnetron transmitters, the suggested values are 0 for the **HV off time before PW change**, and 0.5 seconds for the **Wait time after PW change**.

When IRIS changes the PRF only, and not the Pulse Width:

It freely changes the PRF without any delays.

When IRIS changes the Pulse Width only, and not the PRF:

1. Turn off the High Voltage (only if it was on, and the **HV off time before PW change** is nonzero).
2. Wait the time specified in **HV off time before PW change**.
3. Set the pulse width to the new value.
4. Waits the time specified in **Wait time after PW change**.
5. If possible, checks that the pulse width actually changed.
6. Turn High Voltage back on (only if turned off in step 1).

When IRIS changes the Pulse Width and the PRF, and the new PRF is higher than the old PRF:

1. Turn off the High Voltage (only if it was on, and the **HV off time before PW change** is nonzero).
2. Wait the time specified in **HV off time before PW change**.
3. Set the pulse width to the new value.
4. Wait the time specified in **Wait time after PW change**.
5. If possible, checks that the pulse width actually changed.
6. Sets the PRF to the new value.
7. Wait the time specified in **Wait time after PRF change**.

8. Turn High Voltage back on (only if turned off in step 1).

When IRIS changes the Pulse Width and the PRF, and the new PRF is lower than the old PRF:

1. Turn off the High Voltage (only if it was on, and the **HV off time before PW change** is nonzero).
2. Wait the time specified in **HV off time before PW change**.
3. Set the PRF to the new value.
4. Wait the time specified in **Wait time after PW change**.
5. Sets the pulse width to the new value.
6. Wait the time specified in **Wait time after PRF change**.
7. If possible, checks that the pulse width actually changed.
8. Turn High Voltage back on (only if turned off in step 1).

11.4.4 RVP calibration

The following parameters are shown when **Polarization Diversity** is enabled:

Calibration		Help
Horizontal beamwidth	0.90 deg	
Vertical beamwidth	0.90 deg	
Antenna gain	45.0 dB	
Cal signal bandwidth	Narrow (SG) <input type="checkbox"/>	
Horiz Transmit loss H Only	2.0 dB	
Horiz Transmit loss H+V	2.0 dB	
Horiz Receive loss	2.0 dB	
Horiz Test signal loss	52.6 dB	
Vert Transmit loss V Only	0.0 dB	
Vert Transmit loss H+V	0.0 dB	
Vert Receive loss	0.0 dB	
Vert Test signal loss	0.0 dB	
Test signal gen control in use	<input type="checkbox"/> Yes	
Frequency control available	<input type="checkbox"/> Yes	
Level control available	<input type="checkbox"/> No	
Horiz test signal level	1.00 dBm	
Vert test signal level	2.00 dBm	

Figure 31 RVP Calibration Parameters - Dual-transmitter radar

The following parameters are shown when **Polarization Diversity** is disabled:

Parameter	Value
Horizontal beamwidth	0.90 deg
Vertical beamwidth	0.90 deg
Antenna gain	45.0 dB
Cal signal bandwidth	Narrow (SG)
Transmit loss	2.0 dB
Receive loss	2.0 dB
Test signal loss	52.6 dB
Test signal level	0.00 dBm

Figure 32 RVP Calibration Parameters - Single-transmitter radr

Horizontal beamwidth/Vertical beamwidth

Type the horizontal and vertical antenna half-power beam widths in degrees.

Antenna gain

Type the antenna gain on the axis of the antenna in dB.

Cal signal bandwidth

- For a normal signal generator enter **Narrow**.
- For a noise source enter **Broad**. For noise sources, enter the **ENR** value.

For noise source, you must use a single point calibration, for a signal generator you must use multiple power levels.

Horiz/Ver Transmit loss

Type the transmitter power loss values in dB between the transmitter and the antenna feed.

Horiz/Ver Receiver loss

Type the receiver loss values in dB from the feed to the receiver. This is usually the same as the transmitter loss.

Horiz/Vert Test signal loss

In performing calibrations, a test signal generator is injected into the system. This accounts for any loss of test signal power in the connection between the test signal injection point and the receiver. Losses in the cabling and in the directional coupler are usually included here. These losses may also be calibrated out when you set up your signal generator.

Internal test signal gen. in use

Select whether internal test signal generator is in use.

Answering **Yes** activates the test signal level fields.

If **Polarization Diversity** is disabled in the optional data parameters, then only one field is available.

Horiz test signal level

Type the horiz test signal level.

Vert test signal level

Type the vertical test signal level.



For dual polarization radars, you can type loss values for the horizontal and vertical channel to deal with differences in the waveguide, as well as correcting for transmitter power effects.



Single polarization and simpler configurations have fewer loss values.

Example

In the following example, we assume that the horizontal and vertical powers are both 200 kW, with a 1.0 dB loss in the horizontal waveguide, and a larger 1.5 dB loss in the vertical waveguide.

We also assume that in H+V mode, the power splits unevenly with 90 kW to horizontal and 110 kW to vertical. This gives 3.5 and 2.6 dB losses over the full power case. This is added to the waveguide losses to get 4.5 and 4.1 dB.

Horiz Transmit loss H Only	1.0 dB
Horiz Transmit loss H+V	4.5 dB
Horiz Receive loss	2.0 dB
Horiz Test signal loss	0.0 dB
Vert Transmit loss V Only	1.5 dB
Vert Transmit loss H+V	4.1 dB
Vert Receive loss	2.0 dB
Vert Test signal loss	0.0 dB

11.4.5 Signal Processing Options

Signal Processing Options	
Gaseous attenuation	0.0160 dB/km
Power spectrum window	Hamming (Def)
AGC decay code	3
Dual-PRF / AGC delay	2
Parameter data width	8&16 Bit
Velocity sign	Normal
Sync mode fuzz angle	0.15 deg

Figure 33 RVP Signal Processing Parameters

Gaseous attenuation

The gaseous attenuation constant determines the atmospheric attenuation in dB/km used by RVP when acquiring radar data. For a 5-cm radar, a reasonable default value is 0.016 dB/km.

Power spectrum window

Select the type of window that the signal processor should use when power spectra are computed. Choices are:

- **Rectangular**
- **Hamming (Def)**
- **Blackman**

AGC decay code

Enter the time constant of the exponential average applied to the log receiver to produce the AGC signal. ONLY used on the RVP6 processor only, and it is typically set to 3.

Dual-PRF / AGC delay

Enter the number of pulses to send through the clutter filters prior to the start of each ray. These pulses stabilize the filters. Typically set to 2.

Parameter data width

- **8-bit**
- **8&16-bit**. In this mode, you can select the data width in the task configuration menu.

Velocity sign

- **Normal**.
Vaisala recommends that you set this parameter to **Normal** unless you have another computer wired up to the signal processor which displays velocities reversed and cannot be changed.
- **Inverted**.
IRIS inverts the velocities as they are read from the signal processor, and the **Ascope** utility reverses the **T** and **A** signs on its display.

Sync mode fuzz angle

The suggested value for this is 0.15°. If IRIS uses angle sync mode, this controls the tolerance.

For more information, see *RVP900 Digital Receiver and Signal Processor User Guide* .

11.4.6 Data Simulations




Figure 34 RVP Data Simulation Parameters

The data simulator provides separate time series for every bin that is being processed.

Along with **Ascope**, this provides a convenient way to study the bias and uncertainty of processing algorithms on simulated data.

Clutter width scientific units

Options are **Normalized** or **meters/sec**.

Clutter width (Gaussian model)

More information

- [Digital Signal and Target Simulators \(page 62\)](#)

11.4.7 Pulse Width Definitions

The parameter window is different according to whether the **Polarization Diversity** parameter in **Optional Data Parameters** is set to **Enabled** or **Disabled**.

Pulse Width #1 (Code:0) Definitions	
Pulsewidth	1.00 usec
Range mask spacing	125.00 meters
Output bit pattern	1
Minimum PRF	250 Hertz
Maximum PRF	1200 Hertz
Transmit power at calibration	250000 Watts
Burst power at calibration	11.00 dBm
Digital filter loss at calibration	0.00 dB

Figure 35 RVP Pulse Width Definition parameters: Polarization Diversity disabled

Pulse Width #1 (Code:0) Definitions		Help
Pulsewidth	4.00 usec	
Range mask spacing	150.00 meters	
Output bit pattern	1	
Minimum PRF	50 Hertz	
Maximum PRF	2500 Hertz	
Transmit power at calibration (H)	211800 Watts	
Transmit power at calibration (V)	50000 Watts	
Burst power at calibration (H)	0.00 dBm	
Burst power at calibration (V)	0.00 dBm	
Digital filter loss at calibration	0.00 dB	
Noise equivalent bandwidth	1.10 Mhz	

Figure 36 RVP Pulse Width Definition parameters: Polarization Diversity enabled

Each pulse width has its own set of configuration parameter values:

Pulsewidth

Enter the first pulse width (usually the shortest) in microseconds.

Setup prompts for the other pulse widths.

Range Mask Spacing

Set this value to match to the spacing (in meters) between successive bins in the range mask of your signal processor.

The value varies depending on the type of signal processor, and with the choice of acquisition clock frequency.

The resulting bin spacing (that should be copied into this setup slot) is printed in the RVP TTY dialog.

Output bit pattern

Enter the base 10 value of the 4-bit output signals that the signal processor uses to control pulse width.

Recommended values are 1, 2, 4, and 8 for pulses #1 ... 4.

This has no effect on systems that do not use the signal processor to control the pulse width.

Minimum PRF

Check with your manufacturer to see if there is a lower limit. A value of 160 Hz is usually acceptable.

Maximum PRF

Enter the maximum PRF in Hz allowed for pulse width #1 (specified above).

Setup prompts for all pulse widths.

Use the PRF limit corresponding to the longest pulse width (this should be the lowest maximum PRF). This guards against cabling errors.

Transmit power at calibration

Enter the peak transmit power (Watts) for each pulse width. Set unused pulse widths to 0.

Burst power at calibration (H)

Burst power at calibration (V):

Digital filter loss at calibration

11.4.8 Custom Trigger Period Sequences

This is a feature only implemented on RVP7.

Always leave these lengths set to 0.

11.4.9 Setting-up Real Time Display (RTD)

The screenshot shows a software interface for configuring the Real Time Display (RTD). It consists of two main panels. The top panel, titled 'Real Time Display', contains the following settings: 'System transmits RTD' is set to 'From RVP'; 'RTD transmitter priority' is set to 4; 'Max. number of bins in display' is set to 500; and 'Number of RTD channels' is set to 1. The bottom panel, titled 'RTD Channel #0', contains the following settings: 'Name of RTD transmitter #1' is set to 'rtd_v1_xmt'; 'Broadcast IP address #1' is set to '127.0.0.1'; 'UDP port #1' is set to 30730; and 'Data to send' is set to 'Z,V&W'. Each panel has a 'Help' button in its top right corner.

Figure 37 RVP RTD Parameters

System Transmits RTD

This option enables or disables the transmission of the RTD and shows or hides the RTD setup options.

When enabled you can specify up to 16 separately configured transmitter channels. Choices are:

- **No**
RTD transmission is disabled.
- **From App**
An application program such as IRIS Ingest issues RTQ library calls to supply the data stream.
- **From RVP**
RVP provides the data. In this case, the host application requires no modification to support RVP generating a display.
A single computer cannot generate from both sources.
If you are using **dspexport**, then both the host computer and RVP can generate data.

RTD transmitter priority

Maximum number of bins in display

This parameter limits the bandwidth of data transmitted over the network for the real time display.

It is used only in `rtd_v1_xmt`.

The display is usually acceptable with only a few hundred range bins of data. The maximum size of a ray that can be transmitted over the network is approximately 1500 bytes. Each data type takes up 1 byte. If there are more range bins in a task than can be sent, IRIS sends only 1 out of every **N** bins, where **N** is the smallest number possible.

Number of RTD channels

Shows the number of RTD channels. You must increase this number each time you add a new RTD channel to the configuration.

RTD Channel Parameters

Each RTD channel has its own set of configuration parameters:

Name of RTD transmitter #1

Specify the name of the executable program which is run to transmit the real time display stream for this channel.

Vaisala recommends the default transmitter `rtd_v1_xmt`.

Vaisala also ships 2 other transmitter programs: `rtd_v2_xmt` and `rtd_nids3_xmt`.

You can also customize the format by writing your own program and entering it here.

The API and the existing transmitter programs are public.

Broadcast IP address #1

Specify the broadcast addresses here.

Generally only one is used, and it is your network address with the machine number set to 255.

You can use the local loopback address 127.0.0.1 to display only locally. To find your address, type `netstat -nr` to list your interfaces.

For example, if your interface is called `eth0`, type `ifconfig eth0` to show your broadcast address. If it is not there, you may need to turn on the broadcast feature.

UDP port #1

Specify your port number here. Any unused port number can be used, but Vaisala suggests using 30730 as a default.

Data to send

Select **Z,V,&W** for minimal data types, **Single Pol** for all single polarization data, or **Dual Pol** for all data types.

This control also only applies to the **rtd_v1_xmt** format.

Note that there is an internal limit of 10 data types.

More information

- [Real Time Display Data Handling \(page 137\)](#)

11.5 Radar Control Processor Setup

To configure radar control processor (RCP) parameters, launch the **Setup** utility and select **RCP - Radar Control Processor**.

For more information, see *Radar Control Processor RCP8 User Guide*.

11.5.1 Interface to RCP

The screenshot shows the 'Interface to RCP' configuration window. The window has a title bar with the text 'Interface to RCP' and a 'Help' button. The main area contains several configuration options, each with a label and a control element:

- System has an antenna**: A checkbox labeled 'Yes'.
- Main Interface to RCP**: A dropdown menu showing 'Serial'.
- Antenna angle insertion source**: A dropdown menu showing 'Normal RCP'.
- Is this the 1 controlling host**: A checkbox labeled 'Yes'.
- Main serial device name**: A text input field containing the character 'i'.
- Receive format from RCP**: A dropdown menu showing 'RCV02 (Enhanced)'.
- Transmit format to RCP**: A dropdown menu showing 'XMT02 (Enhanced)'.
- Allow extended packets**: A checkbox labeled 'No'.

Figure 38 RCP Interface Configuration Parameters

System has an antenna

In most environments only the radar host systems have an antenna. Select **No** for all analysis and display systems.

Main Interface to RCP

- **Network**

This is the most common interface on RVP and RCP systems. It uses a multicast network socket to send and receive information from the RCP.

For network interfaces you must enter the multicast address, port number, interface, and network delay.

- **Serial**

This is the legacy serial cable interface. You must also enter the serial device file name. For RVP systems using a serial tag interface to the RCP, enter **Serial** for the interface and **Normal RCP** for the angle source.

- **AntExport**

Not recommended for general use. Allows a low-bandwidth remote host to get antenna control and status. All the other setup questions are removed because that information is automatically exported from the main RCP system.

- **None**

On an RVP systems with a hardware interface for angle input (either parallel tags or synchro inputs) enter **None** for the interface, and **Native RVP** for the angle source.

For RCP and RVP interface configuration examples, see [Network Export Overview \(page 242\)](#).

Antenna angle insertion source

Shows which angle source used to determine the current antenna position. Other information, such as the status and control bits always comes from the **Normal RCP** interface.

- **Normal RCP**

The antenna angles arrive in the normal network packets from the RCP.

- **Native RVP**

The RVP gets angles from a hardware source.

- **Native RCP**

The RCP inherently knows the antenna position.

Is this the 1 controlling host

Select one of your computers to be the controlling host.

This is the only computer that sends transmit packets to the RCP. These packets control antenna position and other switches. If you configure more than one host as a controller, you cannot be in full control.

Network Interface Configuration Options

Network Multicast Address

We suggest using the default address of 224.0.0.3. This is a "link-local" address which by default is not passed through routers and instead goes through switches and hubs. If you need to go through a router, consider using the `site-local` address

239.255.0.1.

The strength of the multicast addressing scheme is that the antenna position information can go to several recipients simultaneously, so both the RVP and the IRIS host can receive antenna information. However, the packets may travel to other machines on the local network and cause network administrators to complain.

Be sure to set the same address and port number on RCP8 and RVP as needed. The multicast addresses have many reserved values, so if you have more than one RCP8 system at a site, we recommend using different port numbers, rather than different addresses.

Network Port Number

Suggested default of 30785. Increment from there if needed.

Network Interface

Specify which Ethernet interface to use for the RCP communication.

If the antenna information does not need to leave the local computer, then use the loopback interface of `lo`.

Average Network delay

Vaisala recommends that you start with the default value of 0 ms here. This is the packet transmission delay from the RCP8 to the local system. For slow networks measure this by pinging RCP8 and enter half the average ping time.

Serial Interface Configuration Options

Main serial device name

Type the pathname of the device file for the serial port wired to the RCP. For internal simulation, set this to blank.

You can freely substitute FIFOs for serial device files. What to do is based on the device name: If the device pathname ends in `-x` or `-y`, then IRIS assumes that we are opening a FIFO pair to be used in some sort of loopback mode.

For example, first create the FIFOs:

```
$ cd /usr/sigmet/config
$ mkfifo ant_fifo-x ant_fifo-y
```

Then choose `/usr/sigmet/config/ant_fifo-x` as the device name. IRIS writes to the specified FIFO, and reads from the other. If the RCP is a Vaisala RCP, choose `/usr/sigmet/config/ant_fifo-y` as the **RCP8/SiteHost** serial port.

Running at and with parity

Specify the baud rate and parity of the serial port.

For **AntExport** interfaces expect the following questions:

AntExport hostname/IP-Address

Type the host of the exporting system.

AntExport Port Number

Suggested default of 30745.

All Interfaces**Receive format from RCP**

Enter one of the following antenna reception formats for both the main and auxiliary:

- **No Reception**
- **rcv01 (Original RCP)**
- **rcv02 (Enhanced RCP)**
- **rcv03 (Shipboard Format)**
- **rcv05 (Dual System)**
- **Scientific Atlanta 3860**

Transmit format to RCP

Enter one of the following antenna reception formats for both the main and auxiliary:

- **No Transmission**
- **xmt01 (Original RCP)**
- **xmt02 (Enhanced RCP)**
- **xmt05 (Dual System)**
- **Scientific Atlanta 3860**

Allow extended packets

For Vaisala radars, set this to YES.

For information on the reception formats, see *IRIS Programming Guide*.

11.5.2 Advanced Interface Features

Advanced Interface Features Help

Antenna is on a moving platform ☐ No

Auxiliary receive format No Reception

Auxiliary transmit format No Transmission

Start RCP Simulator ☐ Yes

Transmit subprocess priority i -15

Receive subprocess priority i -15

Timezone of time packets ☐ UTC

Trust timestamps in RCVxx ☐ Yes

Extended header format name

Figure 39 RCP Advanced Interface Configuration Parameters

Antenna is on a moving platform

Use this to enable the INU related setup questions, and platform motion correction in the real-time display.

INU info insertion source

This tells which INU source we are using. Normally we use RCP8. If we are getting INU information from a custom extended header library, then enter **Custom Header**. Only visible on moving platform systems.

Auxiliary receive/transmit format

Some systems have 2 serial lines each for transmitting and receiving RCP control information.

Only the primary line is used to receive information. If your system uses 2 lines, configure the second line as the auxiliary.

Auxiliary serial device name

Available when a **Auxiliary receive format** is set to something other than **No reception/transmission**.

Enter the auxiliary serial device file when used.

Start RCP Simulator

Used for simulated systems to automatically start up the antenna simulator when the antenna driver starts.

Receive/Transmit Subprocess Priority

On UNIX systems, set the priority to -15.

Timezone of time packets

Some RCPs are configured to send the current time to IRIS over the serial link. Use this value to set the time of the radar computer at the safest times. This specifies the timezone of that data stream.

Trust timestamps in RCVxx

Some RCP serial formats include a timestamp used to accurately time sequence the received data.


Set this to **No** on systems attached to RCPs that do not fill in those numbers.

Extended header format name

Set this to blank for systems with no custom extended header.

If you have custom extended headers, enter the name of the extended header shared library.

11.5.3 Packet and Data Logging



Packet and Data Logging	
Produce log files on disk	<input type="checkbox"/> Yes
Log incoming Antenna I/O Packets	<input type="checkbox"/> No
Log incoming BITE I/O Packets	<input type="checkbox"/> Yes
Log incoming Time I/O Packets	<input type="checkbox"/> Yes
Log unrecognized I/O Packets	<input type="checkbox"/> Yes
Log AZ/EL data insertions	<input type="checkbox"/> No

Figure 40 RCP Packet and Data Logging Configuration Parameters

Produce log files on disk

Choose either **Yes** or **No**.

You can use antenna log files to debug errors in the antenna position, BITE packets, Time packets, and INU packets.

When enabled, a log file called `${IRIS_LOG}antlib.log` is created. This log file is rotated using log rotate, as configured by `/etc/logrotate.d/sigmat-antlib`.

These files are also used to produce the BITE histograms.

Log incoming Antenna I/O Packets

Choose either **Yes** or **No** to log incoming Antenna I/O Packets in the antenna log file.

Log incoming BITE I/O Packets

Choose either **Yes** or **No** to log incoming BITE I/O Packets in the antenna log file.

Log Incoming Time I/O Packets

Choose either **Yes** or **No** to log incoming Time I/O Packets in the antenna log file.

Log unrecognized I/O Packets

Choose either **Yes** or **No** to log unrecognized I/O Packets in the antenna log file.

Log AZ/EL data insertions

Choose either **Yes** or **No** to log the AZ/EL position of the antenna in the antenna log file.

Log INU data insertions

Choose either **Yes** or **No** to log INU data in the antenna log file.

11.5.4 Radar Site and Antenna Placement

To check or update radar placement information, select **Setup > RCP Radar Control Processor**.

Radar Site and Antenna Placement	
Ground height above sea level	2000.0 meters
Antenna height above the ground	500.0 meters
Default Latitude of antenna	38.98765 deg North
Default Longitude of antenna	29.12345 deg East

Figure 41 RCP Radar Site and Antenna Placement Configuration Parameters

Ground height above sea level

Enter the height above sea level (in meters) of the ground at the radar site. All product heights are referenced to this value.

If you wish to make products relative to sea level, enter 0 and put the ground height and tower height into the next question. If the radar is on a ship, then a value of 0 is appropriate.

Antenna height above the ground

Enter the height of the radar antenna above the ground height chosen above. ¹⁾

Default Latitude of antenna

Enter these values in decimal degrees with as many places of accuracy as desired (N and E are positive). ¹⁾

Default Longitude of antenna

Enter these values in decimal degrees with as many places of accuracy as desired (N and E are positive). ¹⁾

¹⁾ If you are using RCV03 format, this number (set in meters) is overridden by the altitude reported from the antenna controller.

Moving Platform Systems

Antenna position ...

Enter the distance in meters from the inertial navigation unit (INU) location to the antenna location. This is recorded with the data and used for platform motion velocity corrections.

For example, if the INU is located in the middle of a ship at sea level, and the antenna is 10 meters (32 ft 10 in) above the sea, 15 meters (49 ft 3 in) to the stern and centered, enter the values **-15**, **0**, and **10**.

INU height offset

For moving platform systems that do not correctly measure the height of the INU, this number is added to what is reported by the antenna controller.

Antenna Scan geometry

Choose from: **Traditional** and **Aircraft Tail**.

For an **Aircraft Tail** radar, the elevation angle scans continuously and the azimuth angle is the angle of the scanning cone, where 0 is perpendicular to the elevation axis. See *IRIS Product and Display Guide*.

11.5.5 Antenna Characteristics

Parameter	Value
Elevation can spin 360	No
Minimum elevation angle	-2.00 deg
Maximum elevation angle	108.00 deg
Maximum azimuth velocity	40.00 deg/sec
Maximum elevation velocity	40.00 deg/sec
Initial mode for Azimuth axis	Velocity
Initial Azimuth velocity	0.00 deg/sec
Initial mode for Elevation axis	Velocity
Initial Elevation velocity	0.00 deg/sec

Figure 42 RCP Antenna Configuration Parameters - Vaisala Example

Elevation can spin 360

Set this to **Yes** to remove the need for the following 2 questions.

Minimum/Maximum elevation

The minimum and maximum elevation position in degrees that the antenna can safely reach.

Maximum azimuth/elevation velocity

The maximum velocity in degrees per second that the antenna can safely rotate on each axis. This limit applies to both clockwise/counterclockwise and up/down motion. The antenna should be able to achieve the velocity limits set here.

Initial mode for Azimuth/Elevation axis

This parameter sets the mode of the antenna when IRIS is first started. Select one of the following values:

- **Stop**
The antenna is not moving when IRIS is started. This should be the antenna's initial mode at sites where there is a possible hazard to personnel.
- **Position**
The antenna is moved to its initial position when IRIS is started.
- **Velocity**
The antenna is rotated at its initial velocity when IRIS is started.

If the initial mode for Azimuth/Elevation axis is not set to **Stopped**, the following options are shown:

Initial Azimuth/Elevation position

Enter the position in degrees that the antenna should take when IRIS is started. Used when the initial mode is set to **position**.

Initial Azimuth/Elevation velocity

Enter the degrees/second that the antenna should rotate when IRIS is started. Used when the initial mode is set to **velocity**.

11.5.6 Timing Features

Timing Features		Help
Radiate toggle period	<input type="text" value="1.00 sec"/>	
Stop radiate toggle after	<input type="text" value="5 min"/>	
Noise toggle period	<input type="text" value="0.00 sec"/>	
Signal generator minimum value	<input type="text" value="107 dBm"/>	
Signal generator maximum value	<input type="text" value="20 dBm"/>	
Signal generator warmup time	<input type="text" value="60.0 sec"/>	
Signal generator settle time	<input type="text" value="1.0 sec"/>	
Initial signal generator level	<input type="text" value="0 dBm"/>	

Figure 43 RCP Timing Configuration Parameters

Radiate toggle period

IRIS automatically toggles the radiate control off for this time, then on again, once per task if the following conditions are met:

- IRIS can control the radiation.
 - IRIS can sense the radiation state.
 - IRIS is requesting the radiation to be on, but it is actually off.
 - Radiate has been requested on more that the **Warmup time for transmitter** set in the ingest setups.
 - Less than the **Stop radiate toggle after** time has passed since the transmitter was not following the request.
- Setting either parameter to 0 disables toggling. The recommended values are 1 second and 5 minutes.

Stop radiate toggle after

IRIS stops toggling radiate on and off after this time. That is, if radiate doesn't go on after a certain time, it stops trying to turn it on.

Noise toggle period

When the **INGEST** process or the **Ascope** utility take noise samples, the signal generator bit in the antenna controller is set for this amount of time after IRIS is through with its noise tasks.

This value is used by Gematronik radars for calibration purposes.

Set this parameter to 0 if you do not need this feature.

Signal generator minimum /maximum value

The lowest and highest power output of the signal generator in dBm.

Signal generator warmup time

Time allowed after the signal generator is turned on before the signal level is assumed to be correct.

Signal generator settle time

Time allowed after the signal level is set before the received power is measured. A value of 1 second is recommended.

Initial signal generator value

Enter the signal generator level to use when IRIS is started.

11.5.7 Control Bit Definitions

Control Bit Definitions Help

Pulse Width Control	<input type="checkbox"/> Enabled
Don't Overwrite Pulse Width	<input type="checkbox"/> Enabled
Polarization Control	<input type="checkbox"/> Enabled
Servo Power Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially On
Transmit Radiate Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially On
T/R Power Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially On
Signal Generator Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially On
Siggen Cont.Wave Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially On
Master Reset Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially Off
Noise Generator Control	<input type="checkbox"/> Enabled
	<input type="checkbox"/> Active HIGH
	<input type="checkbox"/> Initially Off

Figure 44 RCP Control Bit Configuration Parameters

Pulse Width Control

Select either **Disabled** or **Enabled**. On driver powerup, the pulse width is not set until it is also set in the signal processor.

Don't Overwrite Pulse Width**Polarization Control**

Select either **Disabled** or **Enabled**. On driver powerup, the polarization is not set until it is also set in the signal processor.

Servo Power Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can control the servo power. ²⁾

Transmit Radiate Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can control the transmitter radiation. ²⁾

T/R Power Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can control the power to the transmitter and receiver rack. ²⁾

Signal Generator Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can control a signal generator for calibration purposes. ²⁾

Siggen Cont. Wave Control

Choose either **Disabled** or **Enabled** to indicate whether the signal generator can be switched between Continuous Wave (CW) and pulse mode. ²⁾

Master Reset Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can be reset. ²⁾

Noise Generator Control

Choose either **Disabled** or **Enabled** to indicate whether the antenna controller can control a noise source for receiver testing and calibration purposes. ²⁾

2) If enabled is selected, an option for **Active HIGH** or **Active LOW** appears as well as an option for **Initially Off** or **Initially On**.

11.5.8 Status Bit Definitions

Status Bit Definitions		Help
Pulse Width Status	<input type="checkbox"/> Enabled	
Polarization Status	<input type="checkbox"/> Enabled	
Servo Power Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Transmit Radiate Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
T/R Power Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Signal Generator Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Siggen Cont.Wave Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> ON: HIGH	
Siggen Fault Status	<input type="checkbox"/> Disabled	
RCP Shutdown Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: HIGH	
	<input type="checkbox"/> Type: Normal	
Low Airflow Status	<input type="checkbox"/> Disabled	
Low Waveguide Pressure Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: LOW	
	<input type="checkbox"/> Type: Normal	
Antenna Local Mode Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Local: HIGH	
T/R Local Mode Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Local: HIGH	
Safety Interlock Status	<input type="checkbox"/> Disabled	
Standby Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Standby: HIGH	
Magnetron Current Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Fault: LOW	
	<input type="checkbox"/> Type: Normal	
Azimuth Encoder Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Cal: HIGH	
Elevation Encoder Status	<input type="checkbox"/> Enabled	
	<input type="checkbox"/> Cal: HIGH	

Figure 45 RCP Status Bit Configuration Parameters

Pulse Width Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect the pulse width.

Polarization Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect the polarization.

Servo Power Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the servo power is turned on.

If enabled is selected, an option for **ON: HIGH** or **ON: LOW** appears.

Transmit Radiate Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the transmitter is trying to radiate.

If enabled is selected, an option for **ON: HIGH** or **ON: LOW** appears.

T/R Power Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the power is turned on to the transmitter/receiver rack.

If enabled is selected, an option for **ON: HIGH** or **ON: LOW** appears.

Signal Generator Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect whether the signal generator is turned on.

If enabled is selected, an option for **ON: HIGH** or **ON: LOW** appears.

Siggen Cont. Wave Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect when the signal generator is in continuous wave or pulse mode.

If enabled is selected, an option for **ON: HIGH** or **ON: LOW** appears.

Siggen Fault Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the signal generator is in fault state.

If **Enabled** is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

RCP Shutdown Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the RCP is turned on.

If enabled is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

Low Airflow Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the airflow is low.

If enabled is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

You also can select whether the fault is treated as a normal or critical fault. Normal faults are marked with yellow, while critical faults are marked with red, and can cause mode switching and window alerts.

Low Waveguide Pressure Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the waveguide pressure is low.

If enabled is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

The fault type is also specified.

Antenna Local Mode Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if it is in local mode.

If enabled is selected, an option for **Local: HIGH** or **Local: LOW** appears.

T/R Local Mode Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the transmitter/receiver is in local mode.

If enabled is selected, an option for **Local: HIGH** or **Local: LOW** appears.

Safety Interlock Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the safety interlock is open.

If enabled is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

The fault type is also specified.

Standby Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect if the transmitter is in the standby mode.

If enabled is selected, an option for **Standby: HIGH** or **Standby: LOW** appears.

Magnetron Current Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the magnetron current is incorrect.

If enabled is selected, an option for **Fault: HIGH** or **Fault: LOW** appears.

The fault type is also specified.

Azimuth Encoder Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the azimuth encoder calibration is correct.

If enabled is selected, an option for **Cal: HIGH** or **Cal: LOW** appears.

Elevation Encoder Status

Select **Enabled** or **Disabled** to indicate whether the antenna controller can detect that the elevation calibration is correct.

If enabled is selected, an option for **Cal: HIGH** or **Cal: LOW** appears.

11.5.9 Network Status Reports

Network Status Reports to the RCP	
Reporting	<input type="checkbox"/> Enabled
Status fault polarity	<input type="checkbox"/> Active HIGH
Initial state of sites	<input type="checkbox"/> All Okay
Radar Workstation 'A' site code	<input type="text"/>
Radar Workstation 'B' site code	<input type="text"/>
Data Processor 'A' site code	<input type="text"/>
Data Processor 'B' site code	<input type="text"/>

Figure 46 RCP Network Status Configuration Parameters

Reporting

Select **Enabled** or **Disabled**. If enabled, the following options appear:

- **Status fault polarity**
Select either **Active HIGH** or **Active LOW**.
Since the site status bits in the XMT02/04/05 formats are set to 1 when a site is okay, the recommended fault polarity is **Active LOW**.
- **Initial state of sites**
Select the initial fault status of all four sites as either **All Okay** or **All Faulted**.
- **Radar Workstation 'A' site code, ...**
Enter the site codes whose fault status is to be reported to the RCP for each of the possible **Radar Workstation sites** and **Data Processor sites**.

11.5.10 Radar Status Timing Mode Requests

RST Mode to Number Mapping	
Radar Status name for MODE #1	<input type="text"/>
Radar Status name for MODE #2	<input type="text"/>
Radar Status name for MODE #3	<input type="text"/>
Radar Status name for MODE #4	<input type="text"/>
Radar Status name for MODE #5	<input type="text"/>
Radar Status name for MODE #6	<input type="text"/>
Radar Status name for MODE #7	<input type="text"/>
Mode to use when RCP is dead	<input type="text" value="0"/>
Mode reporting delay	<input type="text" value="1.0 sec"/>

Figure 47 RCP RST Mode Request Configuration Parameters

Use these questions to define up to 7 modes. Each mode has a number and a name, corresponding to a **Radar Status** menu configuration.

When the configuration is changed in the **Radar Status** menu, the mode is reported back to the RCP. Unrecognized configurations are reported as mode 0.

RCP can also send this mode to the **Radar Status** menu to change the configuration. A request for mode 0 denotes automatic switch mode, which automatically switches configurations based on warning products.

Radar Status name for MODE (1 to 7)

For each 3-bit nonzero mode value, enter the name of an IRIS configuration that is to be activated when that mode is requested.

Mode to use when RCP is dead

This mode is automatically requested by the IRIS antenna driver if it detects that the RCP is dead, that is, that the genuine desired mode cannot be determined.

This is valuable in dual/redundant systems that must switch to a known state when certain errors occur. Setting the mode to 0 does not cause a mode change to occur for a dead RCP.

Mode reporting delay

To make sure that the RCP mode is never ahead or behind the IRIS task scheduler mode, IRIS stops the old task, waits the set delay time, reports the new mode to the RCP, waits again for the delay, loads the new task schedule, and runs it.

If your system does not use the RCP mode report, then the default setting is 0. Note that if the RST menu switches modes, both modes have the same task schedule, the tasks are not stopped and no delay is applied. The same is true for the product schedule.

11.6 IRIS Input Setups

IRIS allows you to configure up to 16 input devices. Each input is a separate process watching a special directory looking for files to arrive. When a file arrives, the process invokes a conversion program, and adds the resulting data to the IRIS product inventory.



The netCDF and HDF5 input pipes require 16-bit data.

The screenshot shows the 'Input Device Specifications' window. At the top, there is a 'Help' button. Below it, the 'Number of input devices' is set to 1. The main section is titled 'Input Device #1' and also has a 'Help' button. It contains several configuration fields: 'Menu alias' is set to 'input'; 'Pipe program name' is empty; 'Source directory' is set to '/usr/iris_data/input/'; 'Command line syntax' is set to 'Pipe' (indicated by a dropdown arrow); and 'Notification scheme' is set to 'Polling' (also indicated by a dropdown arrow).

Number of input devices

Enter the number of inputs you wish to configure for your system. The maximum number supported is 16.

Menu alias

Enter a name for this input.

Pipe program name

Enter the name of a conversion program run when a file arrives.

IRIS checks for this program in the `${IRIS_PIPES}` directory.

If you enter a blank name here, then it is assumed files are in IRIS product format, and are directly inserted into the inventory after byte swapping.

Source directory

Enter the directory to monitor for files.

Each input channel must have a separate directory. At startup, all files found in the directory are deleted. The input process then checks every few seconds for files. If it finds a file with the same size as last time, it runs the pipe conversion program and deletes the file.

All files starting with a "." are ignored. If you are copying between computers you should use "rename notification". In that scheme, the file is first copied to a temporary filename starting with a ".". After the slow copy is completed, the file is renamed to the final name. This prevents the input from reading a partial file. If the filename ends with `.gz` then gunzip is applied before processing. If the file name with `.Z`, uncompress is applied.

The following table shows the input pipes supplied with the IRIS system. You may also choose to write your own. For more information, see the **Antenna** utility section of *IRIS Programming Guide*.

Table 25 Supported IRIS Input Pipes

Name	Syntax	Purpose
BMPSatToIris	Pipe	Converts satellite image to IRIS USER product.
BufrToIris	Pathnames	Converts WMO BUFR format to IRIS cartesian products using OPERA guidelines
HDF5ToIris	Pathnames	Converts NORAD HDF5 file to an IRIS product. The pipe is no longer officially supported.
IMDSatToIris	Pathnames	Converts India Meteorological Department(IMD) satellite data from HDF5 format to an IRIS product. The pipe is no longer officially supported.
hdf52iris	Pathnames	Converts OPERA HDF5 file to an IRIS RAW product.
HDFSatToIris	Pathnames	Converts HDF4 satellite image to an IRIS USER product.
KmaRadToIris	Pipe	Converts an array to an IRIS CAPPI product.
KmaSatToIris	Pipe	Converts satellite image to IRIS USER product.
KnmiHDF5ToIris	Pathnames	
PBMSatToIris	Pathnames	Converts a PBM , PGM , or PPM satellite image to an IRIS USER product.
PictureToIris	Pathnames	Converts, for example, TIFF files to IRIS IMAGE product.

Name	Syntax	Purpose
RainbowToIris	Pathnames	Converts Gematronik Rainbow format to an RAW product. The pipe is no longer officially supported.
UfToIris	Pathnames	Converts UF format to IRIS RAW product.

Command line syntax

Use one of the following options to determine how IRIS runs the pipe program:

- Pipe:

```
pipe-pathname input-filename <input-pathname >outputpathname
```

- Pathnames:

```
pipe-pathname ip:input-pathname if:input-filename op:output-pathname
```

Notification scheme

Use one of the following options to determine how IRIS detects that a new file has arrived:

- Polling:
IRIS checks every few seconds to see if a new file has arrived. If the file size is the same as last time it checked, then the file is processed.
- TCP/IP Socket:
IRIS expects to receive a socket message on the specified port number every time a file arrives. This allows immediate input without the delays due to a polling period.
The socket message syntax is the same as for a normal IRIS network receiver, that is **FILE** followed by the filename and a null.

11.7 IRIS General Setups

11.7.1 Modes and Protocols




Figure 48 IRIS Modes and Protocols

Timezone for data recording

Controls if the task schedule and the product schedule run on UTC or on local time as well as the times shown in the menus and in the file names.

In both cases, you should set your computers system clock to the correct local time zone.

In both cases, IRIS records all the information needed to display the data using either UTC or local time.

If set to **Local Time**, you must use a local time zone that does not switch to and from summer time.

If set to **UTC**, it is OK to have the summer time switch.

Operating system's time

Select **Select from RCP** to indicate whether the INGEST process should set the system time from the RCP serial line time reports if the time difference is 2 ... 20 seconds. For higher values, it signals a message.

If your RCP does not report the time, select **Unaffected by IRIS**.

Memory mapped I/O

Select either **Available in OS** for most systems or **unsupported** for HP9000/800, which does not support a memory mapped I/O file.

External RCP mode change

Answer **enabled** if you want to allow the RCP to control the IRIS configuration that is loaded into the Radar Status menu. This is only available on radar systems, set to **disabled** on analysis systems. If enabled, then the **External socket mode change** feature below is not available, and the automatic mode switch button on the **Radar Status** menu is not manually controlled.

External socket mode change

Answer **enabled** if you want to allow socket messages to control the IRIS configuration that is loaded into the Radar Status menu. If enabled the automatic mode switch button on the Radar Status menu is not manually controlled.

Status product mode change

Answer **enabled** if you want to slave your system's mode to another IRIS system. When a status product arrives from the selected system, your IRIS changes to match the mode. This is used for redundant system switching. If enabled, you see:

- **Supplied by (Site Code)**

Enter the site you wish to slave to.

Response to fatal errors

Select **Restart Processes** or **No Action** to indicate whether you want IRIS processes to restart automatically after a fatal error occurs.

Maximum number of IRIS Clients

Enter the maximum number of IRIS client menu programs that can be connected to the IRIS server at one time. A suggested value for this is 10.

IRIS takes about 30 seconds to free a client slot upon disconnection, so this parameter should be set slightly larger than the actual maximum number you want.

The menus display the message **IRIS is not running on the selected node** if the client table is full.

11.7.2 Speech and Signaling

Speech and Signaling	
Signal network warnings <	<input type="text" value="600 seconds old"/>
Speak/Beep text products	<input type="button" value="No"/>
Speak/Beep mode changes	<input type="button" value="No"/>
Speak/Beep fatal errors	<input type="button" value="No"/>
Speak/Beep BITE faults	<input type="button" value="Yes"/>

Signal network warnings less than

When a product that contains a warning is received over the network, a signal and beep is produced if the data time is within the following number of seconds of the current time.

Zero means do not signal at all. The default setting is 600 seconds old.

IRIS can be configured to generate spoken output for important messages. Warning instances are configured in the **PRODUCT** configuration menu.

You configure other possible speech options.

The **sigaudio** program can configure if you use spoken text, or play a waveform file.

Any of the options can be turned off by selecting **No**.

This setup can be overridden by the newer message configuration file.

Speak/Beep text products on arrival

IRIS has a special product type called "Text products". These products consist of an IRIS header plus an ASCII string.

This causes the string message to be spoken when it arrives on a system.

Speak/Beep mode changes

Audio alert when a mode change is made.

Speak/Beep fatal errors

Audio alert when an IRIS product crashes. This can happen with a program error such as divide by 0, or with the **kill** command.

Speak/Beep BITE faults

Audio alert when a critical BITE fault is signaled.

11.7.3 File and System Quotas

File and System Quotas		Help
Total space for INGEST files	1000.0 megabytes	
Kept INGEST file space	50% of total	
Total space for RAW products	500.0 megabytes	
Kept RAW-Product file space	60% of total	
Total space for Other-Products	1000.0 megabytes	
Kept Other-Product file space	60% of total	
Maximum Products on Disk	60000	
Maximum Product Configurations	1000	
Maximum Products on Archive	100000	
Maximum number of output devices	24	

Total space for INGEST files

When the **INGEST** data exceeds this level, old data is automatically deleted.

It is important to keep at least 10 % of the disk free when the **INGEST**, **RAW**, and other product files have reached their maximum usage.

To estimate the available space for these files, delete all the files, then find out how much disk space is available by typing **df**.

Take the free size minus 10 % of the full size and divide by 2000 to convert blocks to megabytes.

Kept INGEST file space

Enter the percentage of the total disk space that can be used for kept ingest files (files that cannot be deleted by the Watchdog process). When the kept files exceeds this quota, the oldest are deleted first.

A reasonable value is 50 %.

Total Space for RAW Products

When file space used by RAW product data exceeds this level, old data are automatically deleted.

Kept RAW-Product File Space

Enter the percentage of the total disk space that can be used for kept raw product files. When the kept files exceeds this quota, the oldest are deleted first.

A reasonable value is 50 %.

Total space for Other-Products

When the file space used by non-RAW product data exceeds this level, old data are automatically deleted.

Kept Other-Product file space

Enter the percentage of the total that can be used for kept product files. If the kept files exceed this quota, the oldest are deleted first.

A reasonable value is 50 %.

Maximum products on Disk

This is the maximum number of products which allowed on the disk at one time. It is used to allocate memory for the inventory.

A typical value is 10000.

Maximum products on Archive

This is the maximum number of products allowed on an archive media. Configure this dependent on your media capacity.


A value like 20000 would be a good starting point.

Maximum number of output devices


Enter the maximum number of output devices that can be entered in the field (see [Output Device General Specifications \(page 217\)](#)).

The larger the value, the longer it takes for IRIS to startup. For example, if you have up to 10 output devices, IRIS starts very quickly at startup time. If 200 output devices are required, IRIS takes longer to startup.

If the number of configured devices is exceeded, you receive an error message:



11.7.4 Run-Time Priorities



The 'Run-Time Priorities' dialog box contains a list of processes with their respective priority values. Each entry has a small icon to its left and a text field to its right. The values are: INGEST process priority (-8), INGFIG process priority (-8), INPUT process priority (0), PRODUCT process priority (-8), REINGEST process priority (-8), NETWORK process priority (-4), OUTPUT process priority (-4), ARCHIVE process priority (-4), SERVER process priority (0), and WATCHDOG process priority (0).

Process	Priority
INGEST process priority	-8
INGFIG process priority	-8
INPUT process priority	0
PRODUCT process priority	-8
REINGEST process priority	-8
NETWORK process priority	-4
OUTPUT process priority	-4
ARCHIVE process priority	-4
SERVER process priority	0
WATCHDOG process priority	0


Set the priority of each IRIS process.

This is called the *nice priority* on UNIX systems.

Almost all the normal processes run at *nice priority* 0. Valid numbers are in the range -20 ... +20. The smaller the number, the higher the priority, suggested values are shown.

The **ps** command shows these numbers with 20 added to them.

11.7.5 Window Alert Configuration



The 'Window Alert Configuration' dialog box has four settings: 'Multi-site fault rule' set to 'FAULT on one', 'Alert Style' set to 'Red X and Text', 'Display alert for site faults' set to 'No', and 'Display alert for stale image' set to 'No'.

Multi-site fault rule	FAULT on one
Alert Style	Red X and Text
Display alert for site faults	No
Display alert for stale image	No

Window alerts display important fault information by showing a large, **X** on top of the display, possibly with a text message indicating the reason for the fault. These faults indicate that the displayed data is suspect.

Multi-site fault rule

Controls the widow alert, and the summary shown on the **RST** menu.

You can display a fault if either any one system has failed, or require that all systems fail. The list of sites to consider is selected below in the site name section.

Alert Style

Select one of the following: **Disabled**, **Red X and Text**, **Red X Only**, and **Text Only**.

Select **Disabled** to turn off the feature and the remaining questions.

Display alert for site faults


Enable alerts based on the site fault summary shown on the **RST** menu. Note that an alert is shown for timeout and critical faults only. Normal faults do not alert.

Display alert for stale image

Enable an alert when the image displayed on the screen is not current.

In auto-update mode, this prevents operators from seeing an old image for many hours without realizing it.

11.7.6 Radar Site Names and Site Codes



Site #	name	Code	Check for Fault
Site #0 (Unknown) code	XXX		<input type="checkbox"/> No
Site #1 name	SIGMET, iris-rel	REL	<input type="checkbox"/> No
Site #2 name	wes-porter	WPT	<input type="checkbox"/> No



These values are case-sensitive.

Unrecognized site code

The recommended value for the unrecognized site code is "XXX". This is used for all data that does not match anything else in the table.

Check for Fault

Only sites marked are included in the **RST** summary and window alerts. This allows you to exclude unimportant display systems.

Site #(1 to 127) name

Site # name must exactly match the license **Site Name**. The **Site Name** is stored in the ingest, product and product raw files.

You can define up to 128 sites defined, the unrecognized site, plus 127 others.

Code

The 3-character **Code** is used throughout the **IRIS Menu** for referencing to the **Site Name**. The codes appear in the **Ingest Summary**, **Product Summary** and **Product Output** Menus. IRIS prepends ingest, product and product raw files with the 3-character **Code**.

If the typed code is less than 3 characters, then "_" will fill the missing characters.



To remove a site, enter "" for the site name and code.

11.8 License and Site Information Setups



Licenses are machine-dependent. To get your license, call Vaisala with your machine code. To display the machine code, in the operating system prompt, type `show_machine_code`.

If the machine code changes due to a change in the site name or if you install a new version of the operating system, you must request a new license.

1. In the **Setup** utility, select **License**.
The **License and Site Information** window opens.




Figure 49 License Setup Example

2. Check or update the license and site information.

License #1 to #6

Type the software licenses you received from Vaisala, including operational and backup licenses and IRIS.

Also, if you are testing new features using a temporary license from Vaisala, IRIS automatically grants the cumulative features based on all of the licenses. When the temporary license expires, IRIS defaults to the original operational license.

The license file you receive from Vaisala includes a **Features** and a **Products** license, and possibly an **RDA** license. These licenses can go in any of the 6 license fields, but Vaisala recommends using the first 2 fields for organizational purposes. These licenses consist of a 32-character string plus a user comment or description:

```
XXXXXXXX-XXXXXX-XXXXXX-XX-XXXXXX comment
```

IRIS Style

Select a style to configure the menu selections and remove unneeded fields:

- **Radar**
Full IRIS/Radar system.
- **Analysis**
IRIS/Analysis systems.

Site name

Type a site name using up to 16 characters.

The **Site name** is saved with the data and used in displays and printouts.



You must choose the site name carefully.
If the site name changes, you must request a new license from Vaisala.

Hardware name

Normally this is the same as the **Site name**.

In a dual computer system in which 2 computers have the same IRIS site name, **Hardware name** indicates which computer is running.

When making status products, **Hardware name** is used as the site name.

Site code

Type the site code for this site.

QLW

Type a password of up to 15 characters.

Quick Look Window users must provide this password to access operator features.

11.9 IRIS Ingest Setups

11.9.1 Data Source Selection

Data Source Selection	
INGEST data source	Simulated
Simulator virtual time offset	0.0 minutes
Simulate a large-scale windfield	Yes
Nominal wind from the West	5.0 m/sec
Nominal wind from the South	1.0 m/sec
Vertical wind maximum speed	0.00 m/sec
Vertical wind cyclic height	5.0 km
Wind field deformation	0.0 m/sec/100km
Simulate a shearline	Yes
Simulate particle fallspeeds	No
Empirical smearing of polarimetry	No
Simulation center location	At the radar
Clutter density factor	40.0 %

Define the data source by selecting:

From DSP

For normal radar operation select **From DSP**.

Simulated

For simulated data, IRIS supports simulation of a data field of winds and storm cells which move about the radar.

You can use the options shown in the previous image to configure options for testing compositing, the location and time offsets of the simulated data.

11.9.2 Signal Processing and Data Storage

Signal Processing and Data Storage Help

Data truncation height: 30.000 km

Type of angle syncing: None

Source of recorded angles: RVP Tags

Source of recorded time: IRIS Host

DSP parameter computations: R2 algorithms

Extended header format: Not Recorded

Data truncation height

Any data calculated to be above this height are removed to save disk space. This is typically set to 20 km (12.4 mi). This is height above the radar dish. This truncation is not applied to manual scans.

Type of angle syncing

Select the method of angle syncing as **Static**, **None**, or **Dynamic**.

Source of recorded angles

Enter one of the following values:

- **RVP Tags**
Angle information supplied by the RVP.
- **IRIS Host**
Angles are taken directly from the antenna interface software. This choice is used for simulations where the signal processor does not have angle information. It is not recommended for operational systems.

Source of recorded time

Enter one of the following values:

- **RVP Tags**
Time for each CPI is logged on RVP8. This feature is only available on RVP8 systems. Active Ingest task scheduling is still based on the IRIS host computer, so such systems should be time synched.
- **IRIS Host**
Time for each CPI is taken directly from the IRIS host computer. Because of buffering, data arrives and is time tagged in groups of 2 or 3 CPIs.

DSP parameter computations

Choose either **R2 algorithms** or **R1 algorithms**.

Use the R2 processing algorithms to estimate SNR and spectral width.

You must set the RVP TTY Setup **R2 processing** question to **user** for this selection to take effect.

Extended header format

Enter one of the following values:

- **Not recorded**
Doesn't record extended ray headers.
- **V0**
Records time and calculations
- **V1**
Records time and navigation.

Vaisala recommends not recording extended ray headers if they are not required.

11.9.3 Scanning Options

Scanning Options		Help
Reset the RCP on INGEST startup	<input type="checkbox"/> No	
Task Scheduling Control	Active Only <input type="checkbox"/>	
RHI elevation speedup ratio	<input type="text" value="10.00"/>	
Permissible AZ error during scans	<input type="text" value="0.30 degrees"/>	
Permissible EL error during scans	<input type="text" value="0.30 degrees"/>	
AZ maximum speed at end positions	<input type="text" value="0.50 deg/sec"/>	
EL maximum speed at end positions	<input type="text" value="0.50 deg/sec"/>	
AZ speed tolerance	<input type="text" value="2.00 deg/sec"/>	
EL speed tolerance	<input type="text" value="2.00 deg/sec"/>	
AZ minimum expected moving speed	<input type="text" value="0.20 deg/sec"/>	
EL minimum expected moving speed	<input type="text" value="0.20 deg/sec"/>	
AZ settling time between sweeps	<input type="text" value="1.00 seconds"/>	
EL settling time between sweeps	<input type="text" value="1.00 seconds"/>	
Direction of continuous scans	Clockwise <input type="checkbox"/>	
Coasting time between tasks	<input type="text" value="60 seconds max"/>	
Optimize for continuous output	<input type="checkbox"/> No	

Reset the RCP on Ingest Startup

Causes an **Error Reset** command to be sent to the RCP when the **INGEST** process starts. The reasons that you might want to do this are:

- In dual/redundant systems, the reset clears any error conditions that may accumulate while the RCP was inactive. These generally are not real faults, and it is safe to clear them automatically.
- In single radar systems the reset helps to insure that the RCP is ready to respond to ingest's commands.
- With the reset enabled, you can then clear RCP shutdown conditions easily from the **IRIS Radar Status** menu by toggling the **INGEST** process Off/On.

The main reason not to select the automatic reset is that you may prefer a policy in which RCP shutdowns are always manually handled by an operator, after first determining that the original cause of the failure has been repaired.

Task Scheduling Control

Normally set this to **Active Only**.

IRIS supports a **Passive** mode of data collection in which it is slave to other radar control software. In this mode, IRIS monitors the azimuth, elevation, and PRF of the radar and attempts to match it with the tasks in the task schedule, and to record data. See *IRIS Radar User Guide*.

If **Passive Only** or **Active/Passive** is selected then the **Passive Type** is specified.

Passive Type

The choices are:

- **Multi-Tasking**
Used for PPI Full scanning when the system controlling the antenna does one or more volume scans. In this case there can be more than one task in the task schedule.
- **Single Tasking**
Used for any scan mode (Sector, RHI, PPI Full, Manual). In this case there may only be one task in the task schedule.
- **Status Slaving**
Can be used for any scan mode (Sector, RHI, PPI Full, Manual) and there can be multiple tasks in the schedule.
The controlling computer must send a **STATUS** product to IRIS to signal which task is about to start. In this case, there is an additional question to provide the **Slaved to Site Code** (three letter site code of the site sending the **STATUS** products).
- **TS Playback**
This can be used for any scan mode (Sector, RHI, PPI Full, Manual) and there can be multiple tasks in the schedule. Use with **tsarchive** to play back recorded data.
The task is selected based on the name recorded with the data.

RHI elevation speedup ratio

During RHI scans, the antenna velocity is increased at higher elevations in order to save time. This parameter controls how much faster the antenna goes at 90° elevation compared to 0°. This is typically set to 10.

Permissible AZ/EL error during scans

The IRIS system insists that the antenna get to within this angular distance of any desired position before proceeding. The tolerances are in degrees, and are typically set to about 0.5°.

AZ/EL maximum speed at end positions

These speed limits work in together with the above position limits.

When the antenna is positioned within the angle tolerance, it must also be moving at a speed less than these maximums. This prevents falsely proceeding in the case of an underdamped antenna which moves quickly through its settling position several times before coming to a stop. The speed limits also help to remove the initial elevation "starting trail" during continuous PPI scans.

Vaisala recommends the setting of 0.5°/s.

AZ speed tolerance

At the start of each sweep, IRIS waits until the antenna speed is within the value of the requested speed. This prevents the sweep from starting while the antenna may be still moving too fast.

EL speed tolerance

Same as above for RHI Full sweeps.

AZ/EL Min expected moving speed

When IRIS is positioning the antenna using the above angle and speed criteria, it is possible that success is never attained. This can happen if the antenna gets stuck before reaching the destination, or if it oscillates endlessly around that point.

During any repositioning operation, IRIS first calculates a maximum time to wait based on the angular distance to be traveled and the minimum moving speed given here.

Five seconds are added to compensate for edge effects.

IRIS proceeds after this time limit expires, regardless of what the antenna is doing.

This prevents endless waits resulting from antenna defects.

Typical values are 1.0 to 5.0°/s. A value of 0 results in a fixed 5-second maximum wait.

AZ/EL min settling time between sweeps

These minimum times allow IRIS to work better when the step between tilts is very small. In addition to the above criteria for determining that the antenna is close to a desired position, IRIS waits these minimum times.

Direction of continuous scans

You can specify whether continuous PPI scans go **clockwise** or **counterclockwise**.

To equalize the wear on the gears, Vaisala recommends that you change this every few months.

Coasting time between tasks

If the number of seconds between 2 continuous scan PPI tasks is less than this number, IRIS does not stop the antenna between the tasks. This can prevent wear on the antenna.

Set this value to 0 to always stop between tasks.

Optimize for continuous output

If set to **Yes**, the following changes are made compared to the legacy behavior:

- Leave the DSP in continuous output mode between tasks.
- If the same task is running continuously, skip reading the **gparm** data at the start of the task. This means it would not detect faults like burst pulse missing.
- Do not set the sweep number value between sweeps.

Set the value to **No** unless you want continuous real-time displays.

For continuous displays, disable the noise sample in ingest.

When set to **Yes**, you should see only about 1 ray missing between tasks at 3 rpm 1° resolution. Consider using instead the real-time data sent directly from RVP.

11.9.4 DSP Noise Sampling

Perform noise sampling

Use this flag to disable automatic noise sampling done by IRIS. This is appropriate for passive ingest. It can save scan time, and avoid contaminated samples.

Modern IF receivers do not have a noise level drifting problem. When disabled, noise samples are taken from the values stored inside the RVP, be sure to type in and save the powerup noise levels for each pulse width. Operational noise levels are not taken from the value found on the last zauto calibration.

Time between noise samples

When a task starts, if it has been at least this long since the last noise sample, a new sample is taken. This is typically set to 10 minutes.

Azimuth/Elevation during noise sample

Select either **Don't care** or **Minimum Angle**.

If you select **Minimum Angle**, an entry box appears where you can specify the azimuth in degrees at which to take the noise sample.

Take sample whenever PW changes

If the signal processor cannot store separate noise levels for each pulse width, then you must select **Yes**.

Retry bad noise samples and Noise retry wait

Use these questions to configure the noise sample interference detection.

Ingest attempts to detect the case in which during the noise sample you get interference from another pulsed radar. This interference causes a higher noise sample, and cause uncalibrated data, similar to hitting the sun at noise sample time. Each time Ingest detects interference it sends the message *Interference in noise calculations*.

Ingest then waits the retry wait time (typically 1 second) and tries again. This is repeated up to the specified number of times.

The assumption is that the other radar is a scanning radar, so if you wait 1 second, it should no longer be pointed at you. After the last attempt, if it still detects interference, it still runs the scan. If you are getting false positives, you still get the correct data.

11.9.5 Transmitter Control

Transmitter Control		Help
Idle time to shut off transmitter	<input type="text" value="300 seconds"/>	
Warmup time for transmitter	<input type="text" value="10 seconds"/>	
Pulsewidth and PRF are set	<input checked="" type="checkbox"/> at task start	

Idle time to shut off transmitter

If no task is scheduled to run for this number of seconds, then the transmitter is switched to standby to extend its lifetime (only in radiate automatic mode).

Warm-up time for transmitter

Each time an IRIS task starts, we wait this long since the radiate was turned on. This allows time for a slow on circuit, and also time for the RVP to detect the burst pulse power.

Many systems pulse with and polarization changes require radiate to be turned off. In such cases this warmup time is triggered. If radiate is set to automatic and the transmitter is off, it is turned on this many seconds before the task starts. Be sure to set this less than the idle time above.

Pulsewidth and PRF are set

Ingest can set the pulsewidth and PRF. This allows the transients to settle if there is time between scans.

11.9.6 Clutter Suppression

Z: Clutter Suppression via Clutter Map Help

Excess power needed for valid dBZ	<input type="text" value="10.0 dB"/>
Elevation tolerance for matchup	<input type="text" value="1.00 degrees"/>
Non-zero velocity criterion	<input checked="" type="checkbox"/> Check Velocity
Clutter map in ReINGEST	<input checked="" type="checkbox"/> Enabled

Excess power needed for valid dBZ

This configures IRIS ingest clutter map. If the **Task Configuration Menu** clutter map button is pressed, IRIS looks for a ingest file marked as the residual clutter map. All range bins containing data in the clutter map file are thresholded unless the current data is at least this much higher. If we exceed the threshold, the dBZ value is passed unchanged.

Elevation tolerance for matchup

When looking for the corresponding range bin in the clutter map file, the nearest elevation angle is used up to this maximum difference. If none is found, then no correction is applied.

Non-zero velocity criterion

If this is set to **Check Velocity** then data which would pass the excess power test is thresholded if the velocity is near 0.

Clutter map in ReINGEST

If this is set to **Enabled**, the `Clutter_map` filter is applied to the data in reingest. The filter is only applied if no other clutter map filter has been used. The ingest file from that radar site must have the same task name and be marked as the clutter map.

11.9.7 Beam Blockage

Zc: Partial beam blockage Correction Help

Beam blockage in ReINGEST	<input checked="" type="checkbox"/> Disabled
---------------------------	--


Beam blockage in Reingest

Enables applying IRIS's partial beam blockage algorithm when data arrives on a system at reingest time.

The beam blockages config file must contain information individually for each radar site to be processed.

See *IRIS Radar User Guide*.

11.9.8 DP Intervening Attenuation




This allows turning on/off the Dual-Polarization attenuation correction.

The DP attenuation is based on the principle that the attenuation is proportional to the PhiDP. Because of noisy PhiDP at low SNR, the details are fairly complicated.

You can fine-tune the configuration in the *dpolat-ten.conf* file.

11.9.9 Z-Based Intervening Attenuation



You can configure the coefficients used for the intervening attenuation correction.

When enabled, the corrected reflectivity Z_c is computed from Z using the following equation:

$$dBZ_c = dBZ + 2C\Delta r\Sigma Z^E$$

Where C is the constant above, and E is the exponent. All values of Z are clipped at the maximum Z before the calculation, and the total correction is clipped at the maximum cumulative value.


We have default values for C and X band radars. We recommend no correction be used for an S-band radar.

These numbers are used in both the ongest process if turned on in the task configuration menu, and at reingest time when data arrives over the network, if the **Atten correction in Reingest** button is pressed.



DP-Attenuation takes precedence and we do not apply both attenuations to the same data.

11.9.10 Target Detection



This computes Zc with uniform weather removed. Any input signal of more than 2 range bins in a row is smoothed and then only peaks are passed.

The goal is to pick out targets against a weather background.

Only use this for target tracking. This can also be computed at ingest time as configured in the task configuration menu.

11.9.11 Velocity Unfolding



Maximum age of the "UNFOLD" VVP

IRIS can be configured to automatically unfold velocity data, producing a data type called Vc based on a VVP product on the disk which must be called UNFOLD.

This is the maximum time difference between the data and the time of the UNFOLD product.

A 0 value disables the check.

See the NDOP product in *IRIS Product and Display Guide*.

Maximum separation to the VVP

The maximum distance between the radar location of the VVP product and the data being unfolded. It might be necessary to unfold based on a different radar when one radar's data is imported.

Velocity unfolding in ReINGEST

If enabled, V_c using unfolding is computed at reingest time, overriding any previous values.

The recommended setting is **Disabled**, if unfolding is required, specify it in the task configuration.

11.9.12 Velocity Fallspeed Correction

Vc: Velocity Fallspeed Correction Help

Vt-Z Constant above melting level	i	0.80 m/s
Vt-Z Exponent above melting level	i	0.060
Vt-Z Constant below melting level	i	2.70 m/s
Vt-Z Exponent below melting level	i	0.110
Fallspeed correction in ReINGEST	<input type="checkbox"/> Create Vc	

Vt-Z Constant above melting layer

These questions allow you to specify V_t - Z relationship above and below the melting layer, where V_t is the terminal velocity of the precipitation.

We use an exponential equation like: $V_t = Constant Z^{Exponent}$

See the **NDOP** product in *IRIS Product and Display Guide*.

Fallspeed correction in ReINGEST

If enabled, then V_c using fallspeed correction is computed at reingest time, overriding any previous values.

The recommended setting is **Disabled**, if fallspeed correction is required specify it in the task configuration.

Note that if either **Fallspeed correction in ReINGEST** or **Velocity unfolding in ReINGEST** are enabled, V_c is made at reingest time.

11.9.13 Storm Relative Velocity

Vc: Storm Relative Velocity Correction Help

Maximum age of the "STORM" FCAST	i	30.0 minutes
Maximum separation to the FCAST	i	50.0 km
Storm Relative Velocity in ReINGEST	<input type="checkbox"/> Disabled	

Maximum age of the "STORM" FCAST

IRIS can be configured to automatically compute storm relative velocity data, producing a data type called **Vc** based on an **FCAST** product on the disk which must be called **STORM**.

This is the maximum time difference between the data and the time of the **STORM** product. A 0 value disables the check.

Maximum separation to the FCAST

This is the maximum distance between the radar location of the **FCAST** product and the data being processed.

It might be necessary to a different radar when one radar's data is imported.

Storm Relative Velocity in ReINGEST

If enabled, then **Vc** of storm relative velocity is computed at reingest time.

The recommended setting is **Disabled**, if wanted, specify it in the task configuration if possible.

11.9.14 HydroClass



Hydrometeor classification is called **HydroClass** in Vaisala documentation.

When enabled here, IRIS computes **HydroClass** data at reingest time.

HydroClass calculations in RVP are controlled by the **Task Configuration Menu**.

This is a separately licensed feature.

11.9.15 Melting Levels

Month	Melting Level Height (km)
January	1.0
February	1.0
March	1.5
April	2.0
May	2.5
June	3.0
July	3.5
August	3.5
September	3.0
October	2.5
November	1.5
December	1.0

Enter an estimate for the melting level for each month. These are heights above mean sea level.

The monthly values are default values, we assume you are changing these values dynamically while IRIS is running. The melting level is used in several algorithms, such as fall speed correction and **HydroClass**.

These melting levels on an IRIS/Radar system are loaded on the RVP processor, and are also recorded with the **RAW** radar data. This allows downstream product generators to have access to the correct melting level.



If you are not using this feature, and the numbers are set incorrectly, they disable melting levels.

More information

- [Reflectivity Profile and Wind \(page 210\)](#)

11.10 IRIS Product Setups

11.10.1 Product Generation

The screenshot shows a software window titled "Product Generation" with a "Help" button in the top right corner. The window contains a list of configuration parameters on the left and their corresponding values in input fields on the right. The parameters and their values are:

Parameter	Value
Products from partial INGEST scans	<input type="checkbox"/> No
Default Z/R relationship constant	200.00
Default Z/R relationship exponent	1.60
Product arrival wait time	6.0 minutes
Raingage data arrival wait time	6.0 minutes
Signal if busy more than	0.0 minutes
Dual polarization features	<input checked="" type="checkbox"/> Enabled
Read cache size	0.0 megabytes
Zero reference height	0 meters

Products from partial INGEST scans

Select **yes** or **no** to indicate whether products can be made from partial **INGEST** volume scans.

Default Z/R relationship constant/exponent

The system uses the following equation to express the relationship between reflectivity and rainfall rate:

$$Z = aR^b$$

Z

The linear reflectivity

R

The rainfall rate in mm/hr

a

Relationship constant, empirically determined for each site.

b

Relationship exponent, empirically determined for each site.

IRIS usually solves for **R** to convert the radar's reflectivity data to rainfall rate, as follows:

$$R = \left(\frac{Z}{a}\right)^{\frac{1}{b}}$$

Typical values for rain are **a** = 200 and **b** = 1.6. Using these values, suppose reflectivity is measured at 20 dBZ. To solve for **R**, IRIS first converts dBZ to **Z**:

$$20dBZ = 10\log_{10}Z \therefore Z = 100$$

Then solve for **R**:

$$R = \left(\frac{100}{200}\right)^{.63} = .65mm/hr$$

An increase in dBZ, from 20 to 50 for example, creates an increase in rainfall rate:

The values you enter for the constant and exponent depend on the climate at the radar site and experience gathered through use of the IRIS system.

Product arrival wait time

Scheduling timeout for products that require several inputs, but which can run when some are missing.

Products which use this are: **COMP**, **NDOP** (with 3 inputs), and **RAIN1**.

For example, if a composite product requires 3 radar site inputs within 5 minutes. It gets 2 of those inputs, then the 5 minute interval expires. If the **Product arrival wait time** is set to 1 minute, then it waits for 1 more minute before running. This time is meant to cover possible time differences between the radars and differing network transfer speeds.

Raingage data arrival wait time

The time to wait for raingage data to arrive is set separately. This is used in the rainfall correction of the **RAIN1** product.

Alternating polarization features

This question enables the listing of the data types **ZDR** and **KDP**, and also the listing of the **K/R** relationship in many of the menus. It also enables the following questions on the **K/R** relationship below.

Default K/R relationship

These number allow control over the default **KDP-R** relationship, similar to the **Z-R** relationship above.

Read Cache size

The IRIS memory mapped I/O library routines support caching file read. It only operates for reading files. Making this size nonzero disables memory mapping and uses the specified cache size in the product generator.

If your system supports memory mapped I/O, then you may want to keep the caching size at 0. If you do not have memory mapped I/O, then benefits can result by setting the cache size to the approximate size of the INGEST volume scans that are being processed. However, if there is not enough main memory to hold these cached data, then the product generator is swapped to disk and no performance benefit are achieved.

Zero Reference Height

Enter the height in meters above MSL used for 0 in the product generator. Generally this should be 0 for mean sea level, but for radars far inland, you might want a different reference. All radars to be composited together should have an agreed upon reference. All heights displayed with the user cursor are relative to this reference.

11.10.2 Reflectivity Profile and Wind

Reflectivity Profile and Wind	
Use Gradient in CAPPI & XSECT	<input checked="" type="checkbox"/> Yes
Gradient Above Melting	i 7.0 dB/km
Gradient Below Melting	i 1.0 dB/km
Melting Layer Thickness	i 1.00 km
Melting Layer Intensity	i 7.0 dB
Default Wind	<input checked="" type="checkbox"/> Disabled

This pane defines the reflectivity profile of a gradient above the melting level, a gradient below the melting level, a melting layer thickness, and a melting layer intensity. The melting layer height, is the intersection of the two gradients, and the top of the bright band.

These numbers are used in the **SRI** product profile correction, and in the **CAPPI** and **XSECT** smoothing.

For more information, see *IRIS Product and Display Guide*.

You can change these numbers while IRIS is running.

Use Gradient in CAPPI & XSECT

Enables a vertical gradient extrapolation in product generation for **CAPPI** and **XSECT** products.

This smooths out the top of the products using the **Gradient Above Melting** value in the reflectivity profile.

This is the minimum value used when a lower sweep has valid data and the upper sweep is below threshold.

Gradient Above/Below Melting

Defines the gradient setting above and below the melting layer.

Melting Layer Thickness**Melting Layer Intensity****Default Wind**

The default wind is recorded with the ingest data and can be used for adjustments to the bird detection algorithm.

To use this feature you must automatically detect the wind speeds and enter them in the radar system.

More information

- [Melting Levels \(page 207\)](#)

11.10.3 Configuring IRIS Status Products

STAT (status) products are typically made on all IRIS systems that are critical to system operation, such as the radar host, the product generator, and or critical display systems. Instead of containing radar data, status products contain information about how well the IRIS system is working.

These products are shown in the product output menu, and can be transferred to other IRIS systems using the product output menu.

When transferred to another IRIS system, the receiving system becomes aware of faults or problems with the sending system. For example, the radar-host status products are distributed to most systems in a radar network, and the red-X is displayed on various windows based on these status products.

The status product lists faults if any of the following occurs:

- BITE critical faults
- RCP communication failure (RCP **DEAD**)
- RVP signal processor error
- IRIS internal critical fault. These are internal errors that are flagged as critical in IRIS.



If there is a change in status such as a critical fault, the **Status** product is generated immediately.

1. In IRIS **Setup > Product**, enable status product generation and configure the product parameters.

Status product generation

If enabled, IRIS also generates status products when the overall system status changes from OK to Fault, or the other way around.

Time between status products

Define how often you want to generate status products (in minutes). Select 0 if you do not want to generate these products.

Make product for each task

Instructs IRIS to make a new status product each time a task starts. This is useful if you wish to do status product task slaving.

Status Prod maximum file count

Type the number of status product files to be kept on the system.

STATUS product receive timeout

Select **Disabled** or **Enabled**.

If enabled, set this time slightly longer than the time between status products.

The default value is 11 minutes with products mode every 10 minutes.

This allows IRIS to detect failures of other networked systems. If it has been more than the specified time since a status product has arrived from another system, it is marked as **Timeout** on the network status display.

2. Identify critical systems.
3. Identify separate receiving system(s).
4. To configure the network identifiers, select IRIS **Setup > RCP > Network Status Reports to RCP**.
This makes it possible to identify the reported sites.
5. Output status products to receiving systems.
6. Determine which status products are referenced by the *SIGNALS.DAT* file for action.
7. Configure the *SIGNALS.DAT* file to take the appropriate action.
8. In the **Product Output** menu, configure the status products for output.

The status products now enable IRIS systems to alert other systems on the network that there are problems or that a particular event has occurred.

These messages can be parsed by the *SIGNALS.DAT* file and actions can be taken such as sending an email to a cell phone.

11.10.4 Product Transmission and Display

Product Transmission and Display	
WARN max time difference	15.0 minutes
TRACK max time difference	0.50 hours
FCAST max time difference	15.0 minutes
Default max time difference	15.0 minutes
Network send timeout	2.0 minutes
Maximum files queued for send	5 files
Centroid value signal	Maximum
Label bottom of CATCH display	Enabled
Label bottom of SLINE display	Enabled
Label bottom of TDWR display	Enabled
Label bottom of TRACK display	Enabled
Label bottom of WARN display	Enabled
Display options menu for Web display	Disabled

WARNING max time difference

IRIS allows the automatic display of a warning overlay on top of any **PPI** or earth projection product.

When the product is displayed, the **WARN** product with the nearest time is overlaid. However, if the time difference exceeds this value, it is not overlaid.

The recommended value is 15 minutes. A value of 0 disables the check.

TRACK max time difference

If the time difference between the most recent point in the **TRACK** product and the data time of the image exceed this limit, then the overlay is not drawn.

A value of 0 disables the check.

FCAST max time difference

Similar for forecast products.

Default max time difference

Similar for all other product types.

Network send timeout

Each time IRIS starts a network transfer, a timer is also started. If the timer completes before the transfer completes, the transfer is aborted. This prevents an infinite lockup of the system in some cases where the network stops working in the middle of a transfer.

Maximum files queued for send

Enter the maximum files that IRIS queues for sending to a network output device, other devices have no limit (for example, in the event of a network failure). When the link is restored all of the queued files are sent. The order of transmission is as follows:

1. All **STAT** products, oldest first.
2. All **RAW** products, oldest first.
3. All other products, newest first.

The receiving machine must then catch-up by processing all the data.

For critical real time applications, keep the number of backlog files in the queue small (for example, 2 or 3) so that real time operation can resume quickly.

For a system where the data archive is important, set the number to be large, for example, to 50, or to 0. A value of 0 means the maximum feature is disabled, and files are queued with no limit. This limit applies only to network devices.

Centroid value signal

When **WARN** products are generated or arrive over the network, they can optionally generate a signal if a warning is detected in a protected area.

Select here if the signal is based on the maximum or average data value. Vaisala suggests using the average value.

All the warning generating products can show the warning message on the bottom of the display window. Use these buttons to enable that feature, if desired.

11.10.5 Product Scheduling Priority

Product Type	Priority
BEAM Product Priority	20
CAPPI Product Priority	20
CATCH Product Priority	0
COMP Product Priority	20
DWELL Product Priority	0
FCAST Product Priority	20
HMAX Product Priority	50
LAYER Product Priority	50
MAX Product Priority	20
MLHGT Product Priority	50
NDOP Product Priority	20
PPI Product Priority	20
RAIN1 Product Priority	20
RAINN Product Priority	20
RAW Product Priority	20
RHI Product Priority	20
RTI Product Priority	0
SHEAR Product Priority	20
SLINE Product Priority	20
SRI Product Priority	0
THICK Product Priority	50
TOPS Product Priority	20

Define the relative priorities for each product type using the range from 0 (lowest priority) to 100 (highest priority).

The product generator sorts the full schedule of products and determines the next product to run according to the following hierarchy:

1. User-defined product priority. All products of a given priority run in favor of products of a lower priority.
2. Oldest data time. Within a given priority, the product that runs on the oldest input data is scheduled before any others.
3. Order within the schedule, from top to bottom.

Different radar sights require different settings.

Typical Schedule

A typical schedule might set:

- XSECT products to priority 30
- WARN products to priority 40
- All others to priority 20

Schedule Optimizing RAW Data Output

A site that must output raw data quickly would increase the priority of **RAW** products or decrease the priority of products considered "background."

11.10.6 Protected Areas

The screenshot shows a configuration window for Protected Areas. It contains two sections, 'Warning Region #1' and 'Warning Region #2', each with a 'Help' button. Region #1 has fields for Name (Center), Center East of the radar (0.000 km), Center North of the radar (0.000 km), Width East-West (100.000 km), Height North-South (100.000 km), and Orientation (0.00 degrees). Region #2 has fields for Name (East), Center East of the radar (110.000 km), and Center North of the radar (0.000 km).

Region	Name	Center East of the radar	Center North of the radar	Width East-West	Height North-South	Orientation
Warning Region #1	Center	0.000 km	0.000 km	100.000 km	100.000 km	0.00 degrees
Warning Region #2	East	110.000 km	0.000 km			

The IRIS warning product (**WARN**) allows you to define up to 32 protected areas.

If the warning results fall into one of the selected protected areas, a signal is sent to all the IRIS terminals.

Each protected area consists of a rectangle. You can define the location, size, and orientation.



If the area you wish to protect is of an irregular shape, you can piece it together with several areas.

Name

Type a name for the region. The name can be up to 12 characters long. If the name is blank, then the region is undefined and disabled.

Center East/North of radar

Type the location of the center of the protected region in kilometers relative to the radar.

Type values for West and South as negative numbers.

Width East-West

Enter the width of the region in kilometers. These numbers cannot be negative.

Height North-South

Enter the height of the region in kilometers. These numbers cannot be negative.


Orientation

You can rotate the region specified with the previous questions by up to 180° clockwise from the straight orientation.

11.11 IRIS Output Devices Setups

11.11.1 Output Device General Specifications

You configure the output device in **Setup Utility > Output**.

Number of output devices


Before adding an output device, update the **Number of output devices** field with the new total number of output devices for your system setup.

The maximum number supported is 200. For information on increasing the value, see [File and System Quotas \(page 188\)](#).

General Output Device Questions

For each output device, the questions vary depending on the device type, the following questions always appear.



Device Type

Enter the device type **Archive**, **Link**, **Network**, **Printer**, **Window**, or **UNUSED**.

Menu alias

Select a text alias that is displayed in the pull down menus where you are selecting an output device.

The alias allows easy identification of output devices. For example, you may have window outputs on several different workstations, and you could place the node name here.

Min time between output

For slow network outputs, you can pace the outputs such that some of the outputs are skipped by selecting a pacing time here.

To enable this feature, you must also tag the product header lines with the **Time Filter** bit in the **Product Output Menu**.

11.11.2 Printer Specific Parameters



This setup is for printer output devices selectable from the **Product Output Menu**. Screen dump style printing is configured from the printer/setup menu. Only Postscript printers are supported.

Paper Size

Select the size of paper in your printer.

Choices are 8.5 × 11, 8.5 × 14, 11 × 17, A4 and A3.

If the paper size is wrong, the printer does not print.

Queue Name

Enter the name of your printer queue.

To see a list of available choices, type **lpstat -a** at the UNIX shell.

Width and Height of image

Enter the dimensions of the print image to be generated and sent to the printer.
Postscript printers do not rescale to fit the screen.

11.11.3 Window Specific Parameters

Minimum time between output

Adds a "skip" for products sent to a particular destination.

Device movie length

Enter the number of frames in the Quick Look movie for that device, usually 20.

Width/Height of image

Specify the width and height of the target image.

This is the initial size and the size can be changed by the mouse. The space reserved for Quick Look movies is based on the movie length and default image size.

If you change the image size during operation, the maximum movie length changes

Horizontal/Vertical offset

Specify the initial position of the window on the screen. This is the upper left corner. On SGI systems an offset of 0, 0 places the window such that the window manager's border is not visible.

Slide Show

Specify if the window should power up in slide show mode or not.

Display Name

Specify the workstation display and screen number on which the window is to appear.

11.11.4 Network Specific Parameters

You configure network parameters in **Setup Utility > Output**.

File format	IRIS (Def)
Filename format	Default
Compression scheme	None
Notification scheme	TCPIP
Target directory	/usr/iris_data/product
Copy scheme	SCP
User name	radarop
Notification port number	30725
Recipient host name	Analysis

File format

Enter the format of the file transferred. The recommended format for IRIS-to-IRIS transfers is **IRIS**.

Table 26 IRIS Output File Format Options

Choice	Description
IRIS	File copied without conversion.
NORDRAD1	File converted to NORDRAD1 format
BMP	-
GIF	-
TIFF	TIFF format with GeoTIFF header information, you can view the GeoTIFF information with <code>listgeo</code> .
JPEG	-
PNG	-
Postscript	-
None	File is not copied. Notification is sent.

Choice	Description
Pipe	<p>User-specified pipe program</p> <p>Pipes are programs are run separately from IRIS. This gives flexibility because you can install your own, and you can upgrade the program without interrupting IRIS.</p> <p>Note that detailed error messages cannot be signaled to the IRIS error log. Instead, a generic fault signal is logged saying to look for an error log file. These pipes write a <code>*.log</code> file in the <code>\${IRIS_LOG}</code> directory.</p> <p>The pipe configuration tuning cycle consists of:</p> <ol style="list-style-type: none"> 1. Attempting to output a file. 2. Checking the log file. 3. Editing the <code>.conf</code> file. 4. Trying again.
Header	File header is copied.

Pipe program name

This parameter is shown if you select a pipe file format.

You can specify the name of a user supplied pipe program used to format the output file. The program must be placed in the `${IRIS_PIPES}` directory.

The following table shows the output pipes supplied with IRIS.

For information on writing your own pipe see *IRIS Programming Guide*.

Table 27 Supplied IRIS Output Pipes

Name	Supported Products	Supported Data Types	Syntax	Purpose
IrisToAdids	PPI, CAPPI, TOPS, BASE, MAX, RAIN1, RAINN, SRI, VIL, VIR, LAYER, HMAX, SHEAR	T, Z, Zc, Ze, V, Vc, W, SQI, ZDR, ZDRc, PhiDP, KDP, RhoHV, LDRh, LDRv, PhiDPh, PhiDPv, HCLAS, VIL, Rain Rate, RAIN, H, SHEAR, SNR	Pipe	Converts IRIS product to ADIDS format.
IrisToArchive 2	RAW	Z, V, W	Pathnames	Converts IRIS RAW product to NEXRAD Archive2 format.
IrisToAsterix			Pipe	Converts IRIS product to Eurocontrol ASTERIX format.
IrisToBufr	PPI, CAPPI, TOPS, MAX, RAIN1, RAINN, VVP, SRI, VIL, VIR, RAW	V, W, ZDR, LDRh, Rain Rate, RAIN	Pipe	Converts IRIS cartesian product to WMO BUFR format using OPERA guidelines.

Name	Supported Products	Supported Data Types	Syntax	Purpose
IrisToEwis	RAW			Converts IRIS to EWIS format
IrisToGrib1	CAPPI, TOPS, BASE, RAIN1, RAINN, SRI, VIL, HMAX, USER	Z, V, W, ZDR, Rain Rate, RAIN, H	Pipe	Converts IRIS Cartesian product to WMO GRIB version 1 format.
IrisToHDF5	PPI(NORDRAD), CAPPI, TOPS, MAX, RAIN1, RAINN, RHI VVP, XSECT, RAW	Z, V, W, SQI, ZDR, PhiDP, KDP, RhoHV, LDRh, VIL, Rain Rate, RAIN, H	Pathnames	Converts IRIS product to HDF5 format using NORDRAD2 guidelines.
IrisToMcIdas	PPI, CAPPI, TOPS, BASE, MAX, RAIN1, RAINN, SRI, VIL, HMAX, SHEAR	Z, Zc, V, Vc, W, ZDR, LDRh, LDRv, VIL, Rain Rate, RAIN, H, SHEAR	Pathnames	Converts IRIS product to McIDAS area files.
IrisToNetCDF	RAW	T, Z, Zc, V, Vc, W, SQI, ZDR, ZDRc, PhiDP, KDP, RhoHV, LDRh, LDRv, PhiDPh, PhiDPv, HCLAS	Pathnames	Converts IRIS RAW product to NetCDF files.
IrisToOdimHdf5	PPI (EWIA files), CAPPI, TOPS, MAX, RAIN1, RAINN, RHI VVP, VIL, XSECT, RAW	T, Z, V, W, SQI, ZDR, PhiDP, KDP, RhoHV, LDRh, VIL, Rain Rate, RAIN, H, SNR	Pathnames	Converts IRIS product to HDF5 format using OPERA guidelines.
IrisToUf	RAW	T, Z, Zc, V, W, SQI, ZDR, PhiDP, KDP, RhoHV, LDRh, LDRv	Pipe	Converts IRIS RAW product to UF format.
IrisToUKMO			Pipe	Converts IRIS RAW product to UKMO format.
VilToVir			Pathnames	Converts an IRIS VIL product to average Z.



For more information on configuring pipes, see the comments in the appropriate **.conf** file for the pipe in the **config_template/init** directory.
During development, copy it to your configuration directory and edit as required.

Command line syntax

This parameter is shown if you select a pipe file format. The choices for how IRIS runs the pipe program are shown below. In addition, the output process sends the color seam values and number of colors.

- Pipe:

```
pipe-pathname input-filename <input-pathname >output-pathname
```

- Pathnames:

```
pipe-pathname --ip:input-pathname --op:output-pathname
```

In addition to these arguments, the pipe program is supplied with the following arguments:

<code>-seams=1:2:3:4</code>	Specifies the seams between colors
<code>-colors=12</code>	Specifies the number of colors
<code>-device=0</code>	Specifies the output device number, origin 0.

Filename format

Enter the format of the file name produced. The choices are:

- **Default**
Node `YYMMDDHHMMSS.PPPNNNN`.
- **Native**
The same format used in the IRIS internal inventories (with a new random suffix).
Node `SSSYMMDDHHMMSS.PPPXXXX`.
- **8.3**
Node `.NNN`.
- **METPS**
Is node `ATYMDHMS`.
- **Original**
Original is the same format with the same name used in IRIS internal inventories.
The purpose of the original format is to allow a program to reference the original data files later.
Original is node `SSSYMMDDHHMMSS.PPPXXXX`.
- **IIA**
Node `PPP_D_PSI_RNG_YYYYMMDDHHMMSS`.

The recommended format for IRIS-to-IRIS transfers is **Default**. Note that pipe programs have the power to override the output filename, so these choices may be effectively ignored.

The node formats and syntax are as follows:

SSS

3-letter site code

YYYY

4-digit Year

YY

2-digit Year (modulo 100)

MM

2-digit Month

DD

2-digit Day

HH

2-digit Hour

MM

2-digit Minute

SS

2-digit Second

PPP

3-letter Product type

XXXX

4-letter Random characters

node

Source system's node name, limited to 8 chars in 8.3 format

NNNN

4-digit base 10 number incrementing for each file

AT

Letters "AT"

YMDHMS

Year-1990, month, day, hour, minute, second, all base 62.

D

1 or 2-letter data type

PSI

3-digit product specific information

RNG

3-digit maximum range in km

Compression scheme

Select one of the following:

- **None**
- **Compress**
The filename gets a `.Z` suffix.
- **Gzip**
The filename gets a `.gz` suffix.
- **TIFF PackBits**
Only applicable to outputs in TIFF format.

NORDRAD files are always compressed with the NORDRAD scheme. For IRIS-to-IRIS transfers we recommend compressed if it is bandwidth limited, otherwise normal.

Notification scheme

IRIS supports the following network output notifications:

- **None**
- **NORDRAD1**
- **TCPIP** (a socket message is sent to the receiver, using address format **INET**)
- **RENAME** (the file is renamed after the copy is complete so a polling program finds a complete file)
- **UNIX** (a socket message is sent to the receiver, using address format **UNIX**)

The recommended notification for IRIS-to-IRIS transfers is **TCPIP**.



The UNIX address format can only be used to communicate with a program on the same computer that IRIS is running on. Therefore it can be used only for communication with a UPI program, and not for communication to another IRIS. It creates a socket file with path name `${IRIS_KEYS}iris_portXXXXX`, where `XXXXX` is the port number.

Target directory

Specify the directory where the file is to be copied. The directory should be a maximum of 56 characters long. The recommended directory for IRIS-to-IRIS transfers is the `${IRIS_PRODUCT}` directory on the receiving machine.

Copy Scheme

None

The product file is not copied at all. Use this to just notify another program about your product.

Copy

The file is copied using program I/O, with **fopen**, **fread**, and **fwrite**.

The recommended copy scheme for IRIS-to-IRIS transfers is **RSCP**.

Use **Copy** only if either: You are copying to the source computer or if **SCP** does not work, and you are using NFS.

RCP

Use the `rcp` secure copy shell command.

SCP

Use the `scp` secure copy shell command.

Script

A user-specified copy script program is run to do the copying.

User name

This question is shown for script copy schemes and RCP copy schemes.

It is the user name supplied to the script, and used in the **rcp** command before the "@" sign.

The recommended value is **operator**.

Password

This question is shown for script copy schemes.

It is the password supplied to the script. The value is not displayed, and is encrypted in the configuration file.

Copy script name

This question is shown for script copy schemes.

You can specify the name of a user supplied program used to copy the file to the target.

You must place the program placed in the `${IRIS_PIPES}` director with the following arguments:

SourcePath DestPath DestHost User Password [RenameName]

The source path is in a temporary directory. The destination path is the directory specified in above. The following table shows the copy scripts supplied with IRIS.

Table 28 Copy Scripts Supplied with IRIS

Copy Script	Purpose
sig_ftp	Runs the FTP program to copy files
N2RelayOut	Uses N2 library to store products to NORDRAD2

Notify port number

This question is shown for TCP/IP and UNIX notification.

For output to an IRIS on another computer use port number 30725.

For output to a UPI program on any computer, use port number 30726. This allows the UPI program to run on a computer node which is also running the IRIS network receiver.

Node name

This question is shown for TCP/IP notification.

Enter the name of the machine to notify.

NORDRAD1 Example

If you are outputting to a NORDRAD1 system, the following table summarizes the system configuration.

Parameter	Value
File Format	NORDRAD
Filename format	Default
Compression Scheme	None Nordrad packing is done automatically
Notification scheme	NORDRAD
Target directory	<i>/usr/iris_data/nordrad</i>
Copy scheme	Copy
Recipient host name	<blank>. The NORDRAD hostname is configured in the <i>NORDRAD_AREAS.DAT</i> file.

11.11.5 Archive Specific Parameters

Type of archive media

Select **Tape**, **Magneto-Optical**, **Large Disk**, or **DVD** (Linux only) to specify the type of archive device.

Tape

If you chose **Tape**, the following question appears:

Device file

Set the name of the device file for the tape. Note that this often takes the form of a name like */dev/rmt/c1t2d0*. This means SCSI controller card 1, SCSI address 2, device 0.

Magneto-Optical

If you chose **Magneto-Optical**, the following questions appear:

File system type

Applicable to HP systems only. Set to **HFS** or **VXFS** to match your systems root file system type.

Device file

Set the name of the device file for the disk. Note that this often takes the form of a name like */dev/dsk/c1t2d0*. This means SCSI controller card 1, SCSI address 2, device 0.

MO Disk mount point

Specify the point for the MO disk. The recommended value is */modisk*, but any value could be used.

Raw Device file

Usually the same as the device file, but with a *rdsk* in the path.

Large Disk

If you chose **Large Disk**, the following question appears:

LDA directory

Specify the LDA directory, typically something like */usr/iris_data/lda1*.

DVD

If you chose **DVD** (Linux only) the following questions appear:

Device File

Specify the device file used for the DVD drive. Typically it looks something like */dev/scd0* or */dev/scd1*.

You can determine this by typing as root **cdrecord -scanbus**. Identify the entry for your DVD. The middle number of the leading group of 3 numbers identifies your device, for example, 3,0,0 corresponds to */dev/scd0* while 3,1,0 would be */dev/scd1*.

DVD Disk mount point

This is usually */mnt/dvd*.

Buffer Size

To make the DVD writing more efficient, files are written to a temporary buffer called */usr/iris_data/temp/DvdArchive1* (for DVD 1). When the buffer size specified here is exceeded, then the files are written as a block to the DVD. During the write, IRIS "locks-out" sending new files to the buffer. After the files are written, the contents of the buffer are all deleted and the process repeats automatically. Files queued for send to the DVD are not lost. Note that the buffer is flushed to the DVD if IRIS is stopped (by **qiris**). Typical buffer size is 200 MB. DVD's can hold approximately 4 GB.

12. Suncal Utility

12.1 Suncal Overview

The sun may serve as an external radiation source for calibration of a radar system. This technique is simple and requires no external hardware to the radar system. The sun's position can be calculated from any point on Earth at any given time provided that accurate time and lat/lon information is known. This provides a convenient check for the antenna pointing accuracy. The sun's power can also be a useful technique for monitoring the calibration of the receive chain of the radar when used in conjunction with independent measurements of solar flux density. Solar flux densities are known to vary with frequency and are measured accurately over the 100 to 10000 MHz band from various solar observatories. Antenna beam width can also be computed from sector scans of the sun.

The **Suncal** utility performs sector scans of the sun's position and outputs calibration data. The utility is supplied with both the RDA and IRIS releases and works with the RVP signal processors and any antenna controller accessible through the antenna library. The **Suncal** utility can be run interactively from a command line and does not use a graphical interface. It can also be inserted into the **Task Scheduler** as an Exec Task and run on a routine basis.

The **Suncal** utility outputs a **BEAM** product. The **BEAM** product contains SNR data with no thresholding and can be viewed on an IRIS system, but is not automatically inserted into an IRIS product directory. The **BEAM** product is then processed to produce a final calibration results file.

On dual-polarization radars, **Suncal** can output a second **BEAM** product containing LDRH data. This is used to compute the LDR offset.

12.2 Invoking Suncal and Options

To invoke **Suncal**, type the following command:

```
$ suncal
```

Suncal was designed without a graphical utility so it can be run as an IRIS Exec Task.

When running automatically from the IRIS task scheduler, **Suncal** produces an IRIS error message for an error (such as the measured sun peak power is below a specified threshold), or a configuration drift (such as the antenna offset errors are larger than desired, or the LDR offset is too big). This is useful for running **Suncal** routinely without operator interaction and still being able to monitor the calibration of the receive chain.

The `2>&1 | signal_iris` command causes IRIS to signal the error output from **Suncal**.




Figure 50 Suncal Exec Task

Suncal may also be run interactively from the command line. If run interactively, the current status is reported on the terminal as well as reporting the calibration results. There is also an option to process an input **BEAM** product(s) that may have been created earlier. This is useful for remote testing. For example, you can run **Suncal** and then send Vaisala the resulting **BEAM** product which we can then process for analysis.

Table 29 Suncal Command Line Options

-auto	Do not log progress on the terminal, skip update. The -auto option is normally given when running as an Exec Task to preclude output to a terminal window.
-full	Do full scan, process, and update phases (default).
-help	Print this list.
-process:<path>	Process an existing BEAM product.
-resave	Reads and saves the <i>suncal.conf</i> file with comments and all new fields filled with default values.
-update[:<file>]	Interactive update from results, most recent if blank.
-version	Prints the version number.

12.3 How Suncal Works

Solar scans can provide you with an antenna pointing offset, antenna beam width measurements, receive chain and LDR offset calibration.

Variation in the solar flux of the sun has little effect on the antenna pointing and beamwidth measurements. Changes in the solar flux density affect the power measured by the receiver. However, you can use independent measurements of the solar flux density to verify changes in relative peak power and to calculate the antenna gain for a radar system.

Suncal operation is broken down into 3 phases, each of which produces an output used by the next phase:

1. The scan phase runs the antenna and collects data which is stored in IRIS format **BEAM** products.
2. The process phase reads in the **BEAM** product(s) and calculates a results file.
3. The update phase reads the results file and interactively allows the operator to update the radar calibration.

12.3.1 Antenna Scanning Sequence

The **Suncal** utility uses the antenna library to control the antenna scan.

We normally expect that the antenna angles are input to the RVP processor, which is the case for IRIS. The current UTC time is taken from the local computer system's time to compute the sun's position. You must check that the time is correct to within a few seconds.

A **Suncal PPI** sector scan is created and starts centered at the sun's initial position minus half of the elevation span given in the *suncal.conf* file. This scan starts below the sun's position and scans back and forth at the resolution requested in the file.

You control the PRF, sample size, range bin spacing, and number of bins. This task is not angle synced. The azimuth scan speed is half that implied by the requested PRF and sample size. The data nearest to the desired azimuths are stored.

The first defined pulse width of the signal processor is used. The quality of the sun calibration should not be affected by different pulse widths because the sun is broad band, just like the noise. The recorded data is SNR (which in IRIS is dBT with range normalization turned off).

To account for the sun's movement during the scan, some corrections need to be made so the output is similar to a non-moving radiation source.

To do this, the sun's position is recalculated at the start of each sweep. The change in the sun's position is subtracted from all angles for that sweep. This correction is output to the terminal window during each sweep when run interactively.

For example, if the sun moved towards the horizon by 0.10° during the **Suncal** task and there were 5 sweeps the elevation angle increment of each sweep would be numerically decreased by approximately 0.02° . Similar angle corrections are done in the azimuth direction.

12.3.2 BEAM Product Generation

BEAM is a full screen cross-section format image showing range-averaged intensity in azimuth and elevation coordinates.

BEAM is used during calibration and alignment and to verify antenna patterns.

A **BEAM** product is automatically produced upon the completion of the sector scan.

This **BEAM** product range averages most of the bins. You can selectively skip nearby bins to avoid clutter.

The azimuth and elevation limits of the **BEAM** product are chosen to be slightly larger than your sector scan.

The **BEAM** product is placed in the specified directory.

- If you have an IRIS system running, place this in the `/usr/iris_data/input` directory, and configure a blank input pipe to read them. This means you can display them in IRIS.
- If you do not have IRIS, use the **productx** utility to view the **BEAM** product numerically.

If you requested a dual-polarization calibration, a second LDR **BEAM** product is produced, covering the same area.

12.3.3 Processing BEAM Data into Results

The measured location of the sun in the **BEAM** product is calculated by first thresholding the SNR data above a certain signal-to-noise level which is configured in the `suncl.conf` file.

A 2D second order polynomial is fitted to the resulting data. Note that this fit fails if you set the threshold too low (everything passes), or set it too high (nothing passes). Take care with selecting the threshold and the radars operating noise level. This is best done after checking some produced **BEAM**.

The peak power of the sun measurement, and target beam width are determined from the polynomial fit and finding the peak and width. Note that the azimuthal target beam width appears larger than expected by $1/\cosine$ of the elevation angle because an azimuth degree corresponds to less than a degree of a great circle as you get nearer to the zenith. Because of this, we recommend that you keep the azimuth sector width at least 8° .

The **RAW** value is what is measured from the **BEAM** product. The other value is corrected for this effect. The peak power is also converted to dBm and stored in the results. All other areas are corrected for this effect.

From now on, only data with a signal strength greater than 3 dB below the peak value are used. Again a 2D second order polynomial is fitted to the **Zh** SNR data. The sun's position is determined by solving that polynomial for 0. The position is then compared to the sun's calculated position at the start of the scan and antenna pointing offsets are given in both azimuth and elevation.

For dual-pol data, the second LDR **BEAM** product is also processed. We compute the average LDR in the 3 dB peak region, and store it in the results. This number should be near 0. This number, when added to the current LDR offset is the new estimate for what the LDR offset should be. A polynomial fit is also calculated for **Zv** by adding the LDR to the **Zh** values. The sun's position in V polarization is also printed so you can check the alignment.

Note that you can skip the scanning phase, and pick up processing at the **BEAM** product phase by calling **Suncal** with the `-process:` command line arguments. For dual-pol data supply 2 `-process:` arguments, 1 for the SNR **BEAM**, and 1 for the LDR **BEAM**.

12.3.4 Interactively Updating Configs from Results

Interactive update is only available for the LDR offset.

This is a feature which automatically changes your LDR offset in the `setup_dsp.conf` file, and put it into use. It displays the difference, and prompt you to answer **y** if you want to make the change. It is up to the operator's judgement to determine if this is a normal drift, or if something has broken in the receiver and the change should not be applied.

When changes are made, they are logged to the `/var/log/messages` and `/var/log/sigmat.log` files.

You can skip the **BEAM** processing phase, and pick up processing just at the Interactive Update phase by calling **Suncal** with the `-update` command line argument. This reads in the most recent `suncal_results` file.

If you run **Suncal** automatically from the IRIS task scheduler, if a change is detected, you are prompted to run `suncal -update` manually.

12.4 Using Suncal Results

The calibration results file contains information derived from the calibration including, for example:

- Housekeeping information about the radar, such as the time, location, and site name.
- Radar calibration numbers such as the noise level and the receiver bandwidth.
- Numbers calculated from the sun such as the observed position of the sun, the pedestal angle errors, the area of the sun above threshold, the beam widths, and the peak power of the sun.

You can use the antenna offset errors to adjust axis offsets in RCP8 and the beam width to verify manufacturer's stated widths.

The following is an example results file. Your results file may be different.

```
results.sVersion = "8.12"
results.sSitename16 = "SIGMET, dry2"
results.sSitename3 = "DRY"
results.VolumeYmds.isec = 80657
results.VolumeYmds.imills = 2915
results.VolumeYmds.iyear = 2006
results.VolumeYmds.imon = 3
results.VolumeYmds.iday = 24
results.BeamYmds.isec = 80709
results.BeamYmds.imills = 2374
results.BeamYmds.iyear = 2006
results.BeamYmds.imon = 3
results.BeamYmds.iday = 24
results.FileYmds.isec = 80709
results.FileYmds.imills = 2382
results.FileYmds.iyear = 2006
results.FileYmds.imon = 3
results.FileYmds.iday = 24
results.fRadarLon = -70.99999996
results.fRadarLat = 41.10000003
results.fRadarAltitude = 95
```

```
# Expected location of the sun.
results.fSunAzPos = 263.0827948
results.fSunElPos = 21.18174355
# Results from processing the BEAM product.
results.fTargetArea = 1.483424239
```

```
# If 1, then continue processing.
results.bTargetAreaValid = 1
results.fFitError = 0.3933128975
```

```
# If 1, then continue processing.
results.bTargetFitValid = 1
results.fTargetAzPos = 263.0988999
results.fTargetElPos = 21.2056663
results.fTargetPowerSnr = -3.364420032
results.fTargetWidthAzRaw = 1.152942299
results.fTargetWidthAz = 1.074832609
results.fTargetWidthEl = 1.07264875
results.fTargetPowerTotal = -80.85394878
results.fTargetPowerSun = -85.86442003
results.fTarget3dBArea = 0.8191843212
```

```
# If 1, then continue processing.
results.bPositionsValid = 1
results.fAzError = 0.01610509038
results.fElError = 0.02392274305
```

```
# If 1, then the Az and El errors were within tolerance.
results.bAzElErrorsOK = 1
```

```
# Results from the Cross Pol BEAM product.
results.bXpolProcessed = 1
results.fXpol3dBArea = 0.8191843212
```

```
# If 1, then offset was calculated.
results.bXpolLdrOffsetValid = 1
results.fXpolLdrMeasured = -2.841477054E-15
results.fXpolLdrOffset = -0.9
```

```
# If 1, then the LDR offset error was within tolerance.
results.bXpolLdrOffsetOK = 1
```

```
# If 1, then positions were calculated.
results.bXpolPositionsValid = 1
results.fXpolTargetAzPos = 263.0988999
results.fXpolTargetElPos = 21.2056663
```

```
# Calibration numbers.
results.fI0Horiz = -81.15
results.fCalNoiseHoriz = -79.98
results.fRadarConstantHoriz = -33.26
results.fActNoiseHoriz = -82
results.fActNoiseVert = -82
results.fReceiverBandwidth = 1
results.iXmtPolarization = 0
results.fWaveLength = 5.4
results.fPulseWidth = 1
results.f0ldLdrOffset = -0.9
results.f0ldZdrOffset = 0.25
```

12.4.1 Antenna Beam Width Calculation

The target width measured by suncal is a function both of the antenna beamwidth and of the width of the sun.

If both signals were Gaussian, it would be a simple matter to correct for the sun's width. Unfortunately the sun is a disk of constant power, and the background noise is within a few dB. Here is a table for approximate conversions:

Table 30 Antenna and Sun Beamwidths

Antenna Beamwidth (Degrees)	Measured Beamwidth (Degrees)	Difference
0.200	0.522	0.322
0.300	0.534	0.234
0.400	0.574	0.174
0.500	0.636	0.136
0.600	0.711	0.111
0.700	0.794	0.094
0.800	0.881	0.081
0.900	0.972	0.072

Antenna Beamwidth (Degrees)	Measured Beamwidth (Degrees)	Difference
1.000	1.064	0.064
1.100	1.158	0.058
1.200	1.253	0.053
1.300	1.349	0.049
1.400	1.445	0.045
1.500	1.542	0.042
1.600	1.640	0.040
1.700	1.738	0.038
1.800	1.835	0.035
1.900	1.938	0.033
2.000	2.035	0.031

12.4.2 Using Results to Calculate Antenna Gain

The solar peak power can be used to compute the gain of the antenna. This gain can be monitored over time to determine the stability of the receiver calibration.

For solar calibration, antenna gain can be written as:

$$G = \frac{4\pi \times P_s}{F_s B_n \lambda^2}$$

G

Antenna gain (dimensionless) on beam axis.

P_s

Received sun peak power (dBm) (`fTargetPowerSun`)

F_s

Solar flux density ($\text{Wm}^{-2}\text{Hz}^{-1}$)

B_n

Noise bandwidth (Hz) (`fReceiverBandwidth`)

λ²

Transmit wavelength (m)

The calculated antenna gain must be corrected to determine the true gain of the system. Solar flux measurements include all polarizations so 3dB must be added to the gain as half the power is lost due to receiving in a single polarization. An additional beam filling correction must be made because the sun radio diameter (0.56 ... 0.58⁰) is considerably smaller than most antenna's 3 dB beam width. A beam filling correction for Gaussian main beams is given below:

$$K(dB) = 20\log\left(1 + 0.18\left(\frac{U_s}{U_a}\right)^2\right)$$

For example, a 1.0° beam has a filling correction of 0.49 dB. Experience has shown about ± 0.5 dB fluctuation in true antenna gain due to solar flux and receiver measurement uncertainties.

Observations of solar flux density (F_s) are available publicly on the internet for several frequencies, locations, and times of day. Suggested sites are the Solar Environment Center (SEC), National Oceanic and Atmospheric Administration in Boulder, Colorado; the Dominion Radio Astrophysical Observatory at Penticton, British Columbia, and the IPS Radio and Space Services Observatory in Australia.

To read the suncal results file into the C++ memory structure, use the `LoadSuncalResults()` function.

12.5 Suncal Configuration File

The **Suncal** utility uses information within the `suncal.conf` file stored in the `{IRIS_CONFIG}` directory.

You can adjust your configuration by editing this file with a text editor such as **emacs** or **vi**.

In the file users, you can add details of the scanning strategy, data output directories, whether to create a log file, and IRIS messaging signal thresholds.



Optional sun simulation is built in to the utility to help testing. You must turn this off for operation.

-resave

Running the **Suncal** utility with the **-resave** option reads in the old `suncal.conf` file, fills in all new fields with default values, and writes out the file including comments.

You can run **suncal -resave** when there is no file to create a default file.

It is a good idea to do this also when you are first using **Suncal** after an upgrade. The user can then change parameters within the `suncal.conf` file to suit their needs. When designing the sector task, remember that tasks are limited to 40 elevation angles.

Configure Logging

The options to create logging while the **Suncal** utility runs, the source of the angle tags, simulation, and minimum sun angle are at the top of the file.

If you wish to run with radiate turned off, and your RVP processor does not sense the radiate control signal, then it faults with `burst pulse missing`. To allow operation in this case, set `AbortOnMessages` to 0.

```
sun_cal.sVersion = "8.12"

sun_cal.lLogToFile = 1

sun_cal.lLogToTerm = 0

sun_cal.lAbortOnMessages = 1

# 1=RVP Tags, 3=AntLib.
```

The **Suncal** utility also checks the elevation angles to ensure they are not outside the position limits of the antenna. A maximum sun angle of 85° has been hard coded into the utility.

The following example shows an excerpt of the *suncal.conf* file where these fields are configured.

```
sun_cal.iAngleSource = 1

# Add a simulated sun, set to 0 for operation.

sun_cal.lSimulateSun = 0

# Will not run if the sun is below this angle in degrees.

sun_cal.fMinimumSunEl = 5
```

Configure PRF, Start Range, Range Bin Spacing, Input Bins, and Pulse Samples

In the following section of *suncal.conf* are the options to configure the PRF, start range, range bin spacing (km), number of input bins, and pulse samples.

We suggest that you select a fairly large start range (like 100 km / 62.1 mi) to avoid interference from weather, clutter, and airplane returns. The azimuth scan speed is half that implied by the requested PRF and sample size. If you have a dual-polarization radar, you configure the transmit polarization here. You must specify a valid polarization which you can transmit.

```
# Configure the recording task here.

sun_cal.fPrf = 800

sun_cal.fRangeStart = 100

sun_cal.fRangeStep = 0.150000006

sun_cal.iBinCount = 1000

sun_cal.iSampleSize = 64

# Choices are 0=Horiz, 1=Vert, 2=Alt, 3=Simul.

sun_cal.iTaskXmtPolarization = 0
```

Configure Resolution and Sector Span

In the next section the resolution and sector span are configured for azimuth and elevation in degrees.

```
# Spacing between rays in degrees.

sun_cal.Az.fSpacing = 0.200000003

# Span of the sector in degrees.

sun_cal.Az.fSpan = 8

# Spacing between rays in degrees.

sun_cal.El.fSpacing = 0.200000003

# Span of the sector in degrees.

sun_cal.El.fSpan = 8
```

Configure BEAM Products

Next we configure the **BEAM** products.

Specify a directory to write the **BEAM** products. If the **BEAM** product is added to the `$IRIS_PRODUCT` directory it is eventually removed by the watchdog process.

It is often a better choice to put the **BEAM** product somewhere else so it is retained for future reference.

To view the **BEAM** product in the QLW, then a nice plan is to place this in the `/usr/iris_data/input` directory, and configure a blank input pipe to read them.

```
# Configure the BEAM product here.

# Write the beam products to this directory.

sun_cal.sBeamDirectory = "/usr/iris_data/input/"
```

If you wish to make an **LDR** calibration from the sun, then specify a second **BEAM** product data type. Choices are to transmit horizontal, and generate LDR, or transmit simultaneous and generate ZDR. You should be able to get both the LDR offset, and the vertical position offset. If you wish to calculate the vertical beam width, run a vertical polarization scan.

```
# Second BEAM data type: 0=none, 25=LDR, 5=ZDR

sun_cal.iBeam2DataType = 25
```

The final section of the *suncal.conf* file configures the processing to produce the results from the **BEAM** products.

```
# Configure the results processing here.

# Write the results file to this directory.

sun_cal.sResultsDirectory = "/usr/iris_data/suncal/"

# Power above this level (in SNR)

sun_cal.fBeamPower = -2

# must cover at least this area (in square degrees).

sun_cal.fBeamArea = 1

# The 3dB beamwidth of the sun must be at least this area (deg**2).

sun_cal.fBeam3DBArea = 0.200000003

# The peak power must be at least this, in SNR.

sun_cal.fBeamPowerThresh = 0

# Alert if the sun's position error is larger than this, in degrees.

sun_cal.fBeamPosThresh = 0.5

# Alert if the LDR offset error is larger than this, in dB.

sun_cal.fBeamLdrOffsetThresh = 0.200000003
```

12.6 Configuring *syslog.conf* for Suncal

The **Suncal** utility logs calibration changes using syslog to puts a message into the `/var/log/messages` file. If you wish to put these in a separate file, perform the following steps.

- ▶ 1. Log in as **root**.
- 2. Edit the `/etc/syslog.conf` file by adding the following at the end of the file:

```
# Log user.info messages to sigmet.log
user.info /var/log/sigmet.log
```

- 3. Send `kill -hup` to the `syslogd` process.

13. RVP and RCP Network Export Utilities

13.1 Network Export Overview

RVP communicates to a host computer through a standard TCP/IP Ethernet connection. RCP8 communicates through Ethernet or serial line.

The following utilities can be used for the network communication:

- **DspExport** exports the **dsp** library over the network to separate host computers. This is the only way to interface to RVP from a separate computer.
- **AntExport** exports the **antenna** library internal state over the network to a separate host computer. This is a low-bandwidth alternative to running programs like **Antenna** and **Bitex** over the network. This allows multiple computers to control the antenna simultaneously.

Vaisala does not recommend using this in most environments.

These utilities provide flexibility for implementing RVP, RCP, and IRIS under different network and hardware platform scenarios. For example, RVP and RCP running on separate PCI systems or in various combinations on the same PCI system.

You can also use the **DspExport** and **AntExport** utilities to run remote maintenance utilities over low-speed or high-latency network links for which the X-window export technique is not effective.

13.2 DspExport Overview

DspExport works as follows:

- When it receives a socket connection request, it establishes a connection to the radar server computer (RVP902) and initially allows multiple connections.
- **DspExport** handles the **INFO**, **SETUP**, and **OPEN** commands.
- When the **OPEN** command is sent, an exclusive connection for I/O to RVP902 is established.
If a second **OPEN** request arrives while the first is still active, it fails, and returns the message `Device allocated to another user.`

The source code and examples for **DspExport** and the **dsp** library are provided with the RVP release software.

Table 31 DSP Files

Example	File
DspExport	<code>\${IRIS_ROOT}/src/rda/dsp</code>

Example	File
<i>dsp</i> library	<code>\${IRIS_ROOT}/base/dsp_lib</code> In the library, the example code talks to DspExport in the <i>OpenSocket.c</i> , <i>dsp_read.c</i> , and <i>dsp_write.c</i> files.



Search for the string **SOCKET** to see how the code differs between SCSI interface and socket interface.

- 1. To check if **DspExport** is running, type:

```
$ ps -aef | grep DspExport
```

DspExport is usually configured to run all the time.

2. You can start the application from the terminal window by typing: **DspExport**
3. For detailed logging, start the daemon with the **-v** option
4. The default port is 30740.
To use another port, start it with an option such as **-port:12345**.
5. To view the options, type **-help**.

13.3 Starting and Stopping **DspExport** and **AntExport**

If **DspExport** or **AntExport** are used on a platform, then they should be configured to start automatically when the computer boots.

Vaisala software runs as services in the Linux operating system in order to take advantage of built-in management tools for starting and stopping services. This includes a graphical user interface for controlling services and built in support for controlling services at different run levels of the operating system.

Enable the software for the following levels (indicated by an *).

- 0 Halt
- 1 Single-user mode
- 2 Not used (user-definable)
- 3* Full multi-user mode
- 4* Not used (user-definable)
- 5* Full multi-user mode (with an X-based login screen)
- 6 Reboot

When configuring how services are started, Vaisala recommends using a command-line utility such as **systemctl**.

DspExport Automatic Start and Test

As **root** type:

```
# cp /usr/sigmet/config_template/init/dspexport /etc/init.d/  
# cd /etc/init.d  
# chmod +x dspexport  
# chkconfig --add dspexport
```



Systems delivered from the factory or installed using **sigconfig** on the IRIS/RDA release software DVD automatically make sure that all of the necessary files and permissions have been set for items in */etc/init.d/*.

To verify that the **DspExport** service starts automatically, as **root**, type:

```
#chkconfig --list dspexport  
antexport 0:off 1:off 2:off 3:on 4:on 5:on 6:off
```

At this point, **DspExport** has been configured to run the next time the computer is restarted. To start **DspExport** immediately, type the following command as **root**:

```
# service dspexport start  
starting DspExport: PC Linux [OK]  
#
```

The ok message is displayed if start-up occurs smoothly. If this message is not displayed, make sure the above steps have been taken and that the service is not already running.

To verify that **DspExport** is running type the following line and check that the response matches the one shown below.

```
$ ps -eaf | grep DspExport  
UID PID PPID C STIME TTY TIME CMD  
operator 4019 1 0 16:05 ? 00:00:08 /usr/sigmet/bin DspExport  
-daemon  
$
```

To stop **DspExport**, run the following command as **root**:

```
#service dspexport stop  
Stopping DspExport: [OK]  
#
```

The ok message is displayed if shutdown occurs smoothly.

AntExport Start-up and Test

For **AntExport** the configuration is similar to **DspExport**. As **root** type:

```
# cp /usr/sigmet/config_template/init/antexport /etc/init.d/
# cd /etc/init.d
# chmod +x antexport
# chkconfig --add antexport
```

To verify that the **AntExport** service will start automatically, as **root**, type:

```
#chkconfig --list antexport
antexport 0:off 1:off 2:off 3:on 4:on 5:on 6:off
```

At this point, **AntExport** has been configured to run the next time the computer is restarted. To start AntExport immediately, type the following command as **root**:

```
#service antexport start
Starting AntExport: [OK]
#
```

The ok message is displayed if start-up occurs smoothly. If this message is not displayed, make sure the steps above have been taken and that the service is not already running.

To verify that **DspExport** is running type the following line and check that the response matches the one shown below.

```
$ ps -eaf | grep AntExport
operator 4019 1 0 16:05 ? 00:00:08 /usr/sigmet/bin/AntExport -daemon
#
```

To stop **AntExport**, run the following command as **root**:

```
# service antexport stop
Stopping AntExport: [OK]
```

The above message is displayed if shutdown occurs smoothly.

13.4 Example Network Configurations

The following examples show the system architecture options. For each option, there is a one page summary diagram that shows the basic topology and the specific set-up responses for the following:

- Setup/RVP. See [Radar Video Processor Setup \(page 149\)](#).
- Setup/RCP. [Radar Control Processor Setup \(page 166\)](#)
- RCP8 TTY setups
- RVP TTY setups




These examples are for network communication only. In addition, the following communications options that have been used on previous systems and are still supported.

- Tag angle input to RVP through parallel tags, S/D convertor or serial line
- RCP8 communication to a host computer through a serial line

See [Non-Network Antenna Angles to RVP \(page 252\)](#).

13.4.1 Example: Separate PC for RVP8, RCP8, and Host (for example, IRIS)

With this approach, hardware for any of the 3 units can be upgraded without effecting the other units. When upgrading a legacy system, this is often the easiest approach.




DspExport Running	Yes	No	No
AntExport Running	No	No	No
setup/RVP			
System has signal processor	Yes	No	Yes
Interface to RVP	Native	-	DspExport
Processor Type	RVP8	-	-
DspExport Hostname/IP-Address	-	-	for example rvp8
DspExport Port Number	-	-	for example 30740
System transmits RTD	From RVP8	No	No
setup/RCP			
System has antenna	Yes	Yes	Yes
Main Interface to RCP	Network	None	Network
Antenna angle insertion source	Normal RCP	Native RCP8	Normal RCP

Is this the 1 controlling host	No	-	Yes
Network Multicast Address	224.0.0.3	-	224.0.0.3
Network Port Number	for example 30785	-	for example 30785
Network Interface	for example eth0	-	for example eth0
Average Network Delay	for example 0 ms	-	for example 0 ms
Receive format from RCP	for example RCV02	-	for example RCV02
Transmit format to RCP	-	-	for example XMT02
RCP8 TTY Setups "site host"			
Connection type for host computer I/O:		Network	
Multicast address:		224.0.0.3	
Port number:		30785	
Network Interface		eth0	
Data format transmitted by host		for example XMT02	
Data format received by host		for example RCV02	
DspX RVP8 Setups mc			
Live angle input - 0:None, 1:Sim, 2:TAGs, 3:S/D : 0			

13.4.2 Example: Separate RVP, Combined RCP8 and Radar Server Computer

Here, RCP8 and IRIS run on separate threads on the RCP8 platform. RCP8 has more than enough processing power to perform both tasks.



DspExport Running	Yes	No
AntExport Running	No	No
setup/RVP		
System has signal processor	Yes	Yes
Interface to RVP	Native	DspExport
Processor Type	RVP8	-
DspExport Hostname/IP-Address	-	for example rvp8
DspExport Port Number	-	for example 30740

System transmits real time display	From RVP8	No
setup/RCP		
System has antenna	Yes	Yes
Main Interface to RCP	Network	Network
Antenna angle insertion source	Normal RCP	Native RCP8
Is this the 1 controlling host	No	Yes
Network Multicast Address	224.0.0.3	224.0.0.3
Network Port Number	for example 30785	for example 30785
Network Interface	for example <code>eth0</code>	for example <code>eth0</code>
Receive format from RCP	for example <code>RCV02</code>	for example <code>RCV02</code>
Transmit format to RCP	-	for example <code>XMT02</code>
Antx RCP8 Setups "site host"		
Connection type for host computer I/O:		Network
Multicast address:		224.0.0.3
Port number:		30785
Network Interface		<code>eth0</code>
Data format transmitted by host		for example, <code>XMT02</code>
Data format received by host		for example, <code>RCV02</code>
DspX RVP8 Setups mc		
Live angle input - 0:None, 1:Sim, 2:TAGs, 3:S/D : 0		

13.4.3 Example: Combined RVP, IRIS Host

This is a special configuration and should only be used with a third party radar controller. The IRIS Host should only output **RAW** data to one other system and should not generate other products in order to keep PC motherboard and network overhead at a minimum.

RVP8 Host


DspExport Running	No
AntExport Running	No
setup/RVP	
System has signal processor	Yes
Interface to RVP	Native
Processor Type	RVP8

System transmits RTD	From RVP8
setup/RCP	
System has antenna	Yes
Main Interface to RCP	Serial
Antenna angle insertion source	Normal RCP
Is this the 1 controlling host	Yes
Main Serial Device Name	/dev/ttyS0
running at	38400 baud
with parity	none
Receive format from RCP	RCV02
Transmit format to RCP	XMT02
setup/INGEST	
Manner of Angle Acquisition	Binary
Angle Syncing	Dynamic
DspX RVP8 Setups "mc"	
Live angle input - 0:None, 1:Sim, 2:TAGs, 3:S/D : 0	

13.4.4 Example: AMR with Separate Main RCP8 and Host

This configuration is used to support Antenna Mounted Receiver (AMR) systems for which RVP is in a sealed box above the elevation axis.

Communication is using a high-speed wireless LAN. Because of the control and monitoring requirements in the AMR box, the RVP also runs an RCP8 thread for AMR.




DspExport Running	Yes	No	No
AntExport Running	No	No	No
setup/RVP			
System has signal processor	Yes	No	Yes
Interface to RVP	Native	-	DspExport
Processor Type	RVP8	-	-
DspExport Hostname/IP-Address	-	-	for example, rvp8
DspExport Port Number	-	-	for example, 30740

System transmits real time display No	No	No	From App
setup/RCP			
System has antenna	Yes	Yes	Yes
Main Interface to RCP	Network	None	Network
Antenna angle insertion source	Normal RCP	Native RCP8	Normal RCP
Is this the 1 controlling host	No	-	Yes
Network Multicast Address	224.0.0.3	-	224.0.0.3
Network Port Number	for example 30785	-	for example 30785
Network Interface	for example eth0	-	for example eth0
Average Network Delay	for example 0 ms	-	for example 0 ms
Receive format from RCP	for example RCV02	-	for example RCV02
Transmit format to RCP	-	-	for example XMT02
Antx RCP8 Setups "site host"			
Connection type for host I/O:	Network	Network	
Multicast address:	224.0.0.3	224.0.0.3	
Port number:	for example 30785	for example 30785	
Network Interface	for example eth0	for example eth0	
Data format transmitted by host	none	XMT02	
Data format received by host	none	RCV02	
Transmits Internal BITE	No	Yes (0x05)	
Transmits AUX BITE	Yes (0x02)	Yes (0x03, for AMR RCP control)	
Receives AUX BITE	Yes (0x03)	Yes (0x02, for AMR RCP status)	
Transmits Analog Q BITE	Yes (0x0F)	Yes as required	
DspX RVP8 Setups "mc"			
Live angle input - 0:None, 1:Sim, 2:TAGs, 3:S/D : 0			

13.4.5 Example: Separate RVP, RCP8, IRIS and a Remote Workstation

This configuration is useful in the case of a remote maintenance workstation that is running on a low-speed link or on a high-latency link such as a geosynchronous satellite.



DspExport Running	Yes	No	No	No
AntExport Running	No	No	Yes	No
setup/RVP				
System has signal processor	Yes	No	Yes	Yes
Interface to RVP	Native	-	DspExport	DspExport
Processor Type	RVP8	-	-	-
DspExport Hostname/IP-Address	-	-	for example rvp8	for example rvp8
DspExport Port Number	-	-	for example 30740	for example 30740
System transmits real time display	From RVP8	No	No	No
setup/RCP				
System has antenna	Yes	Yes	Yes	Yes
Main Interface to RCP	Network	None	Network	AntExport
AntExport hostname/IP-Address	-	-	-	for example iris
AntExport Port Number	-	-	-	for example 30745
Antenna angle insertion source	Normal RCP	Native RCP8	Normal RCP	Normal RCP
Is this the 1 controlling host	No	-	Yes	-
Network Multicast Address	224.0.0.3	-	224.0.0.3	-
Network Port Number	for example 30785	-	for example 30785	-
Network Interface	for example eth0	-	for example eth0	-
Average Network Delay	0 ms	-	for example 0 ms	for example, 0 ms
Receive format from RCP	for example RCV02	-	for example RCV02	-
Transmit format to RCP	-	-	for example XMT02	-
Antx RCP8 Setups "site host"				
Connection type for host computer I/O:		Network		
Multicast Address		224.0.0.3		

Port number		for example 30785		
Network interface		for example eth0		
Data format transmitted by host		for example XMT02		
Data format received by host		for example RCV02		
DspX RVP8 Setups "mc"				
Live angle input - 0:None, 1:Sim, 2:TAGs, 3:S/D : 0				

13.5 Non-Network Antenna Angles to RVP

RVP supports the following techniques for bringing-in antenna tag angles:

- Parallel binary or BCD "TAGS"
- S/D convertor
- From RVP internal simulator

For information on the **mc > Live Angle Input** question, see *RVP900 Digital Receiver and Signal Processor User Guide* .

In these selections, you must configure the **setup/RCP** section of the RVP **Setup** utility to specify the serial line input as follows:

Table 32 RCP Serial Line Input

setup/RCP	
System has antenna	Yes
Main Interface to RCP	None
Antenna angle insertion source	Native RVP8

Alternatively, use a serial line input to RVP. In this case, you must set the **mc > Live Angle Input** response to **None**. Also, you must configure the **setup/RCP** section of the RVP **Setup** utility to specify the serial line input as follows:

Table 33 RVP Serial Line Input

setup/RCP	
System has antenna	Yes
Main Interface to RCP	Serial
Antenna angle insertion source	Normal RCP

setup/RCP	
Is this the 1 controlling host	No
Main serial device name	/dev/ttyS1
Running at	19200
With parity	None
Receive format from RCP	RCV01

13.6 RCP8 on Serial Interface

The RCP is connected through a serial line directly to the host computer. The following must be configured for this:

- RCP TTY setups. See *Radar Control Processor RCP8 User Guide*
- Host computer setup/RCP configuration (for example, for IRIS)

setup/RCP	
System has antenna	..
Main Interface to RCP	Serial
Antenna angle insertion source	Normal RCP
Is this the 1 controlling host	Yes
Main serial device name	/dev/ttyS1
Running at	19200
With parity	None
Receive format from RCP	RCV02
Transmit format to RCP	XMT02

On RCP8 itself, set **Setup > RCP** set to:

setup/RCP	
System has antenna	Yes
Main Interface to RCP	None
Antenna angle insertion source	Native RCP8

For more information on setting-up a serial line interface, see *Radar Control Processor RCP8 User Guide*.

The **AntExport** utility may be run on the host computer to export control to another computer.

14. Zauto Utility

14.1 Zauto Overview

The RVP Doppler signal processors output calibrated values of the equivalent radar reflectivity factor. **Zauto** is an interactive graphic utility for calibrating the reflectivity offset of the signal processor. The results are stored in a calibration file that is loaded into the DSP for use during programmed radar data collection.

For information on the theory of signal processor calibration, see *RVP900 Digital Receiver and Signal Processor User Guide*.

To perform a calibration, a calibrated RF signal generator (siggen) must be used. **Zauto** can be used with a manually controlled siggen or a siggen controlled by the RCP. For manual operation, it is most convenient if the signal generator control can be located near the workstation where **Zauto** is run. The siggen should be configured for CW operation rather than pulse mode.

Setup allows you to input any losses that are present in the system, such as:

- Loss between the transmitter and the antenna feed
 - Loss between the antenna feed and the receiver
 - Loss between the test signal injection point and the receiver
- This must include the loss suffered in the cable that connects the siggen to the injection point, the coupler loss, and any calibration required for the signal generator.

More information

- [Zcal Overview \(page 272\)](#)

14.2 Invoking Zauto

- ▶ 1. Run the **Setup** utility.
 - a. Verify the setup information to make sure **Zauto** calibrations are accurate.
For an automatic siggen, use the **Antenna** utility to verify that the siggen is setting the correct values.
 - b. For magnetron systems, check/adjust the STALO and signal generator frequencies:
 - Set switch 2 to the A position to run the normal receiver signal into the burst channel.
 - Use RVP TTY **ps** command to plot burst frequency spectrum. Turn off AFC while you are there.
 - Set siggen frequency to an appropriate level.
 - Adjust siggen frequency until it reads out the correct IF frequency (often 30 MHz) to within 100 KHz. Alternately use MFC to adjust the STALO frequency. It is worth checking that you are not off by a multiple of 18 MHz, or on the wrong side lobe of the transmitter.
 - c. Exit **Setup**.

2. In the command line, type: **zauto&**
If needed, use one of the following options:

Option	Description
-amr	Runs the utility for Vaisala AMR calibration. You cannot use this mode with other hardware. <i>See Vaisala AMR Antenna-Mounted Receiver User Guide.</i>
-burst_pwr	
-BW_is_invPW	Optional parameters for the -cal option.
-cal	Performs an automatic calibration without displaying the zauto menu. The results are saved to the calibration file, unless there is a value outside the tolerance range. This option is available only with an automatic siggen.
-debug	Use this to debug Zauto .
-demo -demo2	Runs the utility without the signal processor, for testing and demonstration purposes.
-pol H or V	Forces polarization to horizontal or vertical in Zauto startup.
-pw_idx 1 - 4	Select the pulse width index used for defining the pulse width for automatic calibration.
-display display_name	

3. For magnetron systems, when you are done with **Zauto**, recheck the frequency for drift.

14.3 Zauto Menu





Figure 51 Zauto Utility

- Calibration Parameters**
Displays calibration parameters defined with the **Setup** utility.
- Calibration Plot**
Displays a plot of the IF measured power against the signal generator setting.
- Calibrate Pane**
Lets you control the calibration using the fields and buttons in this pane.
- Results Pane**
Shows the temporary calibration information, such as the current noise and Zcal values for the specified pulse width.

14.3.1 Calibration Parameters



All of the calibration parameters are taken from the **Setup** utility, and they serve as a check that **Setup** was properly configured.


If you see an error in these parameters, exit the **Zauto** utility, and correct the error in **Setup** before attempting a calibration. Otherwise, the calibration will be incorrect.

The following **Setup** parameters are displayed:

- Radar wavelength (cm)
- Transmit power (kW)
- Digital filter loss at calibration (dB)
- Horizontal and vertical beam width (degrees)
- Antenna gain (dB)
- Burst power at calibration (dBm)
- Transmit loss (dB)
- Receive loss (dB)
- Siggen loss (dB)

These values remain fixed throughout the **Zauto** procedure.

14.3.2 Zauto Calibration Plot



Zauto displays a plot of the IF power in dBm against the signal generator setting, similar to the plot shown in the reflectivity calibration section of *RVP900 Digital Receiver and Signal Processor User Guide*.

Here, the horizontal axis of the plot is the input signal power at the antenna, which accounts for antenna-to-receiver loss and signal generator loss.

Zauto corrects for these effects, based on the setup information. In performing the calibration, it displays the signal generator value on the horizontal axis.

Left and Right Plot Limits

Plot range fields at the lower left and right of the calibration plot define the lower and upper limits, in dB, of the signals to be generated.

You can change the limits, and **Zauto** rescales the plot for the new range.

Zauto does not allow a new range limit when there would be data points outside the range.

Left and Right Fit Limits

Vertical red lines mark the limits of the least squares fit. They can be moved independently by pointing with the mouse on the graph and clicking the left mouse button.

If the fit limits lie outside the plot range, they are shown as colored lines at the corresponding edge of the graph. The default limits are taken from the calibration configuration settings. See [Defining Zauto Configuration Parameters \(page 261\)](#). Usually, the fit limits are set after a number of points have been plotted and before doing a least squares fit.

You should set the limits so that the fit is made to the linear portion of the plot, typically 15 dB above noise to the saturation point of the LOG receiver. Points that lie outside the fit limits are displayed in red to show that they are not be included in the next fit. The limits can be reset and another least squares fit performed to fine tune the plotted line. When the limits are changed, the last fit and noise lines are removed, along with the appropriate information in the results display.

Plot Points

Plot points are the dots that mark the strength of the signal sampled at a number of specified settings. A black box is drawn about the low and high point used to calculate the dynamic range.

Fit Line

Shows the least squares fit of the plot points that fall within the fit limits.

Noise Level Line

The noise level line is a horizontal line drawn when the siggen is not generating a signal.

14.3.3 Calibrate Pane

Pulse Width

Begins a new calibration at the specified pulse width, which you select from a menu. When you switch to a new pulse width, any prior data points and temporary results are discarded. **Zauto** lets you choose whether you want to save the calibration.

Polarization

On dual polarization radars, calibration must be performed separately for each polarization channel. Do not change this for other radars, as changing the polarization erases the current calibration points.

Delete

Select **Delete** to delete the last calibration point. Select **Delete** many times to delete successive points, in reverse order.

Noise

Select **Noise** to take a noise sample and plots the result. The noise sample must be taken after the least squares fit is done. For a manual siggen, you must turn the siggen to its lowest setting or disconnect it before taking a noise sample. **Zauto** does this automatically when the siggen is controlled by the RCI.

When you take the noise sample, a red line is drawn at the A/D noise level. If the noise level is outside the range of 10 to 30 A/D units, align the LOG channel A/D converter by adjusting the appropriate offset pot on the DSP. This can be done using the Ascope utility. Make sure that the A/D converter gain has been adjusted as well.

Sample

Select **Sample** to generate and plot the specified test signal. In the field to the right of this button, you enter the desired siggen setting in dBm. For a manual siggen, you must set the siggen to match this setting. **Zauto** measures the power at IF, and plots the point on the calibration graph.

The siggen setting can be entered in one of the following ways:

- Type a number directly into the field.
- Move the slider within the sliding scale until the desired value is displayed in the field.
- Click inside the scale to move the slider in steps. The size of the step is defined in the AutoCal Configuration menu (see below).

Siggen ON/OFF

Use this button to toggle the siggen off before taking a noise sample, then toggle it on again.

ID

Identify which siggen is used in the calibration. This is helpful in the future when you want to compare new results to old calibration files.

Fit

Select **Fit** to cause **Zauto** to perform a least squares fit to the data points that lie within the specified range limits. The resulting line is drawn on the calibration plot. At least two points are needed. The Results display shows the slope and intercept values for the line.

The fit is a straight line. The fit range limits should be set so that only the points in the linear region of the calibration curve are included. The signal processor corrects for the curved portion of the calibration, which corresponds to weak signals.

Automatic Calibration

Automatic calibration is available only if you have an automatic siggen.

Select **AutoCal** to generate a series of signals (beginning at the high end, ending at the low end) and plots them on the graph. When it is finished, a noise sample is taken and a least squares fit of the data points is taken. The calibration is then saved. See [Defining Zauto Configuration Parameters \(page 261\)](#).

14.3.4 Defining Zauto Configuration Parameters

The Zauto Config dialog box is titled "Zauto Config" and contains a "Configuration" section. The parameters are organized into three main groups:

- Cal Pulse Width**: 0.8
- Polarization**: Horiz
- Update other PW**: Yes

Below these are three rows of limits, each with two input fields:

- IF Power Plot Limits**: -100, 10
- Sig Gen Plot Limits**: -100, 15
- Sig Gen Fit Limits**: -72, 0

Next are three rows of ranges, each with two input fields and a "Step" input field:

- Sig Gen Lower Range**: -100, -85, Step 1
- Sig Gen Center Range**: -85, 5, Step 10
- Sig Gen Upper Range**: 5, 10, Step 1

Finally, there are three tolerance parameters, each with one input field:

- Slope Tolerance %**: 80
- dBZo Tolerance %**: 80
- Range Tolerance dBm**: 10

At the bottom of the dialog are four buttons: **Save Config** (highlighted with a double border), **Ok**, **Apply**, and **Cancel**.

1. Select **Config**.

2. Define the automatic calibration procedure parameters:

Cal Pulse Width

Select the pulse width to be calibrated automatically.

Update other PW

As an alternative to recalibrating for each pulse width, choose **Yes** to copy the results of a calibration at one pulse width to other pulse widths, scaled by the different radar constants for the 2 pulse widths. For the most accurate results, however, the radar should be re-calibrated at each pulse width.

Polarization

Only to be changed for dual polarization radars.

IF Power Plot Limits

The range of measured signal plotted on vertical axis.

Sig Gen Plot Limits

The range of signals to be plotted on horizontal axis.

Sig Gen Fit Limits

The range to be included in the least squares fit.

Siggen Steps

This controls interval between generated signals. We may want to fine steps at the 2 roll-off regions in order to get an accurate measure of the dynamic range. Thus you can enter steps for 3 different power ranges.

Slope and dBZo Tolerance %

These are positive integers between 1 and 100, used for the comparison with the reference calibration information during an automatic calibration. If the new calibration differs by more than these percentages, AutoCal does not update the calibration.

Range Tolerance dBm

If the dynamic range changes by more than this value, alert and do not update.

3. Select **Apply** and **Save Config**.

14.3.5 Zauto Results

Results	
Update	View Cal
Rad Const dB	74.20
Slope	1.0014
Noise dBm	-90.86
Io dB	-137.57
ZCAL dB	-63.37
Fit SD	0.09
Dynamic Range	103.00

The **Results** pane shows the temporary calibration information such as the current slope and dBZ or Zcal values for the specified pulse width. These values apply to the most recent squares fit and noise sample. This pane is updated every time a new noise level is taken, or any time the data used for linear fit changes.

Update

Select **Update** to store the current calibration for the selected pulse width. The slope result is copied regardless of pulse width. The calibration reflectivity is copied over for the specified pulse width.

Radar Constant

Displays the calculated radar constant. See *RVP900 Digital Receiver and Signal Processor User Guide*.

Slope

Displays the slope of the straight line fit to the data values in dB per machine number (A/D value) The slope should be close to 1. Less than 1.02 is a reasonable threshold. If a reasonable value is not acquired, adjust the fit range limits.

Noise

Displays the noise level in dBm.

Io

Displays the calibration intercept.

ZCAL

Displays the Zcal value computed from the radar equation. See dBZo in *RVP900 Digital Receiver and Signal Processor User Guide*.

Fit SD

Displays the standard deviation on the least squares fit in dB. This should be under 1 for a good fit. If a reasonable value is not acquired, adjust the fit range limits.

Dynamic Range

Displays the dynamic range of the processor at this pulse width. The dynamic range is defined as the difference in input signal power between a signal measuring at least 1 dB above the noise level, and a signal which is starting to saturate the receiver such that we have 1 dB roll off from the idealized linear fit.

View Calibration

Select **View Calibration** to show a list of current results, the last results saved to a file, and the reference calibration set by the **Zcal** utility.

Select **Exit** to close the window.

The screenshot shows a window titled "View Calibration" with a close button (X) in the top right corner. Below the title bar is a subtitle "Summary of dBZo and Slope Values". There are two dropdown menus: "Pulse Width" set to "1.0" and "Polarization" set to "Horiz". The main area contains a table with four columns: "New Results", "Stored", and "Reference". The table lists various calibration parameters and their values. At the bottom of the table area, it says "File/Save, will store the New Results." and there is an "Exit" button.

	New Results	Stored	Reference
Cal dBZ	-57.97	-57.97	-0.06
Slope	1.0075	1.0075	1.0090
Noise dBm	-90.00	-90.00	-90.00
IO dB	-130.94	-130.94	-68.88
Fit SD	0.12	0.12	0.13
Constant	72.97	72.97	-----
XMT Power	100.00	100.00	-----
Burst Power	1.00	1.00	-----
Noise Equiv BW	1.11	1.11	nan
Dynamic Rng	-----	nan	91.00
Siggen Noise	-80.00	-80.00	-74.00
Siggen Sat	-----	nan	17.00
Sat Level	-10.41	-10.41	-1.76
Cal Time	11:23:00	11:39:29	15:37:31
Cal Date	5 Aug 2020	4 Aug 2020	31 Oct 2006
Siggen ID	1039.2000	1039.2000	1039.2000
Siggen Date	31 Oct 2006	31 Oct 2006	31 Oct 2006

File/Save, will store the New Results.

Exit

14.4 Zauto Commands

The **Zauto** utility provides the following commands:

File

Save writes the calibration information to a file.

Print creates an X-window dump of the menu you are running, as follows:

- **Print > to Printer** sends the output to the postscript or color printer specified in the **Printer Setup** menu.
- **Print > to File** sends the output to a file in your default home directory.
- **Print > Setup** lets you configure the printer on your system.

Exit exits the utility.

Calibration information is stored in the *config* directory in a file called *zcalib.conf*. You are prompted to save the file before you exit from the utility.

Help

On Utility displays information about the utility.

Contents and **Index** provide access to the online help.

14.5 Manually Calibrating Signal Processor



For manual siggen control, it is best if the control for the signal generator and the workstation are located next to each other. Otherwise, 2 people and some coordination are required to perform a calibration.



CAUTION! The sensitivity and dynamic range of the radar can be affected by the gain of the IF signal entering the IFD. First adjust the IF signal level (see the test procedure in *RVP900 Digital Receiver and Signal Processor User Guide*).

To protect the signal generator, the radar is not usually set to transmit during calibration. Check with your manufacturer. If it is OK to transmit while the siggen is connected, it better simulates operating conditions. If transmitting is not recommended, turn everything on, but do not set the transmitter. This assures that all sources of noise are accounted for.

1. Set the antenna elevation greater than 20° to reduce the effect of earth temperature noise which is detectable by modern, sensitive receivers.
If you are transmitting, this eliminates the possibility of weather signals interfering with the calibration.
2. Check that the signal generator is set for the CW (continuous wave) operation and not for pulse mode operation.
3. Select a pulse width.
Note that the pulse width lines of the DSP issue the appropriate signal. If this control is implemented on your system through the antenna controller, it is set correctly.

4. Set the plot range limits.
If you do not know what limits to set, use the system defaults. You can adjust them later without losing data.
5. Collect the plot points for the calibration:
 - a. Enter the siggen value in the unlabeled field next to **Sample**. You can use the slide bar.
 - b. If the siggen is not controlled by the RCI, set the signal generator output to match the specified value. Otherwise, this is done for you.
 - c. Select **Sample**.
Zauto draws the point on the calibration plot

Repeat these steps until you have collected a sufficient number of points (for example, 6 points in the linear range of the curve). If you make a mistake, select **Delete** to remove the point or reset the pulse width and start again.
6. After you have collected the points, set the plot limits to include only those points in the linear range.
7. Turn down or disconnect the signal generator and select **Noise**.
A horizontal line is drawn at the average noise level.
8. Select **Fit**.
Check the line and results to make sure they are reasonable.
Reset the limits or collect more data as required to get a representative fit to the straight line portion of the curve (typically from 15 dB above noise to 70 dB above noise).
The calibration results are filled in each time you select **Fit**.
9. When you are satisfied with the calibration, select **Update** to update the **View Calibration** display.
You can use results from one pulse width to update other pulse widths. However, for the most accurate results, you should perform a separate calibration for each pulse width.
Errors are likely to be less than 3 dB if the update technique is used.
10. Move on to the next pulse width, if necessary, starting with [step 3](#).
11. When you are finished, check that the **View Calibration** display shows the values that you want to save.
12. Select **File > Save** and then **File > Exit**.



You can also modify the calibration file, using the **Zcal** utility to enter the calibration reflectivity by hand.
You typically use the **Zcal** for testing or after a component has been replaced by another with known calibration.

14.6 Automatically Calibrating the Signal Processor

The **Zauto** utility can automatically calibrate the signal processor output, from either:

- **Zauto** utility
If you perform the automatic calibration from the utility, **Zauto** plots each point on the graph and draws the least squares fit and noise sample lines on the display.
- Command line
If you perform the calibration from the command line, **Zauto** displays a series of messages indicating each siggen setting and DSP value.

In both cases, the new slope is calibrated, and the results are saved in the calibration file.

Zauto uses the reference information from the calibration file to determine whether to accept the new calibration information. If the new calibration deviates too much from the reference settings, it is not used. This prevents loss of data if the signal generator should fail.



You can change the reference calibration information with the **Zcal** utility.

- ▶ 1. Select **Zauto > Config**.
The **AutoCal Config** menu appears.
2. In the **AutoCal Config** menu, choose the pulse width for the calibration, the siggen (signal generator) step, and other calibration parameters.
3. Use the **Slope Tolerance %** and the **dBZo Tolerance %** fields to define the permitted deviation between the reference information and the new calibration.
A higher percentage allows for a larger deviation, with 100% allowing any results to replace the old calibration values.
4. Select **Save Config**.


14.6.1 Calibrating the Signal Processor from Zauto



1. Select **AutoCal**.

Zauto checks a series of signal values and plots the points.

If the new results deviate too far from the old results, **Zauto** displays the message:



2. For each message, choose to either update the calibration file or reject the new calibration information.

14.6.2 Calibrating the Signal Processor from the Command Line

1. In the terminal window, type: **zauto -cal**
The utility displays a series of messages indicating the siggen (signal generator) values and DSP values used in the calibration, such as the following:

Setting	-110.00	DSP Val	25.00
Setting	-105.00	DSP Val	37.50
Setting	-100.00	DSP Val	50.00
Setting	-95.00	DSP Val	62.50
Setting	-90.00	DSP Val	75.00
Setting	-85.00	DSP Val	87.50
Setting	-80.00	DSP Val	100.00
Setting	-75.00	DSP Val	112.50
Setting	-70.00	DSP Val	125.00
Setting	-65.00	DSP Val	137.50
Setting	-60.00	DSP Val	150.00
Setting	-55.00	DSP Val	162.50
Setting	-50.00	DSP Val	175.00
Setting	-45.00	DSP Val	187.50
Setting	-40.00	DSP Val	200.00
Setting	-35.00	DSP Val	212.50
Setting	-30.00	DSP Val	225.00
Setting	-25.00	DSP Val	237.50
Setting	-20.00	DSP Val	250.00
Setting	-15.00	DSP Val	262.50
Setting	-10.00	DSP Val	275.00
Setting	-5.00	DSP Val	287.50
Setting	0.00	DSP Val	300.00
Setting	5.00	DSP Val	312.50
Setting	10.00	DSP Val	325.00

Slope New: 0.4000 Ref: 0.4400

Reflectivity Pulse Width:0.5 New:-39.4354 Ref:-20.5000
file saved

2. If the new values deviate too far from the reference information, the file is not saved. To accept the new values:
 - a. Run **Zauto**.
 - b. In the **AutoCal Config** menu, change the tolerance fields.
 - c. Rerun the utility

14.7 Siggen Calibration File

The **Zauto** utility can read a calibration file containing information on the power level for each nominal setting of the signal generator. This provides an accurate calibration of an automatic signal generator that is controlled by IRIS.

For example, a requested value of -30 dBm may actually be -30.2 dBm.

The **Zauto** calibration display shows the nominal requested setting and the calibrated value (with a resolution of 0.1 dB).

You can create the calibration file through a calibration program or typed in an editor. The file is *SIGGEN_CAL.DAT* in the *IRIS_CONFIG* directory (for example, */usr/sigmet/config*).



For manual calibration with a calibrated signal generator you do not typically need this feature.

The following is a partial example.

```
#  
# First set the date of the calibration in the following format  
# Note the D in Date is capitalized.
```

```
Date: 10:15:00 20 OCT 1995
```

```
#  
# Next the signal generator ID string  
#
```

```
ID: XX aaa_BBB-CCC
```

```
#
# Now include a table of the integer nominal siggen values
# followed by the calibrated value as a floating point value.
# Start with the largest value.
#

0 0.1
-1 -1.1
-2 -2.1
-3 -3.1
-4 -4.1
-5 -5.1
-6 -6.1
-7 -7.1
-8 -8.1
-9 -9.1
-10 -10.1
-11 -11.1
-12 -12.1
-13 -13.1
-14 -14.1
-15 -15.1
-16 -16.1
-17 -17.1
-18 -18.1
-19 -19.1
.
.
.
```

Siggen Data Handling

Only the 128 dB span immediately below the first entry in the file is used. All values outside this range and all missing values are treated as correctly calibrated.

If the file is missing, then all values are treated as correctly calibrated, and the ID string is set to **No siggen file**.

If the file exists, but does not contain an ID string, the ID string is set to **No ID in file**.

The ID and date are displayed in the **Zcal** utility.

15. Zcal Utility

15.1 Zcal Overview

Use the **Zcal** utility as an alternative to the **Zauto** utility to display and enter reflectivity calibration numbers in the calibration file when:

- First setting up a system, before final calibration.
- Resetting reference calibration information.
Reference information is applicable only on systems that automatically run calibration. If a new calibration deviates too much from the reference, it is not used. This prevents loss of data if the signal generator fails.

Zcal does not have a graphical interface. There are separate calibrations for each pulse width and polarization as applicable.

For information on the reflectivity channel calculations, see *RVP900 Digital Receiver and Signal Processor User Guide*.

More information

- [Zauto Overview \(page 254\)](#)

15.2 Invoking Zcal

- ▶ 1. To invoke **Zcal**, on the command line type: **zcal**

15.3 Zcal Commands

Zcal displays the stored and reference calibration information for each pulse width, then prompts you to enter a command.

The number of pulse widths may vary, depending on your system.

For a large number of pulse widths, use a large width terminal window.

All dates shown are in local time as configured on your computer.

```

----- Horizontal Calibration -----
          Sto 1.0us   Ref 1.0us
Fit Slope:      1.1838      1.1838      dB/dB
Cal:            -34.51      -34.51      dBZ
Std Dev:        0.00        0.00
Noise Level:    -93.11      -93.11      dBm
I0:             -57.66      -57.66      dB
Constant:       68.84       68.84      dB
XMT Power:      200.00      200.00      KW
Burst Power:    -10.10      -10.00      dBm
Dynamic Rng:    nan        nan        dB
Siggen Low:     -34.00      -34.00      dBm
Siggen High:    nan        nan        dBm
IF at Low:      -86.74      -86.74      dBm
IF at High:     nan        nan        dBm
IF Maximum:     -50.42      -50.42      dBm
Flag:           0          0
Cal Time:       12:27:21    12:27:21
Cal Date:       24 OCT 2002 24 OCT 2001
Siggen Date:    24 OCT 2012 24 OCT 2012
Siggen ID:      189-111    189-111

          Current Siggen ID: 189-111
          Current Siggen cal date: 24 OCT 2012
          ZCAL command (? for help):

```

The following table lists the commands that you can enter at the prompt.

Table 34 Zcal Commands

Command	Description
Cal	Enter a new calibration reflectivity
ID	Set siggen ID
List	Print out current numbers on terminal
Polar	Switch between horizontal and vertical polarization
Quit	Quit
Refer	Set reference to Stored values
Write	Write calibration file
?	Print help

15.4 Changing Calibration Reflectivity

- ▶ 1. In the command prompt, type **cal**
Zcal displays the prompt:

```
Enter pulse width (choices 1):
```

- 2. Enter the pulse width in microseconds (for example, 1, 1.0, 1.00).
Zcal displays the prompt:

```
Enter new cal reflectivity (old was -34.51):
```

- 3. Enter the calibration reflectivity (dBZ₀) in dB.
Typically this is a negative dB number, such as -35, which corresponds to the minimum detectable dBZ at 1 km (0.6 mi).
Zcal displays the prompt:

```
Enter new cal noise (old was -93.11, nan for none):
```

- 4. Enter the new value for the calibration-time noise level.
If you do not know this number, you enter **nan** (short for "Not a Number"). This disables the feature for adjusting the calibration if the noise level changes from that observed at calibration time.

Zcal redisplay the calibration information, showing the new calibration reflectivity and noise that you entered.

15.4.1 Changing Reference Values

Issue this command when you are happy with the current calibration.

IRIS/Open always uses the current calibration when configuring the DSP. It uses the reference calibration only when performing an automatic calibration. If the new calibration deviates too much from the reference, it is not used.

- ▶ 1. In the command prompt, type: **refer**
Zcal copies the current calibration to the reference calibration and redisplay the calibration information with the new reference information settings.

15.4.2 Writing the Calibration File

- ▶ 1. In the command prompt, type: **write**
Zcal writes the calibration information to the file, then prints the message:

```
File updated successfully.
```

15.4.3 Switching Polarizations

Zcal displays information for only one polarization at a time.

If your radar can transmit in either horizontal or vertical polarization, you can calibrate both channels in **Zauto**.

- ▶ 1. To switch the displayed polarization is display, type: **polar**

16. Zdrca Utility

16.1 ZDR Measurement

The differential reflectivity (ZDR) is a relative power measurement of the signals acquired in the horizontally and vertically polarized channels in the polarimetric weather radar.

ZDR measurement accuracy must be at the level of 0.1 dB for applications of quantitative rainfall and echo identification. Such accuracies are challenging if pursued through absolute power calibrations of each radar channel independently. Accounting for this, RDA calculates the differential reflectivity independent of the reflectivity dBZ, and the related calibration coefficients, while a tunable offset parameter is reserved to maintain the balance of the ZDR calibration, explicitly.

Depending on the radar system stability, regular and semi-continuous monitoring of the ZDR calibration and occasional update of the offset parameter are necessary to maintain an accurate ZDR calibration.

It is operationally feasible to maintain the relative power balance of two radar channels at sub-decibel accuracy, by using the external 0 dB reference defined by the atmospheric echo inputs that are averaged over rapid full rotations of the vertically pointing antenna ("bird bath" scans).¹⁾

16.2 Zdrca Utility Overview

The **Zdrca** utility:

- Performs sequences of vertical scan measurements, accumulates and analyzes qualified data for monitoring the radar ZDR calibration.
The utility is configured to trigger a message for operator attention when the sampled data allows it to conclude that the radar ZDR calibration has drifted beyond a user configurable threshold for alarm.
- Reports calibration data at a precision which keeps the false alarm rate below 5 %.
To establish this, the data samples are collected long enough to meet the configured precision. The run durations can be steered in part by the task parameters, while the actual total sample lengths adapt to variable atmospheric conditions. The lengths may vary from a single full sweep (in case of significant precipitation at the radar) up to a configurable upper time limit.
- Provides a tool for responding to the utility alarm and updating the radar ZDR offset parameter from the specified previous results.
The update action implies that the subsequent ZDR observations of isotropic scatterers are adjusted to 0 dB, which is the goal of ZDR calibration. The action has minimal inference with normal radar operation, as restart of IRIS/RDA processes is not needed.

1) J.J. Gourley, P. Tabry, J. Parent du Chatele, 2006: Data Quality of the Meteo-France C-Band Polarimetric Radar, *Journal of Atmospheric and Oceanic Technology*, Vol. 23, pp. 1340–1356 and R. Keränen, P. Puhakka, and H. Pohjola, 2008: Multi season characteristics of the channel power balance at a polarimetric weather radar, *5th European Conf. on Radar in Meteorology and Hydrology*, Helsinki, Finland

Zdrca distributed with RDA and IRIS, and works with RVP signal processors and any antenna controller accessible through the antenna library, at polarimetric weather radars.

Running Zdrca

Zdrca is designed to run either as a stand-alone non-graphic utility, or as part of IRIS scheduler (as an IRIS Exec Task).

In both modes, **Zdrca** reports its progress, processing, and result quality into an output stream which is routed either to the terminal window, or into the **zdrca** log history file `$IRIS_LOG/zdrca.log`.

Zdrca RAW Products

For each completed task, the **Zdrca** utility outputs a **RAW** product, to serve as a reference for detailed quality checks and to allow for (off-site) post-processing, which is equivalent to the run-time analysis.

The **Zdrca** RAW products are composed of one or up to forty full rotations of vertical sweeps.

You can use the **productx** utility to view the **RAW** headers for the full information of the radar settings during the calibration task.

The data records contain the differential reflectivity ZDR, accompanied by the standard moments **dBZ**, **V**, spectrum width (**W**), and the co-polar correlation coefficient **RhoHV**, which are used in **Zdrca** specific quality considerations and as input to sampling uncertainty estimates in analysis. Through reingest of the **Zdrca RAW** products in IRIS, the data are available for graphical viewing (**Quick Look Window**, or standard IRIS products).

The measured data, used in **Zdrca** analysis, are subject to standard RDA quality thresholding (**LOG**, **CCR**, **SQI**, **SIG**) with configurable settings for typical operational tasks.

By default, the **Zdrca RAW** products are not inserted in IRIS product inventory (`$IRIS_PRODUCT_RAW`). You can configure them to be added by activating an input pipe.

16.2.1 How Zdrca Works

The **zdrca** data acquisition step resembles that of the **Suncal** utility, except that a **PPI** task consisting of one or more full rotations of the antenna is acquired, instead of automated sector scan around the anticipated sun position.

The **zdrca** task is similar to a standard **PPI** task, except that all elevations are in the vertical position. The data outcome of the vertical scans are formatted as **RAW** product files for subsequent analysis.

The **zdrca** data analysis step consists of retrieval of the **RAW** product containing the ZDR data fields subject to configurable IRIS/RDA quality thresholding, supplemented with standard moment data of reflectivity **dBZ**, Doppler velocity (**V**) and spectrum width (**W**). The data of co-polar correlation coefficient **RhoHV** completes the input to estimate ZDR offsets and associated uncertainties reported as dedicated result files.

Auxiliary Variables

Uses of the auxiliary variables **dBZ**, **V**, **W**, and **RhoHV** include:

- **zdrca1**-specific quality criteria are applied gate-to-gate, to enhance the echoes of atmospheric scatterers in the ZDR data sample.
The ground clutter residuals which may remain after Doppler filtering, and other spurious signals such as radio frequency interference, and macroscopic object echoes are diminished.
- The expected variances of ZDR data values are computed as gate-to-gate sampling variations, by referencing the ZDR distribution as echoes from continuous precipitation in the sampling volume.²⁾

ZDR Offsets Estimates

The ZDR offsets estimates are weighted medians of the qualified ZDR data points, checked for consistency with a maximum probability estimator of the same data set.

The check rejects estimates that appear disturbed by excessive non-Gaussian tails or other asymmetries biasing the median estimator from the most plausible ZDR offset value.

The weighting is based on expected gate-to-gate ZDR variances. Data points of high co-polar correlation and large spectral width are favored, which associate with narrowly distributed ZDR data. The weighting approach is statistically optimal in the sense that it maximizes the precision of the ZDR offset estimates, given variable input quality.

The ZDR offsets estimates are reported with estimates of uncertainty, which are derived from actual observed distributions of the ZDR data sample. Also, the input distributions are characterized in terms of expected and actually observed widths, allowing easy quality control. All estimates of uncertainty are expressed at 68 % confidence level ("one sigma" uncertainties, equivalent to root means square widths RMS of normally distributed data).

Post-processing

The **zdrca1 -process: file** triggers a post-processing mode of **zdrca1** analysis using an existing **zdrca1 RAW** product. The **RAW** product resides in the directory specified in the **zdrca1.conf** file.

The outcome of post processing is equivalent to the run-time result, pending the conditions that the **RAW** data are appended on the same ZDR history sample, and that the same **zdrca1** analysis settings are configured.



This option is not used at most operational radars.

This command mode is useful for general quality control for example the effects of variations in quality criteria can be studied. The option allows for monitoring ZDRCAL calibration remotely for example at analysis centers of a radar network. Note that the **RAW** product does not need to originate from another **Zdrca1** utility run, but can be a standard IRIS **RAW** product, with requirement that the specified data **dBZ**, **V**, **W**, **ZDR**, **RhoHV** are available (and only those data fields).

2) The formalism in reference V.N. Bringi and V. Chandrasekar, 2001: *Polarimetric Doppler Weather Radar, Principles and Applications*, 2001. 636 pp. Cambridge University Press is applied.

16.2.2 Typical Use Cases

Moderate Accuracy with High Data Availability in Stable Radar Operation

The default **ZdrCAL** configuration settings aim at moderate accuracy (warning threshold at 0.3 dB) with high data availability in stable radar operation (integration limited to 4 days, maximum).

The vertical task consists of a single sweep intended for regular repetition as part of the radar scheduler, once in an hour for example.

Initial ZDR Offset Estimation During Radar Commissioning and Start-up

Typically, a first estimate of ZDR offset is checked to confirm the radar system state.

An adequate precision suffices (warning threshold 0.4 ... 0.5 dB). The radar can be allocated full-time to **ZdrCAL** runs, for limited time.

Operation can be interactive, typically. In this case the utility can be configured to make several sweeps, each run.

At fair weather, you can increase the number of sweeps (max 40 sweeps).

You can set the **TASK Scheduler** to run **ZdrCAL**, continuously, to collect as much observations as possible, in a limited time.

High accuracy monitoring in stable radar system

Having obtained good knowledge of the proper settings and stability of the ZDR offset, you can configure the stability of the radar, **ZdrCAL** to high accuracy and to very low false alarm rate, with some compromise on monitoring temporal coverage. To this end, it is recommended to:

- Tighten the quality thresholds (LOG, CCR, SQI, SIG)
- Apply harder Doppler filtering and tighten **ZdrCAL** specific quality criteria (raise **RhoHV** threshold, require more qualified gates in each ray)
- Discard incomplete sweeps at high percentage.

Eventually, the utility can be limited to run adaptively to selected weather cases (precipitation on radar) using the mode switching feature of IRIS.

16.3 Running **ZdrCAL** from a Command Line



Operating a radar interactively through command line **ZdrCAL** requires the DSP and antenna to be available.
If DSP is reserved for other use, a message `<Export channel is busy>` is generated.
Also, the ingest process must be switched off in IRIS. IRIS can stay on.

- 1. To invoke **Zdrca1** from the command line, type: **\$ zdrca1**
If needed, add an extra operator

Zdrca1 Operators	Description
-auto	Do scan and process phases, but skip the interactive update and do not log progress on the terminal. This is meant to be run from a scripting environment. Warnings are reported out on the error output
-full	Does full scan, process and update phases. Same as -auto followed by -update , except you get progress reports on the terminal. Note that the update step uses the latest Zdrca1 result file available, that is, the update can proceed even if there are no new results. This is the default behavior if no command line option is given.
-help	Prints a version of this table.
-process:<path>	Triggers a post-processing mode of zdrca1 analysis using an existing Zdrca1 RAW product.
-resave	Reads and saves the zdrca1.conf file with comments and all new fields filled with default values. See Zdrca1 Configuration File (page 282) If zdrca1.conf is missing, the utility uses default settings. . Run the Zdrca1 utility with the -resave option to read in the old zdrca1.conf file, fill in all new fields of current IRIS/RDA version with default values, and write out the file including updated comments. You can run zdrca1 -resave to create a fresh default file by removing the existing file first. It is a good idea to run the -resave option when you first use Zdrca1 after an IRIS/RDA upgrade to see new features.
-update[:<file>]	This triggers an interactive update of the current radar ZDR offset using the latest Zdrca1 result file available for the current radar site. Specify a file name to select a desired (older) result. The specified file resides in the configured Zdrca1 directory and cannot to originate in data ingested at other radar.
-version	Prints the version number.

16.4 Running Zdrca1 as an IRIS Exec Task

Running **Zdrca1** as part of the standard scheduler allows the ZDR calibration status to be routinely monitored without operator interaction.

When **Zdrca1** is added the IRIS **Task Scheduler** as an Exec Task, it runs routinely either at regularly scheduled times, or it can be set to run at specified weather events, in which a IRIS mode switch is triggered by **WARN** products.




Figure 52 ZdrCAL Exec Task

1. To run **ZdrCAL** as an IRIS Exec task, type:

```
zdrCAL -auto 2 > &1 | signal_iris
```

-auto

Sends the progress report output to a terminal. The utility performs the data acquisition and analysis part in **-auto** mode, that is the calibration status is monitored, not updated.

2 > &1 | signal_iris

Reroute the utility warnings to IRIS message log and popup, including the warning issued if the calibration offset drifts beyond the specified alarm threshold.

16.5 Using ZdrCAL Results

The **ZdrCAL** ZDR offset estimates are reported in result files **.zdrCAL_results*.

You can use these files to help maintain an accurate radar system level calibration of differential reflectivity ZDR.

1. To respond to an alarm about a significant deviation of the ZDR offset observed from the current radar setting, check the **ZdrCAL** result file associated with the warning in the configured **ZdrCAL** result directory.
To find the file, check the warning date and time in the result file name (typically, the file is the most recent one) If more recent result files have been generated, the recommended procedure is to inspect the later evolution of the offset estimate and judge the most likely current and future stable setting.

2. To view the most likely offset estimate:
 - a. In most cases, the most recent result file carries the most likely offset estimate. Retrieve the latest **Zdrcal** result by typing: **zdrcal -update**
To specify an earlier result file, type:
zdrcal -update:XXXyymmddHHMMSS.zdrcal_results
Zdrcal looks for the most recent **.zdrcal_results* file in the directory configured in **Zdrcal** (See [Zdrcal Configuration File \(page 282\)](#)).
When it has retrieved the result information, **Zdrcal** inspects the result quality, including:
 - Internal consistency of the estimate
 - Consistency of the radar site and data time span with respect to the current site and time
 - Whether the current ZDR offset setting is consistent with the setting used during the data sampling
 - Whether the result deviates from the configured alarm, significantly
 - b. When prompted, define how the utility should proceed (that is continue the update process, or terminate it).
If you continue the update process, the utility updates the current radar settings in the signal processor, as well as updates the radar setup files to guarantee the continued use of the new setting after restart of IRIS/RDA processes.



You may also want to perform this task to verify the results of running **Zdrcal**.

16.6 Zdrcal Configuration File

The **Zdrcal** utility uses information retrieved in the *zdrcal.conf* file, which is in the `{IRIS_CONFIG}` directory.

You can adjust the local configuration by editing this file with a text editor such as **gedit** to:

- Re-specify the main parameters of the monitor accuracy and the maximum time span of the sample sequence.
- Specify details of the scanning strategy, **Zdrcal**-specific quality criteria, and data output directories, and control the log files.

Version Information

Do not modify the version information at the start of the **Zdrcal** configuration file.

The default technical settings for **Zdrcal** logging at `$IRIS_LOG/zdrcal.log` are recommended, particularly in the introductory phase.

Note that the **Zdrcal** utility appends consecutive run logs in *zdrcal.log*. In longer runs, it is recommended to rename the log file from time to time.

```
# ZDR CAL version. Log settings
zdrCAL.sVersion = "8.12"
zdrCAL.sLogToFile = "YES"
zdrCAL.sLogToTerm = "NO"
```

Threshold for ZDR Offset Warning

The primary configurable parameter of **ZdrCAL** is the threshold for user warning about a significant deviation of the observed ZDR offset from the current radar setting. The max time span prevents **ZdrCAL** accumulating data unreasonably long.

In field tests, the utility analysis has been found robust up to several days of integration (hourly sampling).

```
# Threshold for ZDR offset warning (dB).
zdrCAL.fThresholdForAlarm_dB = 0.3

# ZDR CAL run duration will be adjusted, accordingly,
# in order to keep false alarm rates below 5% (ZDR CAL_FAR_CL).
# ZDR CAL run will be limited to a max time span (hours), however.

zdrCAL.fMaxTimeSpan_hours = 96
```

Task Parameters

The relevant **ZdrCAL** task parameters are configurable.

With all the radar task settings, keep within the site specific hardware limitations, listed in the **Setup** menu, **RVP** section.

The maximum number of sweeps is limited to 40 in IRIS/RDA, in addition.

During the first try, adjust the quality thresholds **LOG**, **CCR**, **SQI**, **SIG** to be adjusted similar to the typical operational task settings, while they can be tuned tighter for optimal quality, or relaxed modestly for optimal result availability.

The data fields in zdrCAL RAW products are thresholded with the configure settings.

```

# Pulse width index, referring to the PWs specified in
setup_dsp.conf.
zdr_cal.Task.iPW = 0

# Pulse repetition frequency (Hz).
zdr_cal.Task.fPrfHz = 1200

# Range of the first gate, range spacing, and max gate range in
signal processing (km).
zdr_cal.Task.fRangeStartKM = 0.1
zdr_cal.Task.fRangeStepKM = 0.1
zdr_cal.Task.fMaxRangeKM = 10

# Number of complete antenna rotations.
zdr_cal.Task.iNrRotations = 1

# Number of rays (inverse of Az resolution) in a rotation.
zdr_cal.Task.iNrRays = 360

# Number of pulses in a ray.
zdr_cal.Task.iSampleSize = 64

# Data resolution in bytes. Recommend:2 in long term use
zdr_cal.Task.uiBytes = 2

# Standard RDA quality criteria (all measurands LOG, CCR, SQI;
width SIG in addition)
zdr_cal.Task.fLOG_thr = 1
zdr_cal.Task.fCCR_thr = 18
zdr_cal.Task.fSQI_thr = 0.29
zdr_cal.Task.fSIG_thr = 5

# Index of the Doppler filter, specified in setup_dsp.conf.
zdr_cal.Task.iDopplerFilter = 1

```

Data Analysis

Zdr_cal applies additional quality checks in data analysis, for qualified ZDR data points to be included in offset estimation.

Note that even the lowest reflectivity data have significant signal to noise ratios as they originate at short distances (<20 km / <12.4 mi). Avoid the highest practical reflectivities due to receiver saturation at very close distances.

Note also that the default settings presume Doppler velocity is negative for incoming (falling) echoes. The minimum co-polar correlation coefficient is set, because for low correlation echoes ZDR distribution is excessively broad. Non-atmospheric echoes (RF interference, and similar) are diminished by requiring several qualified bins in each ray. It is imperative for unbiased measurement that data of full antenna rotations are included only. The fraction of incomplete (or missing) rays must be kept low.

```

# Minimum reflectivity (dBZ)
zdrCAL.Analysis.fMinimumDBZ = -15

# Maximum reflectivity (dBZ)
zdrCAL.Analysis.fMaximumDBZ = 35

# Minimum fall speed (m/s, v_rain > 0)
zdrCAL.Analysis.fMinimumV = -6

# Maximum fall speed
zdrCAL.Analysis.fMaximumV = 0.5

# Minimum co-polar correlation coefficient (RhoHV)
zdrCAL.Analysis.fMinimumRhoHV = 0.6

# Minimum number of qualified bins required in a ray
zdrCAL.Analysis.iMinBinsRay = 2

# The closest range considered (km)
zdrCAL.Analysis.fMinRangeKM = 0.850

# The fraction of missing rays allowed in the sample.
zdrCAL.Analysis.fMaxMissingRays = 0.001

```

Result Files

The **ZdrCAL** utility result files summarize the ZDR offset obtained in analysis of a given data set.

Result reporting is not bound to each radar task (that is each RAW product) performed, but the utility integrates over consecutive samples (proximate in time) until the anticipated precision passes the alarm threshold with a safety margin, or reaches the max time span. The offset estimate, its intrinsic consistency, and actual uncertainty are then evaluated, and the sample is reset.

In this scope, the results can be generated at configurable pace and quality using the following options:

0

Implies that a result file is generated for each complete integration. Result file quality flags may indicate if the result is inconsistent (**bResultValid** = 0) or if the actual uncertainty was lower than anticipated (**bResultPrecise** = 0).

1

Omits reporting inconsistent results.

2

Reports only the highest quality results.

The 5 % false alarm rate can be expected for levels >0. The tight settings tend to require smooth precipitation on the radar, and result availability is limited in dry periods.

```
# Level of result reporting:

# -1: result file from each task (RAW). Not recommended in normal use.

# 0: all available results reported in result files.

# 1: all consistent results reported in result files.

# 2: results at target accuracy (or max sample) reported, only.
zdrca1.Analysis.iReport = 1
```

Quality Settings

The **Zdrca1** utility expects homogeneously selected data input, and changes in quality settings are to be avoided.

During commissioning phase, such changes may be necessary and the utility has the default policy "YES" to switch to new quality settings and to restart a fresh analysis.

During stable operation, it is recommended to switch the policy to "NO" which allows the processing exceptional RAW files (or run special tasks) of different quality as individual runs, while keeping the current main data archive separated, that is the data and settings unchanged.

```
# Policy in case these quality criteria conflict with the history settings.

# YES: Reset the history statistics, and assume the new criteria in future
runs.

# NO: Omit the history data, the new settings used in the current sample,
only. The history unchanged.
zdrca1.Analysis.sUpdate = "YES"
```

Miscellaneous

Zdrca1 miscellaneous parameters are technical. Typical users do not need to modify them.

```
# 1=RVP Tags, 3=Antlib.
zdrca1.Misc.iAngleSource = 1
```

RAW Product Files

The **Zdrca1** utility reports **RAW** product files as intermediate results, allowing for detailed quality checks and distributed analysis.

The default setting is a typical IRIS path for polling incoming data.

When activated in the setup menu, input section, **RAW** products appear in IRIS product menu for network distribution and for visual inspection after automatic reingest.

In this operation mode, the **RAW** files are wiped automatically.

If no input pipe is configured, **RAW** files accumulate indefinitely and regular clean up is necessary.

```
# ZDRCAL RAW product directory:
zdrCAL.sRawPath = "/usr/iris_data/input/"
```

Result Files

The **ZdrCAL** utility reports result files in directory created during standard IRIS/RDA installation.

It is recommended that **ZdrCAL** result files are redirected to a dedicated data directory, such as `/usr/iris_data/zdrCAL`, which you must create.

```
# ZDRCAL results directory:
zdrCAL.sResultDirectory = "/usr/iris_data/log/"
```

Data History

The default setting of **ZdrCAL** utility is to use data history for obtaining high data availability at specified precision.

```
# ZDRCAL accumulates data over subsequent runs (recommended: YES)
zdrCAL.sRunArchive = "YES"
```

For testing purposes, you can set the utility to process each **RAW** product as an independent sample (setting "NO")

16.7 Configuring *syslog.conf* for ZdrCAL

The **ZdrCAL** utility logs calibration changes using **syslog** to put a message in the default `/var/log/messages` file.

To put the messages in a separate file, do the following.

- ▶ 1. Log in as **root**.
2. Edit the `/etc/syslog.conf` file by adding the following at the end of the file:

```
# Log user.info messages to sigmet.log
user.info /var/log/sigmet.log
```

3. Send `kill -hup` to the **syslogd** process.

17. Network Manager

17.1 Network Manager Overview

Vaisala Observation Network Manager NM10 enables remote monitoring, management and control of your weather observation networks on one central, secure, and automated platform. Easy access to all essential event, alert, observation, device status, metadata and maintenance information helps to identify and solve problems quickly ensuring continuous high-quality observations and shorter site visits with correct actions. From implementation to long-term maintenance, a network management solution optimized for your needs improves operational efficiency and reduces the lifetime cost of managing and maintaining all your observation sites.

As system delivery, NM10 is a stand-alone system installed in customer premises and configured individually for each customer. The following figure shows the available main components and interfaces of the system:




Figure 53 Vaisala Observation Network Manager Main Components and Interfaces (System Delivery)

The system includes the capability to receive status data directly from Vaisala weather radar sites.

The weather radar sites authenticate and register via HTTPS, and the status data from the radar sites shows in the NM10 web user interface after both systems have been correctly configured, including creating the authentication key in NM10.

17.2 Creating Network Manager Authentication Keys

Authentication keys are security tokens needed when establishing connections to Network Manager from other systems ("incoming authentication key") and from Network Manager to other systems ("outgoing authentication key").

Typically, the keys are needed for the connection with the AUTOSONDE, MW41, weather radar, and lightning sites. The authentication keys consist of two parts; the authentication key and the authentication secret.

You create the authentication keys in Network Manager.

- ▶ 1. Click **Security > Authentication** in the Administrator view.
A list of the existing authentication keys is displayed.
2. Click **Generate new key**.
3. A pop-up window shows the created key. Copy or export the key:
 - Copy the key from the pop-up window, including both the "incoming authentication key" and the "authentication secret".
 - or export the key to a text file by clicking **Export**. This is needed, for example, when you cannot copy the key directly to the source site software but instead have to transfer the key on a memory stick.



This is the only time that the "authentication secret" is displayed, so make sure to make a note of it either by copying or exporting it.

4. Close the pop-up window by clicking **Close**.
5. The generated "incoming authentication key" is displayed in the list. Check that the **Enabled** option is selected and continue with registering the source.

17.3 Adding a Radar Site to Network Manager

Before adding a radar site to Vaisala Observation Network Manager:

- Make sure Network Manager is installed.
- Generate the Network Manager authentication key. See [Creating Network Manager Authentication Keys \(page 290\)](#).



Network Manager requires Vaisala Weather Radar IRIS/RDA version 9.0.0 or later, installed on CentOS 7.0 or later.

- ▶ 1. Make sure the radar hardware and software is installed, configured, and fully operational.
2. If you have not done so already, in the IRIS **Setup** utility, select **License** and define the **Site Name**.
See [License and Site Information Setups \(page 192\)](#).




You must choose the site name carefully.
If the site name changes, you must request a new license from Vaisala.



For existing sites, you can retrieve the site name from the terminal window by typing: **show_machine_code**

3. If you have not done so already, in the IRIS **Setup** utility, select **License** and enter the license information provided to you by Vaisala.
4. Provide the IRIS machine code portion of the license key you entered in the previous step to Network Manager.

The following image shows an example of the machine code.



5. If you are configuring a new radar network, copy the *ant2nm.ini* file to the configuration directory with the following command:

```
cp /config/sigmet/config_template/ant2nm.ini config/
```

6. Add the following information to *ant2nm.ini*:
 - Network Manager IP address and port number, available from your system administrator
 - Network Manager keys generated in [Creating Network Manager Authentication Keys \(page 290\)](#).

See [Example ant2nm.ini File \(page 295\)](#).

7. In *ant2nm.ini*, check the **heartbeat** value for how often Network Manager expects status information from the radar.

The **heartbeat** parameter defines how often Network Manager expects status information from the radar as well as how often the radar should send status information to Network Manager.

The default value is 60 seconds.

8. In the IRIS terminal window, register the source, that is, the radar site, with Network Manager by typing the command:

```
/usr/sigmet/bin/ant2nm --register
```

Registration provides Network Manager with the site name and co-ordinates based on settings defined in the **Setup** utility.

9. Start sending radar status updates to Network Manager by typing the command:

```
systemctl start ant2nm.service
```

The **ant2nm** service runs in the background and sends antenna status to the network manager at a frequency defined by the heartbeat.

10. To make sure the radar site has connected to the Network Manager and is sending status information, type:

```
usr/sigmet/bin/ant2nm
```

If the connection works correctly, the terminal displays textual information that is returned from Network Manager.

17.4 Viewing Radar Status Information in Network Manager

Once your administrator has added a radar site to Network Manager, you can use Network Manager to monitor radar status information.

For more information, see the Network Manager documentation.

1. Select **Map** to view the status information on a map.
2. To show status information on the map, select **Additional information** and then select the site details marker for each site.
Use the left menu to select which radar status information you want to display.
The map shows the location of each radar in your network as well as the status information for the selected criteria.
3. Select **All Measurements** to view radar status information as a list.

17.5 Updating Radar Site Information for Network Manager

During the radar system and Network Manager set-up, try to enter site information as accurately as possible.

In some cases, after the initial configuration, you may need to update the heartbeat period or site information.

If you change this information, you must re-register the radar site with Network Manager.

- ▶ 1. To update the heartbeat interval, in `user/sigmet/config/ant2nm.ini`, update the **heartbeat** parameter (seconds).
The **heartbeat** parameter defines how often Network Manager expects status information from the radar as well as how often the radar should send status information to Network Manager.
The default value is 60 seconds.
- 2. To update the site coordinates select **Setup > RCP Radar Control Processor**. Under **Radar Site and Antenna Placement**, update the coordinates.
See [Radar Site and Antenna Placement \(page 172\)](#).
- 3. In rare situations, to update the **Site Name**, select **SetupLicense**.
Type a site name using up to 16 characters.



You must choose the site name carefully.
If the site name changes, you must request a new license from Vaisala.

- 4. In the IRIS terminal window, register the source, that is, the radar site, with Network Manager by typing the command:

```
/usr/sigmet/bin/ant2nm --register
```

Registration provides Network Manager with the site name and co-ordinates based on settings defined in the **Setup** utility.

17.6 Starting or Stopping the **ant2nm** Service

Normally, the **ant2nm** service runs in the background.

If there are problems with the service, try restarting it.

- ▶ 1. To check the service status, type: **systemctl status ant2nm**
- 2. To start the service, type: **systemctl start ant2nm**

3. To stop the service, type: **systemctl stop ant2nm**

17.7 Radar Status Information Available to Network Manager

Table 35 Radar Status Information Sent to Network Manager

Antenna Utility	Network Manager	Possible Values
TR Power	TR power	On Off
Radiate	Radiate	On Off
Servo Power	Servo power	On Off
Antenna Mode	Antenna mode	Local IRIS Computer
Standby	Standby	Ready Warming
Magnetron	Magnetron	Critical Fault Warning Fault Normal
Air Flow	Air flow	Critical Low Air Flow Warning Low Air Flow Normal
TR Mode	Transmit power	Local Computer
Interlock	Interlock	Critical Open Door Warning Open Door Normal
Waveguide	Waveguide	Critical Low Pressure Warning Low Pressure Normal
RCP Status	RCP Status	Critical RCP message RCP message

17.8 Example *ant2nm.ini* File

```
[NETWORK_MANAGER_IP_ADDRESS]
hostname = //IP Address
port = 8443

[NETWORK_MANAGER_KEYS]
incoming_authentication =
;enter-your-incoming_authentication, for example, ad9840f7-520f-4c26-ad9a-
b018a2e8dab0

authentication_secret =
;enter-your-authentication_secret, for example,
PNUqLFXgnr93IwYFsMIzhrmvaWzA1zdyvvByvC/vrHD+Qbt3YOSABJ
+kdGkrXfua0Tciow7qdSZBKmZRjHm/jQ==

[NETWORK_MANAGER_EVENT]
;update frequency for outputting antenna events to NM
;heartbeat in seconds. Should not be less than 10 seconds.
heartbeat = 60

[CURL_OPTIONS]
verbose = false

[ANTENNA_TO_NETWORK_MANAGER_STATUS]
ASF_TRPOWER = transmitReceivePower
ASF_RADIATE = transmitterRadiate
ASF_SERVO = servoPower
ASF_LOCAL = localControlOverride
ASF_STANDBY = standby
ASF_MAGTFLT = magnetronCurrent
ASF_LOWAIRFLOW = airFlow
ASF_TRLOCAL = transmitReceiveMode
ASF_INTERLOCK = safetyInterlocks
ASF_LOW_WGP = waveGuide
RCP_STATUS = radarControlProcessor
SUMMARY = summary
```

18. Information Utilities

18.1 Productx

The **productx** product examiner utility displays the information contained in a specified product file.

For all product types, **productx** displays:

1. Product header, including information such as the site where the ingest data came from, the date and time when the ingest data was gathered, and its size.
2. Product-specific meta-data from the header for many product types.
3. Data values from the file.
For Cartesian data files, this could be a large number of pixels. In this case it skips data to present a summary display which fits on the terminal. If you want no skipping, specify a very large terminal width, say 10000.

18.1.1 Invoking Productx

To invoke **productx**, issue the command: **productx [options] filename**

filename is the name of a product file stored in */usr/iris_data/product*.

Raw products are stored in a separate directory: */usr/iris_data/product_raw*.

Table 36 Raw Product Parameters

Parameter	Description
-help	Prints the list of options.
<filename>	Specify which ingest header file to read.
-sweep:#	Specify sweep number, origin 1. Z-axis for 3D data.
-version	Print out just the version number.
-width=#	Specify maximum line with for data display.

Each product file has a unique name based on the site ID, date, and a randomized algorithm. The first 3 letters of the file extension show the product type.

Table 37 Product File Naming

File Name Label	Product Type
BAS	BASE
BEA	BEAM
CAP	CAPPI
FCA	FCAST

File Name Label	Product Type
CAT	CATCH
DWE	DWELL
HMX	HMAX
IMG	IMAGE
LAY	LAYER
MAX	MAX
MHG	MELTING LAYER
NDP	NDOP
OTH	OTHER
PPI	PPI
RAW	RAW
RN1	RAIN1
RNN	RAINN
RHI	RHI
RTI	RTI
SHE	SHEAR
SLI	SLINE
STA	STAT
TDW	TDWR
THK	THICK
TOP	TOPS
TRA	TRACK
TXT	TEXT
USE	USER
VAD	VAD
VUS	VUSER
VIL	VIL
VVP	VVP
WND	WIND
WRN	WARN
XSE	XSECT

18.1.2 Productx Examples

PPI Example

A **PPI** product shows useful header information:

```
$ productx TMS090520180345.PPIFD6W -width:80
----- Product Summary for TMS090520180345.PPIFD6W -----
Ingest site name : 'tms_rad1', Version: 8.11
Ingest hardware name : 'tms_rad1'
Product site name : 'SIGMET, dry2', Version: 8.12
File size: 519040 bytes (Disk space: 519040 bytes)
Product type is: PPI
PCO name: DEF_DBZ, TCO name: PPIVOL_B
PRF: 840/560Hz, Wavelength: 10.63cm, Nyquist: 44.65m/s(V), 22.32m/s(W)
XMT Polarization: Horizontal, Wind:???
Constant:72.06 dB, I0:-104.82 dBm, Cal Noise:-70.66 dBm, Bandwidth:0 kHz.
ZFlags: SP_T, block_zc, attn_zc, target_zc, dpatten_zc, dpatten_z
VFlags: SP_V, 3lag_w, ship_v, unfold_vc, FALL_VC, storm_vc
Heights: Radar: 970m, Ground: 948m, Melting: 4900m MSL
Size is: 720x720x1 pixels
Scale is: 500.00 x 500.00 x 0.00 m/pixel
Center Location: 22 24.7'N, 114 7.4'E, ref: 0 meters
Projection type is: Eqdist Cylinder
Projection Reference Point: 22 24.7'N, 114 7.4'E
Equatorial Radius: 0.00000 km, Flattening: 1/0.00000
Radar position is: 360.0, 360.0 pixels
Product data type is dBZ (2)
Color count:16, Color set: 1, variable
Seams: 16452.00 16702.00 16952.00 17252.00 17402.00 17502.00 17752.00
18052.00
18202.00 18302.00 18552.00 18852.00 19002.00 19102.00 19352.00 19652.00
Maximum range: 180.0 km
PPI elevation angle: 6.60 degrees
Ingest time: 18:03:45 20 MAY 2009 HKT (-480 minutes west) DST:0/0
Volume scan time: 18:03:45 20 MAY 2009 HKT (LT: HKT -480 minutes)
Oldest Ing time: 18:03:45 20 MAY 2009 LT
Product Gen time: 19:23:31 17 JUN 2009 UTC
Input count: 1
Product is not composited.
Displaying cartesian data with skip factor 40
```

```

719:255 255 255 255 255 255 255 255 255 255 255 255 255 255 255 255 255 255
679:255 255 255 255 255 255 0 0 0 0 0 0 0 255 255 255 255 255
639:255 255 255 255 0 0 0 0 0 0 0 0 0 0 0 255 255 255
599:255 255 255 0 0 0 0 0 0 0 0 0 0 0 0 0 255 255
559:255 255 0 0 0 0 0 0 0 0 0 0 0 0 0 0 255
519:255 255 0 0 0 0 0 0 0 0 0 0 0 0 0 0 255
479:255 0 0 0 0 0 0 0 105 117 104 66 0 0 0 0 0 0
439:255 0 0 0 0 0 82 85 121 57 0 101 81 0 0 0 0 0
399:255 0 0 0 0 0 83 111 136 78 0 0 0 0 0 0 0 0
359:255 0 0 0 0 0 83 169 71 0 0 0 0 0 0 0 0 0
319:255 0 0 0 0 0 133 87 0 0 0 0 0 0 0 0 0 0
279:255 0 0 0 0 0 97 93 0 0 0 0 0 0 0 0 0 0
239:255 0 0 0 0 0 78 77 64 0 0 0 0 0 0 0 0 0
199:255 255 0 0 0 0 0 0 0 0 0 0 0 0 0 0 255
159:255 255 0 0 0 0 0 0 0 0 0 255 0 0 0 0 255
119:255 255 255 0 0 0 0 0 0 0 0 0 0 0 0 255 255
79: 255 255 255 255 0 0 0 0 0 0 0 255 0 0 255 255 255
39: 255 255 255 255 255 255 0 0 0 0 0 0 255 255 255 255 255

```

Status Example

A Status product shows the status of IRIS processes at a particular site.

```

$ productx HOT000602152122.STAZ0GN
----- Product Summary for HOT000602152122.STAZ0GN -----
Ingest site name : 'SIGMET, HOT', Version: 7.17
Ingest hardware name : 'SIGMET, HOT'
Product site name : 'SIGMET, HOT', Version: 7.17
File size: 2340 bytes (Disk space: 2340 bytes)
Product type is: Status
PCO name: SIGMET, HOT, TCO name: FAULT
PRF: 500Hz, Wavelength: 5.00cm, Nyquist: 6.25m/s(V), 6.25m/s(W)
Polarization: Horizontal, wind:??
Heights: Radar: 600m, Ground: 100m, Melting: ???m MSL
Size is: 0x0x0 pixels
Center Location: 42_33.0'N, 71_25.8'W, ref: 600 meters
Projection type is: Azimuthal Equidistant
Projection Reference Point: 42_33.0'N, 71_25.8'W
Radar position is: 0.0, 0.0 pixels
Scale is: 0.000 x 0.000 x 0.000 km/pixel
Product data type is Xhdr (0)
Maximum range: 0.0 km
Ingest time: 15:21:22 2 JUN 2000 UTC (0 minutes west) DST:0/1
Volume scan time: 15:21:22 2 JUN 2000 (LT: EDT 300 minutes)
Oldest Ing time: 15:21:22 2 JUN 2000
Product Gen time: 15:21:22 2 JUN 2000
Input count: 1
Product is not composited
Site style is: RADAR

```

```

Overall status is: FAULT
Status of IRIS_INGEST ON/Idle
Status of IRIS_INGFIO ON/NA
Status of IRIS_OUTPUT ON/NA
Status of IRIS_PRODUCT ON/Idle
Status of IRIS_WATCHDOG ON/Running
Status of IRIS_REINGEST ON/Idle
Status of IRIS_NETWORK ON/Idle
Status of IRIS_NORDRAD OFF/Stopped
Status of IRIS_SERVER ON/Idle
Status of IRIS_RIBBON OFF/Stopped
Status of IRIS_INPUT ON/Idle
Status of DSP N/A Stopped
Status of RCP Critical N/A DEAD
Status of WINDOW1 OK Idle test
Status of NETWORK1 OK Idle ToArchive2
Status of NETWORK2 OK Idle netcdf_out
Status of NETWORK3 OK Idle ToBufr
Status of NETWORK4 OK Idle ToHDF5
Status of WINDOW2 OK Idle Joe
Status of ARCHIVE1 OK Idle archive
RST mode: 'DEFAULT'
TSC mode: 'DEFAULT'
PSC mode: 'DEFAULT'
POM mode: 'DEFAULT'

```

```

Active task: ''
Active product: ''
Antenna Position, azimuth: 20.00, elevation: -0.99
Bite fault summary shows 2
Low Airflow: OK
Interlock: OK
Waveguide: OK
Top message #9, Repeats: 1
Problem starting scan at EL=6 (AZ velocity out of range)
Process: IRIS_INGEST, Name: F:202 M:3
Time: 16:34:36 30 MAY 2000
Message list contains 0 messages:

```

18.2 Rays Utility

The **rays** utility gives information about ingest files. You can choose to display information about various parameters of the ingest data.

18.2.1 Invoking Rays

To invoke **rays**, issue the command: **rays [options] filename**

filename is the name of an ingest header file stored in the directory `/usr/iris_data/ingest`.

Ingest files are named with a timestamp for when the data were gathered. For example, ingest data gathered at 10:17:30 on December 2, 1994 is stored in a file named `941202101730`.

Table 38 Ray Options

<code>-help</code>	Prints the list of options.
<code>-data:dtype</code>	Specify which data type to display.
<code>[-if:]filename</code>	Specify which ingest header file to read.
<code>-inter</code>	Run in interactive mode. This is the old style, rays then prompts for some of the options.
<code>-perf</code>	Performance test, display ray headers only.
<code>-range:#</code>	Specify starting range in km.
<code>-sweep:#</code>	Specify sweep number, origin 1.
<code>-terse</code>	Skip showing ingest header info.
<code>-width:#</code>	Specify maximum line with for data display.

To make it easier to enter the names of the ingest files, change your default directory to the ingest directory and get a listing of all the header files (with `ls *`). Select the name of a file with the mouse and paste it into the command line.

18.2.2 Headers only Example

In the following example, **rays** uses the **-perf** option to display the ray header information only. This format lets you evaluate the speed of IRIS or the signal processor and look for missing rays.

There are 2 azimuth and elevation angles recorded with each ray. These are angles at the beginning and ending of each ray.

```
$ rays -perf -terse DRY020418160516. | more
Reading file: /usr/iris_data/ingest/DRY020418160516.01dBT

# 0 Az: 359.80,0.99 El: 0.48, 0.48 Size: 967 16:05:33
# 1 Missing
# 2 Az: 0.99, 2.20 El: 0.48, 0.48 Size: 967 16:05:33
# 3 Az: 2.20, 3.38 El: 0.48, 0.48 Size: 967 16:05:33
# 4 Az: 3.38, 4.59 El: 0.48, 0.48 Size: 967 16:05:33
# 5 Az: 4.59, 5.78 El: 0.48, 0.48 Size: 967 16:05:34
# 6 Az: 5.78, 6.99 El: 0.48, 0.48 Size: 967 16:05:34
# 7 Missing
# 8 Az: 6.99, 8.17 El: 0.48, 0.48 Size: 967 16:05:34
# 9 Az: 9.38, 9.38 El: 0.48, 0.48 Size: 967 16:05:34
# 10 Az: 9.38, 10.57 El: 0.48, 0.48 Size: 967 16:05:34
# 11 Az: 10.57, 11.78 El: 0.48, 0.48 Size: 967 16:05:34
# 12 Az: 11.78, 12.96 El: 0.48, 0.48 Size: 967 16:05:34
# 13 Missing
# 14 Az: 14.17, 14.17 El: 0.48, 0.48 Size: 967 16:05:34
# 15 Az: 14.17, 15.36 El: 0.48, 0.48 Size: 967 16:05:34
# 16 Az: 15.36, 16.57 El: 0.48, 0.48 Size: 967 16:05:34
# 17 Az: 16.57, 17.75 El: 0.48, 0.48 Size: 967 16:05:34
# 18 Az: 17.75, 18.96 El: 0.48, 0.48 Size: 967 16:05:34
# 19 Az: 18.96, 18.96 El: 0.48, 0.48 Size: 967 16:05:34
# 20 Az: 18.96, 20.15 El: 0.48, 0.48 Size: 967 16:05:34
# 21 Az: 20.15, 21.36 El: 0.48, 0.48 Size: 967 16:05:34
# 22 Az: 21.36, 22.54 El: 0.48, 0.48 Size: 967 16:05:34
# 23 Az: 22.54, 23.75 El: 0.48, 0.48 Size: 967 16:05:34
# 24 Az: 23.75, 24.94 El: 0.48, 0.48 Size: 967 16:05:34
```

18.2.3 Velocity Example

You can choose any of the data parameters — V in this example — and rays then displays the header, followed by range bins starting from the specified bin.

Where no data is available for a ray, it displays **Missing**. When no data is available for a range bin within the ray, it displays a series of dashes (--.- --).

```

$ rays XXX041029121855. -data:v2 | more
[joe@localhost ingest]$ rays COX071115233217. -data:v | more
Task Summary for: COX071115233217.
Site name: 'cox-radar', Task name: 'PPI_C'
Scan: PPI, Speed: 9.00 deg/sec, Resolution:1.00 deg
Description: 'Doppler Velocity Volume Scan'
Location: 21 26.0'N 91 58.6'E, Altitude: 64 meters, Melting height:Unknown
Dpolapp config:
Volume Time: 23:32:17.442 15 NOV 2007 UTC (0 min. west) (LT: BDT -360 min.)
ZFlags: SP_T, block_zc, attn_zc, target_zc, dpatten_zc, dpatten_z
VFlags: SP_V, 3lag_w, ship_v, unfold_vc, fall_vc, storm_vc
PRF: 720/576Hz, PulseWidth: 1.00 usec (1)
BeamWidth: 1.46/1.50 deg.
Radar constant: 0.00/0.00 dB, Receiver bandwidth 0 kHz.
Calibration I0: -111.95/-113.03 dBm, with noise -79.70/-76.95 dBm.
LOG-Noise: 0.1776, Lin-Noise: 0.1776, I-Off: 0.0000, Q-Off: 0.0000
SOPRM Flags: 0x04af, LOG Slope: 0.480, Z-Cal: -36.81dBZ, H/V: 0.00 dB
Filters: Dop:6, Log:0; PntCl: 3, Thresh: 1.0 dB; Samples: 80
Processing Mode: FFT, Xmt Phase: Fixed
Zdr Threshold: LOG GDR = 0.00 dB, XDR = 0.00 dB
T Threshold: LOG LOG = 2.4 dB
Z Threshold: LOG & CSR SIG = 5.0 dB
V Threshold: SQI & CSR CSR = 15.0 dB
W Threshold: SIG & SQI & LOG SQI = 0.42
Available moments are: dBZ V
Original moments were: dBT dBZ V W
Starting range 0.125 km, range bin spacing 625 meters
There are 8 sweeps, each having 360 rays and 320 bins
Angle list: 0.0 1.5 3.0 4.5 6.0 9.0 12.0 15.0
Reading file: /usr/iris_data/ingest/COX071115233217.01V
Sweep Time: 23:32:17.442 15 NOV 2007
Starting at range 0.12 km (bin 1), bin step: 0.62 km
# 0 Az: 359.52, 0.47 El: 0.02, 0.02 Size: 320 23:32:32
--.- --.- --.- --.- --.- --.- --.- 17.3 17.3 17.3 17.3 --.- --.- --.-
# 1 Az: 0.47, 1.51 El: 0.02, 0.02 Size: 320 23:32:32
--.- --.- --.- -61.5 -61.5 -62.1 -62.1 -62.7 59.7 59.1 --.- --.- --.- --.-
# 2 Az: 1.53, 2.52 El: 0.02, 0.02 Size: 320 23:32:32
--.- --.- --.- --.- --.- --.- --.- --.- --.- --.- --.- --.- --.-
# 3 Az: 2.54, 3.50 El: 0.02, 0.02 Size: 320 23:32:32
--.- --.- --.- --.- --.- --.- --.- --.- 34.6 -38.8 -1.8 --.- --.-
# 4 Az: 3.52, 4.53 El: 0.02, 0.02 Size: 320 23:32:33
--.- --.- -31.0 -31.0 -31.0 -31.0 -31.0 -30.4 -30.4 -30.4 56.1 -1.8 -1.8 -
1.8
--More--

```

18.2.4 Extended Header Example

For shipboard systems, additional information for each ray can be stored in an extended header in the ingest file.

To display the extended header, use the `-data:xhdr` option.

```
$ rays -data:xhdr -terse -if:DRY020418160516. | more
Reading file: /usr/iris_data/ingest/DRY020418041055.01Xhdr
```

The extended header includes time recorded to the nearest millisecond.

```
Starting at range 0.00 km (bin 1), bin step: 0.30 km
# 0 Az: 359.80, 0.55 El: 0.42, 0.42 Size: 1 4:11:08.055
```

The extended header shows the antenna azimuth and elevation, the platform pitch, roll, and heading, and the derivatives of these values in degrees/second:

```
Az: 350.95 El: 0.40 Pitch: -0.13 Roll: -1.10 Head: 346.79
Vel: 18.72 deg/s 0.04 0.70 359.82 359.82
```

The extended header information is recorded from a serial data stream transmitted from RCP. Typically this is configured to transmit updates at a maximum speed of about 20 times per second. Because rays can be recorded at up to 40 rays per second, and because of pipeline delays in the serial data, the extended header azimuth can lag the actual azimuth by up to several degrees. Normally, the platform motion period is slower.

```
Tr: 2.29 El_or: 0.31 Lat: 1#section#45.5'N Long:138#section#
2.8'E Alt: 14
Cor: 3.59 Age: 291 Vel: 3.69 m/s 0.00 -0.17
```

Tr

Training angle, which is the pedestal relative azimuth of the pedestal.

El_or

Pedestal relative elevation angle.

Cor

Velocity correction (meters/second). Applied to velocity data to correct for platform motion.

Age

Time in milliseconds since this update arrived from RCP.

Vel

Platform position and motion. Altitude is in meters, and motions are in meters/second.

19. Using IRISnet

19.1 IRISnet Overview

The **IRISnet** menu provides a status monitoring and user interface for IRIS network features.

The following example shows a network architecture with radar sites and a central site with a number of displays, an analysis computer, and a **Net Manager**.




Figure 54 Example: IRISnet Menu - Network Manager View

Node Icons Symbols and Color Status Indication

There are 2 types of node icons in IRISnet:

- **Radar Sites**– Workstations that run IRIS/Radar software. These nodes have signal processors that collect data from the radar. In the case of an active IRIS control system, these nodes also have a radar control processor (RCP).
- **Analysis/Display Sites**– Workstations that are run either IRIS/Analysis or IRIS/Display software.

Each network node has a color indicating its status:

- Green - IRIS is running on the node.
- Yellow - IRIS is not running on the node because, for example, the node is turned off or disconnected from the network.
- Red - The node is mis-configured with an invalid hostname or the network host cannot be reached.

Each green IRIS site node can show two types of fault alarms:

- Red cross - Critical error, such as Radar process turned off or BITE fault.
- Yellow cross - Non-critical error.

The **Message Summary** menu of each system lists critical and non-critical faults.

Network Connection Lines and Color Status Indication

Each node may have one or more network connections to the other nodes. These are indicated by lines that are color-coded to indicate status:

- Green - Communication between the nodes is OK.
 - Red - There may be a problem with the line or with the node.
 - Yellow - The communication line cannot be sensed from your location.
- This depends on how communications are routed through the nodes. In the example figure, the IRISnet menu is run from the **RPG11** workstation. The line connection **Products** to **Display** is shown as yellow.

19.2 Starting IRISnet

1. In the terminal window, log in as either **radarop** or **observer**.
2. In the terminal window, type: **irisnet**.


19.3 Checking Network Status

The system updates the status automatically every 10 seconds.

1. To check the automatic updates, check the update cycle from the bar in upper left corner.
2. To update immediately, select **Options > Update**.

19.4 Launching IRIS Applications

Launch applications either on your workstation or remotely over the network using the **IRIS Tools** menu.



To open any of these utilities on a remote machine, the SSH key of the local machine must be copied to the remote machine so the SSH connection can be made without typing a password.

- ▶ 1. Double-click a network node icon to show the **IRIS Tools** menu for that node as shown in the example above.
2. Select an IRIS function.
 - **Setup**– the major configuration utility in IRIS (see *IRIS and RDA Utilities Guide*).
 - **Color Setup**– to configure the IRIS color scales (see *IRIS and RDA Utilities Guide*).
 - **Siris and qiris**– to start and stop IRIS.
 - **Utilities**– to start the graphical utilities menu (see *IRIS and RDA Utilities Guide*).
 - **Overlay**– to edit your background maps (see *IRIS and RDA Utilities Guide*).
 - **Real-time Display**– to see an instant radar display.
 - **Xterm**– starts a remote X-terminal.
 - **Sigaudio**– to control the Iris sound features
 - **VRibbon**– for optional IRIS/TDWR Option.
 - **Runways**– for optional IRIS/TDWR Option.
 - **Ribbon setup**– for optional IRIS/TDWR Option.

19.5 Checking Application Status

When you launch an application, you often get a **Status** menu showing the progress of the application.

For example, when you launch **giris**, the **Status** menu shows all the messages associated with starting the IRIS software.

- ▶ 1. To check status messages, select **Options > Status Menu**.
If it is blank, there are no status messages yet.
- 2. To cancel the **Status Menu**, select **Cancel**.
This does not affect the application.

19.6 Configuring Application Tools

The **IRIS Tools** menu shows the available tools for the site: the top pane shows active tools for the site, the bottom pane shows inactive tools.




Figure 55 IRISnet Tools Menu

- ▶ 1. Select **Tools > Config**.
The IRIS Tools menu appears.
- 2. To access an inactive tool, select it.
The tool moves up to the active tools pane.
- 3. To de-select a tool, select it.
The tool moves down to the inactive tool pane.
- 4. To save you changes, select **Exit Config**.
- 5. To close the configuration view without saving your changes, select **Cancel**.

19.7 Using Drawing Tools

IRISnet drawing tools allow you to draw and save your network block diagram.




Figure 56 IRISnet Drawing Tools



You must have **radarop** privileges to change the IRISnet menu.

- ▶ 1. Collect information from your system manager on the names of network nodes, what nodes are running IRIS, and so on.
2. Select **Options > Tools**.



Select **left** or **right** to define if the tool bar is displayed on the left side or the right side of IRISnet.

3. To add nodes:
 - a. Select the tool icon for either a radar site icon or an analysis/display site icon.
 - b. Move your cursor to the menu and click to plant the icon.
 - c. To position an icon, use click and drag (dragging is only available if the tool bar is displayed).
4. To name or re-name network nodes:
 - a. Switch off the **Tools**.
 - b. Double-click the node name field at the bottom of the icon
The **Server** appears.
The **Hostname** must be the name recognized by the network (as assigned by your network manager).
The **Alias Name** is the name that appears on the icon in IRISnet.



Vaisala recommends that you set the **Alias Name** to something logical like a radar location or a workstation function and that the host name is the same. You can alias hostnames as well in the Unix network configuration. Check with your network manager if you want to alias an un-friendly hostname such as `xnr-f0327` to something more recognizable such as `BOS_Radar`.

5. To connect the network nodes:
 - a. Select the line drawing tool.
 - b. Select a node attachment point.
There are 4 attachment points on a node icon – one on each side.
 - c. Drag the line over to the attachment point on another icon and release the mouse.
 - d. If you miss, re-select the line tool and try again.



After you have made connections between nodes, you can still move them. The node lines "rubber-band".

6. If you make a mistake or want to remove a node or a line, select the eraser tool and then select the object to delete.

7. IRIS provides tools for customizing your control display with a background image. If you wish to use a background image:
 - a. Select a *.gif*, such as a photograph of your headquarters so you can show the location of each computer.
Save the background image in the */usr/sigmet/config/images* directory.
 - b. Import the image to IRISnet by selecting **IRISnet > Options > Config**.
Select the *.gif* file you want to use as IRISnet background.
The *.gif* image MUST be in the *\${IRIS_CONFIG}overlay* directory.
The background GIF image filename must be the exact name of the image in the */usr/sigmet/config/images* directory. If filename is blank, no image is displayed.
 - c. Save and restart IRISnet.
 - d. Set the icons by moving the radar and computer icons so that each site is approximately at its geographical location on the map.
8. You can monitor other computers in your network, even if they do not run IRIS. They are shown as red or yellow, indicating if they are connected to the network.
9. To save your work, select **File > Save**.

19.8 Configuring Network Polling

In most cases, you do not need to change the polling scheme of IRISnet.




Figure 57 Configure Menu

1. Select **Options – Configuration**.
2. Define the **Number of polling processes**.
This is the number of background processes that wake-up after a specified number of seconds (Time between updates) and check the state of the IRIS's that are displayed in IRISnet.
The number of polling processes is 2 ... 15. The default number is 15.



If an IRIS computer is removed from the IRIS network, but IRISnet still shows the computer, the polling process that was checking the removed computer hangs for a 2 minute timeout. This leaves one less polling process for checking IRIS status. It is possible to hang IRISnet if the entire network goes down and all polling processes are in timeout.

3. Define the **Time between updates** (seconds).
This is the time in seconds the polling processes sleeps. When they wake they check the status of the IRIS's in the irisnet and then sleep again. The time between updates in seconds is 15 ... 120. The default time is 60 seconds.
4. To take the changes into effect, save, exit, and restart IRISnet

Appendix A. References

- J.J. Gourley, P. Tabry, J. Parent du Chatele, 2006: *Data Quality of the Meteo-France C-Band Polarimetric Radar*, *Journal of Atmospheric and Oceanic Technology*, Vol. 23, pp. 1340–1356
- J.C. Hubbert, F. Pratte, M. Dixon and R. Rilling, 2008: *NEXRAD Differential Reflectivity Calibration*, 24th Conference on IIPS, AMS annual meeting, New Orleans, USA
- R. Keränen, P. Puhakka, and H. Pohjola, 2008: *Multi season characteristics of the channel power balance at a polarimetric weather radar*, 5th European Conf. on Radar in Meteorology and Hydrology, Helsinki, Finland
- V.N. Bringi and V. Chandrasekar, 2001: *Polarimetric Doppler Weather Radar, Principles and Applications*, 2001. 636 pp. Cambridge University Press

Glossary

Antenna Utility

IRIS utility for manually controlling and monitoring the radar and antenna.

Ascope Utility

A diagnostic and test utility used for aligning and testing the radar and signal processor.

BITEX

Built-in test equipment software provided by IRIS.

differential reflectivity (ZDR)

Ratio between the horizontal reflectivity and the vertical reflectivity (dBZh - dBZv). ZDR depends on the asymmetry of the shape, orientation, and falling behavior of the particles. Positive values indicate more prominent horizontal echoes (such as from large raindrops), and negative values indicate more prominent vertical echoes (such as from hail and graupel).

dual-polarization

Ability of the radar to transmit and receive both horizontally (H) and vertically (V) polarized microwaves. Dual-polarization is a property of dual-polarization radars. Comparing the received dual-polarized microwaves gives detailed information on hydrometeors.

IRIS

Interactive Radar Information System. A suite of software tools for configuring, calibrating, and operating a complete weather radar system.

polarization

With respect to a transverse electromagnetic wave, the correlation between two orthogonal components of its electric or magnetic field. Polarization of electromagnetic radiation is defined by the direction of the electric field. In a dual-polarization weather radar, both horizontal and vertical polarizations can be transmitted and received simultaneously.

PW

Pulse width.

radar control processor (RCP)

Radar control processor. Controls and monitors weather radar system sub-units.

Reflectivity (Z)

Z_H - horizontal, Z_V - vertical, Z_{HV} -horizontal and vertical.

Property of the target that describes how much of the energy is reflected from the target. Radars are calibrated to directly give the reflectivity from the received backscattered energy. Unit for the reflectivity is mm^6/m^3 . The logarithmic value is in dBZ. Also called reflectivity factor.

RF

Radio frequency

RVP900

Vaisala Digital Receiver and Signal Processor RVP900. A product suite consisting of Vaisala IF Digital Receiver RVP901 and Vaisala Signal Processor RVP902.

Technical support



Contact Vaisala technical support at helpdesk@vaisala.com. Provide at least the following supporting information as applicable:

- Product name, model, and serial number
- Software/Firmware version
- Name and location of the installation site
- Name and contact information of a technical person who can provide further information on the problem

For more information, see www.vaisala.com/support.

Warranty

For standard warranty terms and conditions, see www.vaisala.com/warranty.

Please observe that any such warranty may not be valid in case of damage due to normal wear and tear, exceptional operating conditions, negligent handling or installation, or unauthorized modifications. Please see the applicable supply contract or Conditions of Sale for details of the warranty for each product.

Recycling



Recycle all applicable material.



Follow the statutory regulations for disposing of the product and packaging.

VAISALA

