

# Index

## A

AGC  
  decay code, 8–12  
  status display, 3–8  
Age, field, 4–8  
Air flow  
  field, 2–8  
  low pressure status, 8–33  
Angle, sync mode, 8–13  
Antenna  
  computer mode, 2–8  
  configuration overview, 1–4  
  control, 2–1  
  control master reset, 8–31  
  gain, 8–10  
  height, latitude, & longitude, 8–26  
  IRIS mode, 2–8  
  local mode, 2–8  
  local mode status, 8–34  
  min/max elevation, 8–26  
  position for moving platforms, 8–26  
  position mode, 2–4  
  repositioning moving speed, 8–54  
  shutdown, qant command, 2–10  
  Sun Tracking mode, 2–4 , 2–14  
  testing, 1–5 , 2–13 , 4–1  
  velocity mode, 2–4  
AntExport, 9–1  
Archive, output device, 8–75  
  DVD, 8–76  
  large disk archive (LDA), 8–76  
  MO disk, 8–76  
  tape, 8–76  
Ascope utility, 3–1  
  recording data, 3–22  
Atmospheric attenuation. *See* Gaseous  
  attenuation constant  
Attenuation, correction, 8–58  
Attenuator code, 8–18  
Automatic gain control. *See* AGC

Azimuth  
  initial mode for axis, 8–27  
  min/max velocity, 8–27  
  position indicator, 2–4

## B

Beamwidth, 8–10  
BITE  
  address field, 4–11 , 4–13  
  configuration menu, 4–7  
Broadcast, IP address, 8–20  
Byte count packet, 4–8

## C

Cache, read size, 8–62  
Calibration  
  log receiver, 11–3  
  overview, 1–7  
  reflectivity  
    automatic, 10–16  
    manual, 10–14  
    zauto7 utility, 10–1  
  signal generator, 10–18  
Centroid value signal, 8–66  
Clutter, correction, 8–57  
Clutter-to-signal ratio. *See* CSR threshold  
  level  
Coherency relationships, 3–37  
Color  
  conversion for Link output, 8–78  
  example values, 5–11  
  legend format, 5–7  
  palette configuration, 5–10  
  saturation, 5–6  
  scale select, 5–5 , 5–6  
  seam values, 5–7  
  set configuration, 5–8  
  special configuration, 5–10  
  threshold, 5–6  
Compression, for network output, 8–73  
Config, pull-down menu  
  change color set, 5–3  
  set special colors, 5–3  
Continuous, Wave button, 2–7

Control  
  bit, definitions, 8–30  
  panel, 2–6  
CSR, threshold, 3–13  
Customize  
  Bitex menu, 4–7  
  command, 4–6

## D

Data  
  truncation height, 8–51  
  width, 8–12  
DEFAULT.ASCOPE, output file, 3–21  
Delete, command, 5–6  
Device file, 8–4  
Digital, signal simulator, testing with, 3–32  
Doppler  
  mean velocity, sign check, 3–38  
  threshold. *See* SQI threshold  
  velocity spectrum plot, 3–18  
DSP  
  I and Q gain and offset pots, fine  
    adjustment, 3–36  
  I, Q, LOG gain and offset pots, coarse  
    adjustment, 3–34  
  parameter computations, 8–51  
DspExport, 9–1  
Dual-PRF, delay, 8–12

## E

Elevation  
  initial mode for axis, 8–27  
  min/max for antenna, 8–26  
  position indicator, 2–4  
  soft limits, 2–5  
Error  
  count field, 2–11  
  field, 2–5  
  permissible during scans, 8–54  
  response to fatal, 8–41  
  time, 2–11  
Example  
  color values, 5–11

open command, 5–3

## F

FCAST, maximum time difference, 8–65

## G

Gain control, fixed, 3–8  
Gaseous attenuation constant, 8–12

## H

Hardware name, 8–49  
Header, format for extended, 8–52  
Help, viewing online documentation, 1–12  
Hex ID number field, 4–8

## I

I gain and offset pots  
  coarse adjustment, 3–34  
  fine adjustment, 3–36  
I/O  
  field, 4–8  
  summary menu, 2–10  
IAGC, 8–17  
Image  
  sizing/positioning for Link output, 8–77  
  sizing/positioning for Window output, 8–70

Increment, field, 2–6  
Inertial Navigation Unit. *See* INU  
Ingest

  data source, 8–50  
  file space allocation, 8–43

Input  
  count field, 2–11  
  devices, 8–37

Interface type, 8–4  
Interference detection, during noise samples,  
  8–56

Interlock, safety status, 8–34  
Interlock, field, 2–8

INU, height offset for moving platforms,  
  8–26

Inverted velocity, 8–12

IQ Hysteresis feedback, 8–18  
IQRMS field, field, A/D C, 3–15  
IRIS  
    max number of clients, 8–41  
    style, 8–49

## L

Latitude/longitude, values for antenna, 8–26  
LDR, offset, 8–6  
Levels command, 5–5  
License, features and products, 8–48  
Linear  
    channel, A/D plots vs. range, 3–18  
    receiver, dynamic range check , 3–36  
Link, output device, 8–77  
Listing file, 8–3  
LOG  
    channel, A/D plots vs. range, 3–18  
    receiver  
        calibration, 11–3  
        gain and offset pots, coarse adjustment,  
            3–34

## M

Magnetron  
    current status, 8–34  
    field, 2–8  
Map, outlines, overlay file, 7–12  
Memory, mapped I/O, 8–40  
Menu, format, 2–3 , 4–3  
    control panel, 2–6  
    status panel, 2–8  
Movie, length for Window output, 8–70

## N

Network  
    file/filename format, 8–71  
    files queued for send, 8–65  
    signal warnings, 8–42  
    status reports, 8–34  
New command, 5–6  
Noise  
    generator control, 8–31

PRF for sample, 8–8  
sampling, 8–55  
source button, 2–7  
toggle period, 8–29

## O

Options, pull-down menu  
    I/O summary command, 2–10  
    stable platform parameters, 2–10  
    time set, 2–10  
Other-Product, file space allocation, 8–43  
Output  
    bin pattern pulsewidth, 8–15  
    count field, 2–11  
    devices  
        general specifications, 8–68  
        port number/name, 8–75  
Overlay file  
    creating, 7–20  
    example, 7–16  
    format, 7–10  
    GIF underlay , 7–13  
    header statements, 7–10  
    listing and printing, 7–7  
    map outline statements, 7–12  
    naming convention, 7–7  
    text statements, 7–11  
    underlay statements, 7–13  
    viewing, 7–8

## P

Panel, fields, 4–3  
Passive IRIS, 8–52  
Plot  
    linear channel A/D vs. range, 3–18  
    LOG channel A/D vs. range, 3–18  
    time series, 3–20  
Polarization  
    control in RCP, 8–29  
    enabling in ingest, 8–5  
    enabling in product generator, 8–62  
    status for antenna controller, 8–29  
Position  
    actual, 2–5

- mode, 2–4
- requested, 2–5
- Power spectrum window, 8–12
- Pressure, field, 2–8
- PRF, 8–8
- Printer, output device, 8–69
- Printer options, output device type, 8–68
- Priority
  - IRIS processes, 8–45
  - product scheduling, 8–66
  - transmit and receive processes, 8–24
- Processor type, 8–4
- Product
  - generation status, 8–64
  - made from partial Ingest scans, 8–61
  - receive status timeout, 8–64
  - scheduling priority, 8–66
- PROJECTION statement, overlay file, 7–10
- Pulse width change, during noise samples, 8–56
- Pulsewidth
  - control in RCP, 8–29
  - number of, 8–8
  - status for antenna controller, 8–29
  - status/control, 2–9
  - value, 8–15
  - wait time for change, 8–8

## Q

- qant command, 2–10

## R

- Radar, site ground height, 8–25
- Radar Control Processor, 8–21
- Radar Video Processor, 8–4
- Radiate
  - button, 2–7
  - toggle period, 8–28
- Range, mask spacing, 8–15
- Raw-Product, file space allocation, 8–43
- RCP
  - external mode change, 8–41
  - status field, 2–9 , 2–11

- reset button, 2–9
- shutdown status, 8–33
- testing, 4–1
- RCP8
  - network interface, 9–1
  - serial interface, 9–13
- Receiver, losses, 8–10
- Reference height, 8–62
- Repair, setup errors, 8–3
- Reports, network status, 8–34
- RHI, elevation speedup ration, 8–53
- RST, reporting modes, 8–35
- Running utilities, 1–8
  - utils menu, 1–9

## S

- Safety interlock, status, 8–34
- SAMPLE.RES, overlay file, 7–16
- Saturation, color, 5–6
- Scanning, options, 8–52
- Sensitivity Time Control. *See* STC
- Servo power
  - button, 2–7
  - control, 8–30
  - status, 8–32
- Set time button, 2–12
- Setup
  - command line option, 4–2
  - listing file, 8–3
- Shipboard systems, 2–16
- show\_machine\_code command, 8–49
- Siggen
  - calibration file, 10–18
  - continuous wave control, 8–31
  - continuous wave status, 8–32
- Signal, network warnings, 8–42
- Signal generator, button, 2–7
- Signal generator
  - control, 8–31
  - power output, 8–29
  - status, 8–32
- Signal processor
  - options, 8–12
  - overview, 1–6

Site

- name, 8–49
- name/code, 8–47
- number for AWS, 8–78

Socket, external mode change, 8–41

Speech, output for message types, 8–42

SQI, threshold, 3–13

Stable platform, 2–16

Status

- bit, definitions, 8–32
- field, 2–5

Status product, external mode change, 8–41

STC, gain control, 8–17

- status display, 3–8

Stop

- button, 2–4
- light, 2–4

Sun Tracking

- button, 2–5
- mode, 2–4 , 2–14

System time, 8–40

## T

T/R

- computer mode, 2–8
- IRIS mode, 2–8
- local mode, 2–8
- local mode status, 8–34
- power control, 8–30
- power field, 2–6
- power status, 8–32

Tag lines, type of angle syncing, 8–51

Test signal, losses, 8–10

Testing

- Digital Signal Simulator, 3–32
- safeguards, 2–13

Threshold, color, 5–6

Time

- coasting between tasks, 8–54
- elapsed since last report, 2–11
- error, 2–11
- of last report, 2–11
- reset, 2–12
- series at selected range plot, 3–20

update field, 2–11

warmup & settle for signal generator, 8–29

Time zone, 8–40

Timezone, in time packets, 8–24

TRACK, maximum time difference, 8–65

Transmitter

- power loss, 8–10
- pulsewidth power, 8–16
- radiation control, 8–30
- radiation status, 8–32
- standby status, 8–34
- warm-up, idle time, 8–57
- wavelength, 8–8

## U

UDP, port number, 8–20

Underlay, defining in overlay file, 7–13

Units, number of field, 4–8

Unrecognized site code, 8–47

## V

Velocity

- actual, 2–5
- fallspeed correction, 8–60
- mode, 2–4
- requested, 2–5
- sign, 8–12
- unfolding, 8–59

## W

WARN

- centroid value signal, 8–66
- maximum time difference, 8–65

Warning

- disable field, 4–12
- flag field, 4–12
- regions, 8–67

Waveguide pressure

- status, 8–33
- status indicator, 2–8

Wavelength transmission, 8–8

Web, setups, 8–79

Window

- output device, 8–70

password, 8–49  
power spectrum, 8–12  
Window alerts, 8–46

## **Z**

Z/R relationship, 8–61

Zauto7 utility, 10–1  
zcalib.conf, config file, 10–13  
ZDR, offset, 8–6