

Table of Contents

| | |
|---|------------|
| Preface | vii |
| 1. Introduction to IRIS Utilities | 1-1 |
| 1.1 Radar/Antenna | 1-4 |
| 1.1.1 Configuring the Antenna | 1-4 |
| 1.1.2 Monitoring the Antenna | 1-5 |
| 1.1.3 Testing the Antenna | 1-5 |
| 1.2 Signal Processor | 1-6 |
| 1.2.1 Configuring the Signal Processor | 1-6 |
| 1.2.2 Calibrating the RVP7 or RVP8 Signal Processor | 1-7 |
| 1.2.3 Monitoring the Signal Processor | 1-7 |
| 1.2.4 Testing the Signal Processor | 1-7 |
| 1.3 Running the IRIS Utilities | 1-8 |
| 1.3.1 Running the Utilities Locally from a Terminal Window | 1-8 |
| 1.3.2 Running the Utilities Locally Using the utils menu | 1-9 |
| 1.3.3 Running Utilities or the utils Menu from a Remote Workstation | 1-10 |
| 1.4 Getting Online Help | 1-12 |
| 1.4.1 Moving Around in the Document | 1-12 |
| 1.4.2 Searching for Information | 1-12 |
| 1.4.3 Printing Online Documentation | 1-13 |
| 1.4.4 Accessing Other SIGMET Online Books | 1-13 |
| 2. Antenna Utility | 2-1 |
| 2.1 Invoking Antenna | 2-2 |
| 2.2 Antenna Menu | 2-3 |
| 2.2.1 Azimuth and Elevation Section | 2-4 |
| 2.2.2 Control Panel | 2-6 |
| 2.2.3 Status Panel | 2-8 |
| 2.3 Antenna Commands | 2-10 |
| 2.3.1 I/O Summary Menu | 2-10 |
| 2.4 Testing Antenna Safeguards | 2-13 |
| 2.5 Running Antenna in Sun Tracking Mode | 2-14 |
| 2.6 Stable Platform Display | 2-16 |
| 2.6.1 Overview of Stable Platform Concepts | 2-16 |
| 2.6.2 Invoking the Stable Platform Display Section | 2-17 |
| 2.6.3 AZ/EL Graphical Display Features | 2-17 |
| 2.6.4 Stable Platform Parameters Display | 2-18 |
| 2.6.5 Sun Tracking Check of Stable Platform Corrections | 2-19 |

| | |
|--|------------|
| 3. Ascope Utility | 3-1 |
| 3.1 Invoking Ascope | 3-2 |
| 3.2 Ascope Menu | 3-3 |
| 3.2.1 Antenna Status | 3-4 |
| 3.2.2 Display Status | 3-4 |
| 3.2.3 Radar Status | 3-6 |
| 3.2.4 Processing Status | 3-8 |
| 3.2.5 Filters | 3-11 |
| 3.2.6 Calibration | 3-13 |
| 3.3 Ascope Plots | 3-16 |
| 3.3.1 Reflectivity vs. Range Plot (T and Z) | 3-16 |
| 3.3.2 Doppler Mean Velocity vs. Range Plot (V) | 3-16 |
| 3.3.3 Spectrum Width vs. Range Plot (W) | 3-17 |
| 3.3.4 ZDR vs. Range Plot (ZDR) (available with ZDR option) | 3-17 |
| 3.3.5 Linear Channel A/D vs. Range Plot (I and Q or Mag and Arg) | 3-18 |
| 3.3.6 LOG Channel A/D vs. Range Plots (ALOG) | 3-18 |
| 3.3.7 Doppler Spectrum Plot (Spec) | 3-18 |
| 3.3.8 Time Series at a Selected Range (I, Q, and LOG) | 3-20 |
| 3.4 Ascope Commands | 3-21 |
| 3.5 Data Recording and Playback | 3-22 |
| 3.5.1 The “Record” Menu | 3-22 |
| 3.5.2 The “Playback” Menu | 3-25 |
| 3.5.3 Format of the Recorded Data | 3-27 |
| 3.6 The Digital Signal Simulator | 3-29 |
| 3.6.1 Testing with the Digital Signal Simulator | 3-32 |
| 3.7 Ascope Checkup Procedures | 3-34 |
| 3.7.1 Coarse Adjustment of the Gain and Offset Pots | 3-34 |
| 3.7.2 Fine Adjustment of the Gain and Offset Pots | 3-36 |
| 3.7.3 Phase and Amplitude Stability Checks | 3-36 |
| 3.7.4 Doppler Velocity Sign Check | 3-38 |
| 4. Bitex Utility | 4-1 |
| 4.1 Invoking Bitex | 4-2 |
| 4.2 Bitex Window | 4-3 |
| 4.3 Bitex Commands | 4-6 |
| 4.4 Customizing of Bitex | 4-7 |
| 4.4.1 General – Bitex Customization Options | 4-7 |
| 4.4.2 Bitex Customization Tools | 4-8 |
| 4.4.3 Bitex Panel Options | 4-9 |
| 4.4.4 Bitex Data Point Configuration | 4-10 |

| | |
|--|------------|
| 5. Color Setup Utility | 5-1 |
| 5.1 Overview | 5-1 |
| 5.2 Starting color_setup | 5-3 |
| 5.3 Configuring a Color Scale | 5-3 |
| 5.4 Configuring a Color Set | 5-8 |
| 5.5 Configuring the Color Palette | 5-10 |
| 5.6 Configuring the Special Colors | 5-10 |
| 5.7 Example Values to Get Started | 5-11 |
| 6. Dspix Utility | 6-1 |
| 6.1 Invoking Dspix | 6-1 |
| 6.2 Dspix Commands and Prompts | 6-1 |
| 6.3 Sample Dspix Session | 6-2 |
| 7. Overlay Utility | 7-1 |
| 7.1 Invoking Overlay | 7-2 |
| 7.2 Listing and Printing Overlay Files | 7-7 |
| 7.3 Viewing an Overlay with overlay | 7-8 |
| 7.4 Format of Overlay Files | 7-10 |
| 7.4.1 Overlay Header | 7-10 |
| 7.4.2 Text Strings and Bitmap Icons | 7-11 |
| 7.4.3 Map Outlines | 7-12 |
| 7.4.4 Layer Functions and Command | 7-12 |
| 7.4.5 Solid Underlay Regions | 7-13 |
| 7.4.6 GIF Underlay Regions | 7-13 |
| 7.4.7 Example of an Overlay File | 7-16 |
| 7.5 Format of catchment files | 7-19 |
| 7.6 Creating and Editing Overlay Files | 7-20 |
| 8. Setup Utility | 8-1 |
| 8.1 Invoking Setup and Built-In Error Checking | 8-2 |
| 8.2 Radar Video Processor | 8-4 |
| 8.2.1 System Type | 8-4 |
| 8.2.2 Optional Data Parameters | 8-5 |
| 8.2.3 System Parameters | 8-8 |
| 8.2.4 Calibration | 8-10 |
| 8.2.5 Signal Processing Options | 8-12 |
| 8.2.6 Data Simulations | 8-14 |
| 8.2.7 Pulswidth Definitions | 8-15 |
| 8.2.8 Digital IF Gain Control (RVP6 REV.B) | 8-17 |
| 8.2.9 Real Time Display (RTD) | 8-19 |
| 8.3 Radar Control Processor | 8-21 |
| 8.3.1 Process Control and Serial I/O | 8-21 |

| | | |
|-------|--------------------------------------|------|
| 8.3.2 | Radar Site and Antenna Placement | 8-24 |
| 8.3.3 | Antenna Characteristics | 8-25 |
| 8.3.4 | Control and Support Features | 8-26 |
| 8.3.5 | Control Bit Definitions | 8-28 |
| 8.3.6 | Status Bit Definitions | 8-30 |
| 8.3.7 | Network Status Reports | 8-32 |
| 8.3.8 | RST Mode Requests | 8-33 |
| 8.4 | IRIS Input Setups | 8-35 |
| 8.5 | IRIS General Setups | 8-38 |
| 8.5.1 | Modes and Protocols | 8-38 |
| 8.5.2 | Speech and Signaling | 8-39 |
| 8.5.3 | File System Quotas | 8-41 |
| 8.5.4 | Run-Time Priorities | 8-43 |
| 8.5.5 | Window Alert Configuration | 8-44 |
| 8.5.6 | Site Names and Site Codes | 8-45 |
| 8.6 | License Setups | 8-46 |
| 8.7 | IRIS INGEST Setups | 8-48 |
| 8.7.1 | Data Source Selection | 8-48 |
| 8.7.2 | Signal Processing and Data Storage | 8-49 |
| 8.7.3 | Scanning Options | 8-50 |
| 8.7.4 | DSP Noise Sampling | 8-53 |
| 8.7.5 | Transmitter Control | 8-54 |
| 8.7.6 | Clutter Suppression | 8-55 |
| 8.7.7 | Intervening Attenuation | 8-55 |
| 8.7.8 | Unfolding of Velocity | 8-56 |
| 8.7.9 | Velocity Fallspeed Correction | 8-57 |
| 8.8 | IRIS PRODUCT Setups | 8-58 |
| 8.8.1 | Product Generation | 8-58 |
| 8.8.2 | Reflectivity Profile and Wind | 8-60 |
| 8.8.3 | Status Products | 8-61 |
| 8.8.4 | Product Transmission and Display | 8-62 |
| 8.8.5 | Product Scheduling Priority | 8-63 |
| 8.8.6 | Warning Regions | 8-64 |
| 8.9 | IRIS Output Devices Setups | 8-66 |
| 8.9.1 | Output Device General Specifications | 8-66 |
| 8.9.2 | Printer Specific Parameters | 8-67 |
| 8.9.3 | Window Specific Parameters | 8-68 |
| 8.9.4 | Network Specific Parameters | 8-69 |
| 8.9.5 | Archive Specific Parameters | 8-73 |
| 8.9.6 | Link Specific Parameters | 8-75 |
| 8.9.7 | Link Device Parameters | 8-75 |
| 8.10 | IRIS Web Setups | 8-77 |

| | |
|--|----------------|
| 9. RVP8/RCP8 Network Export Utilities | 9-1 |
| 9.1 Starting and Stopping DspExport and AntExport | 9-2 |
| 9.2 Example Network Configurations | 9-5 |
| 9.2.1 Case 1: Separate PC's for RVP8, RCP8 and Host (e.g., IRIS) | 9-6 |
| 9.2.2 Case 2: Separate RVP8, Combined RCP8/RCW (e.g., IRIS Host) | 9-7 |
| 9.2.3 Case 3: Combined RVP8, RCP8/RCW (e.g., IRIS Host) | 9-8 |
| 9.2.4 Case 4: Combined RVP8, IRIS Host | 9-9 |
| 9.2.5 Case 5: AMR with separate Main RCP8 and Host | 9-10 |
| 9.2.6 Case 6: Separate RVP8, RCP8, IRIS and a remote workstation | 9-11 |
| 9.3 Non-Network Antenna Angles to RVP8 | 9-12 |
| 9.4 RCP8 on Serial Interface | 9-13 |
| 10. Zauto7 Utility | 10-1 |
| 10.1 Invoking Zauto | 10-2 |
| 10.1.1 Before running zauto | 10-2 |
| 10.1.2 Invoking zauto | 10-2 |
| 10.2 Zauto Menu | 10-3 |
| 10.2.1 Calibration Parameters | 10-4 |
| 10.2.2 Calibration Plot | 10-5 |
| 10.2.3 Calibration Display | 10-7 |
| 10.2.4 Configuration Menu | 10-9 |
| 10.2.5 Results Display | 10-10 |
| 10.3 Zauto Commands | 10-13 |
| 10.4 Manually Calibrating the Signal Processor Output | 10-14 |
| 10.5 Automatically Calibrating the Signal Processor Output | 10-16 |
| 10.6 The Siggen Calibration File | 10-18 |
| 11. Zcal Utility | 11-1 |
| 11.1 Invoking Zcal | 11-1 |
| 11.2 Zcal Commands and Prompts | 11-2 |
| 11.3 Changing LOG Receiver Calibration Numbers | 11-3 |
| Index | Index-1 |

Figures

| | |
|---|-----|
| Figure 1–1: Typical Antenna Installation | 1–4 |
| Figure 1–2: Typical Signal Processor Installation | 1–6 |
| Figure 5–1: Steps in Defining a Color Scale | 5–2 |
| Figure 5–2: Color Configuration Menu Example for Velocity | 5–4 |
| Figure 5–3: Color Set Configuration Menu example for velocity. | 5–9 |
| Figure 7–1: Sample Overlay Display | 7–9 |
| Figure 8–1: Setup Utility Main Screen for IRIS and RDA | 8–2 |

Tables

| | |
|--|------|
| Table 1–1: IRIS Utilities by Function | 1–1 |
| Table 1–2: Summary of IRIS Utilities | 1–2 |
| Table 3–1: Coherency Relationships | 3–37 |
| Table 6–1: DspX Commands | 6–1 |
| Table 8–1: Input Pipes Supplied with IRIS | 8–36 |
| Table 8–2: Output Pipes Supplied with IRIS | 8–70 |
| Table 8–3: Copy Scripts Supplied with IRIS | 8–72 |
| Table 11–1: Zcal Commands | 11–2 |