

Table of Contents

Preface	vii
1. Introduction to IRIS Utilities	1-1
1.1 Radar/Antenna	1-4
1.1.1 Configuring the Antenna	1-4
1.1.2 Monitoring the Antenna	1-5
1.1.3 Testing the Antenna	1-5
1.2 Signal Processor	1-6
1.2.1 Configuring the Signal Processor	1-6
1.2.2 Calibrating the RVP7 or RVP8 Signal Processor	1-7
1.2.3 Monitoring the Signal Processor	1-7
1.2.4 Testing the Signal Processor	1-7
1.3 Running the IRIS Utilities	1-8
1.3.1 Running the Utilities Locally from a Terminal Window	1-8
1.3.2 Running the Utilities Locally Using the utils menu	1-9
1.3.3 Running Utilities or the utils Menu from a Remote Workstation	1-10
1.4 Getting Online Help	1-12
1.4.1 Moving Around in the Document	1-12
1.4.2 Searching for Information	1-12
1.4.3 Printing Online Documentation	1-13
1.4.4 Accessing Other SIGMET Online Books	1-13
2. Antenna Utility	2-1
2.1 Invoking Antenna	2-2
2.2 Antenna Menu	2-3
2.2.1 Azimuth and Elevation Section	2-4
2.2.2 Control Panel	2-6
2.2.3 Status Panel	2-8
2.3 Antenna Commands	2-10
2.3.1 I/O Summary Menu	2-10
2.4 Testing Antenna Safeguards	2-13
2.5 Running Antenna in Sun Tracking Mode	2-14
2.6 Stable Platform Display	2-16
2.6.1 Overview of Stable Platform Concepts	2-16
2.6.2 Invoking the Stable Platform Display Section	2-17
2.6.3 AZ/EL Graphical Display Features	2-17
2.6.4 Stable Platform Parameters Display	2-18
2.6.5 Sun Tracking Check of Stable Platform Corrections	2-19

3. Ascope Utility	3-1
3.1 Invoking Ascope	3-2
3.2 Ascope Menu	3-3
3.2.1 Antenna Status	3-4
3.2.2 Display Status	3-4
3.2.3 Radar Status	3-6
3.2.4 Processing Status	3-8
3.2.5 Filters	3-11
3.2.6 Calibration	3-13
3.3 Ascope Plots	3-16
3.3.1 Reflectivity vs. Range Plot (T and Z)	3-16
3.3.2 Doppler Mean Velocity vs. Range Plot (V)	3-16
3.3.3 Spectrum Width vs. Range Plot (W)	3-17
3.3.4 ZDR vs. Range Plot (ZDR) (available with ZDR option)	3-17
3.3.5 Linear Channel A/D vs. Range Plot (I and Q or Mag and Arg)	3-18
3.3.6 LOG Channel A/D vs. Range Plots (ALOG)	3-18
3.3.7 Doppler Spectrum Plot (Spec)	3-18
3.3.8 Time Series at a Selected Range (I, Q, and LOG)	3-20
3.4 Ascope Commands	3-21
3.5 Data Recording and Playback	3-22
3.5.1 The “Record” Menu	3-22
3.5.2 The “Playback” Menu	3-25
3.5.3 Format of the Recorded Data	3-27
3.6 The Digital Signal Simulator	3-29
3.6.1 Testing with the Digital Signal Simulator	3-32
3.7 Ascope Checkup Procedures	3-34
3.7.1 Coarse Adjustment of the Gain and Offset Pots	3-34
3.7.2 Fine Adjustment of the Gain and Offset Pots	3-36
3.7.3 Phase and Amplitude Stability Checks	3-36
3.7.4 Doppler Velocity Sign Check	3-38
4. Bitex Utility	4-1
4.1 Invoking Bitex	4-2
4.2 Bitex Window	4-3
4.3 Bitex Commands	4-6
4.4 Customizing of Bitex	4-7
4.4.1 General – Bitex Customization Options	4-7
4.4.2 Bitex Customization Tools	4-8
4.4.3 Bitex Panel Options	4-9
4.4.4 Bitex Data Point Configuration	4-10

5. Color Setup Utility	5-1
5.1 Overview	5-1
5.2 Starting color_setup	5-3
5.3 Configuring a Color Scale	5-3
5.4 Configuring a Color Set	5-8
5.5 Configuring the Color Palette	5-10
5.6 Configuring the Special Colors	5-10
5.7 Example Values to Get Started	5-11
6. Dspix Utility	6-1
6.1 Invoking Dspix	6-1
6.2 Dspix Commands and Prompts	6-1
6.3 Sample Dspix Session	6-2
7. Overlay Utility	7-1
7.1 Invoking Overlay	7-2
7.2 Listing and Printing Overlay Files	7-7
7.3 Viewing an Overlay with overlay	7-8
7.4 Format of Overlay Files	7-10
7.4.1 Overlay Header	7-10
7.4.2 Text Strings and Bitmap Icons	7-11
7.4.3 Map Outlines	7-12
7.4.4 Layer Functions and Command	7-12
7.4.5 Solid Underlay Regions	7-13
7.4.6 GIF Underlay Regions	7-13
7.4.7 Example of an Overlay File	7-16
7.5 Format of catchment files	7-19
7.6 Creating and Editing Overlay Files	7-20
8. Setup Utility	8-1
8.1 Invoking Setup and Built-In Error Checking	8-2
8.2 Radar Video Processor	8-4
8.2.1 System Type	8-4
8.2.2 Optional Data Parameters	8-5
8.2.3 System Parameters	8-8
8.2.4 Calibration	8-10
8.2.5 Signal Processing Options	8-12
8.2.6 Data Simulations	8-14
8.2.7 Pulswidth Definitions	8-15
8.2.8 Digital IF Gain Control (RVP6 REV.B)	8-17
8.2.9 Real Time Display (RTD)	8-19
8.3 Radar Control Processor	8-21
8.3.1 Process Control and Serial I/O	8-21

8.3.2	Radar Site and Antenna Placement	8-24
8.3.3	Antenna Characteristics	8-25
8.3.4	Control and Support Features	8-26
8.3.5	Control Bit Definitions	8-28
8.3.6	Status Bit Definitions	8-30
8.3.7	Network Status Reports	8-32
8.3.8	RST Mode Requests	8-33
8.4	IRIS Input Setups	8-35
8.5	IRIS General Setups	8-38
8.5.1	Modes and Protocols	8-38
8.5.2	Speech and Signaling	8-39
8.5.3	File System Quotas	8-41
8.5.4	Run-Time Priorities	8-43
8.5.5	Window Alert Configuration	8-44
8.5.6	Site Names and Site Codes	8-45
8.6	License Setups	8-46
8.7	IRIS Ingest Setups	8-48
8.7.1	Data Source Selection	8-48
8.7.2	Signal Processing and Data Storage	8-49
8.7.3	Scanning Options	8-50
8.7.4	DSP Noise Sampling	8-53
8.7.5	Transmitter Control	8-55
8.7.6	Clutter Suppression	8-55
8.7.7	Intervening Attenuation	8-56
8.7.8	Unfolding of Velocity	8-57
8.7.9	Velocity Fallspeed Correction	8-58
8.8	IRIS Product Setups	8-59
8.8.1	Product Generation	8-59
8.8.2	Reflectivity Profile and Wind	8-61
8.8.3	Status Products	8-62
8.8.4	Product Transmission and Display	8-63
8.8.5	Product Scheduling Priority	8-64
8.8.6	Warning Regions	8-65
8.9	IRIS Output Devices Setups	8-67
8.9.1	Output Device General Specifications	8-67
8.9.2	Printer Specific Parameters	8-68
8.9.3	Window Specific Parameters	8-69
8.9.4	Network Specific Parameters	8-70
8.9.5	Archive Specific Parameters	8-74
8.9.6	Link Specific Parameters	8-76
8.9.7	Link Device Parameters	8-76
8.10	IRIS Web Setups	8-78

9. RVP8/RCP8 Network Export Utilities	9-1
9.1 Starting and Stopping DspExport and AntExport	9-2
9.2 Example Network Configurations	9-5
9.2.1 Case 1: Separate PC's for RVP8, RCP8 and Host (e.g., IRIS)	9-6
9.2.2 Case 2: Separate RVP8, Combined RCP8/RCW (e.g., IRIS Host)	9-7
9.2.3 Case 3: Combined RVP8, RCP8/RCW (e.g., IRIS Host)	9-8
9.2.4 Case 4: Combined RVP8, IRIS Host	9-9
9.2.5 Case 5: AMR with separate Main RCP8 and Host	9-10
9.2.6 Case 6: Separate RVP8, RCP8, IRIS and a remote workstation	9-11
9.3 Non-Network Antenna Angles to RVP8	9-12
9.4 RCP8 on Serial Interface	9-13
10. Zauto7 Utility	10-1
10.1 Invoking Zauto	10-2
10.1.1 Before running zauto	10-2
10.1.2 Invoking zauto	10-2
10.2 Zauto Menu	10-3
10.2.1 Calibration Parameters	10-4
10.2.2 Calibration Plot	10-5
10.2.3 Calibration Display	10-7
10.2.4 Configuration Menu	10-9
10.2.5 Results Display	10-10
10.3 Zauto Commands	10-13
10.4 Manually Calibrating the Signal Processor Output	10-14
10.5 Automatically Calibrating the Signal Processor Output	10-16
10.6 The Siggen Calibration File	10-18
11. Zcal Utility	11-1
11.1 Invoking Zcal	11-1
11.2 Zcal Commands and Prompts	11-2
11.3 Changing LOG Receiver Calibration Numbers	11-3
Index	Index-1

Figures

Figure 1–1: Typical Antenna Installation	1–4
Figure 1–2: Typical Signal Processor Installation	1–6
Figure 5–1: Steps in Defining a Color Scale	5–2
Figure 5–2: Color Configuration Menu Example for Velocity	5–4
Figure 5–3: Color Set Configuration Menu example for velocity.	5–9
Figure 7–1: Sample Overlay Display	7–9
Figure 8–1: Setup Utility Main Screen for IRIS and RDA	8–2

Tables

Table 1–1: IRIS Utilities by Function	1–1
Table 1–2: Summary of IRIS Utilities	1–2
Table 3–1: Coherency Relationships	3–37
Table 6–1: DspX Commands	6–1
Table 8–1: Input Pipes Supplied with IRIS	8–36
Table 8–2: Output Pipes Supplied with IRIS	8–71
Table 8–3: Copy Scripts Supplied with IRIS	8–73
Table 11–1: Zcal Commands	11–2