

# Table of Contents

<b>Preface .....</b>	<b>vii</b>
<b>1. Introduction to IRIS Utilities .....</b>	<b>1-1</b>
1.1 Radar/Antenna .....	1-4
1.1.1 Configuring the Antenna .....	1-4
1.1.2 Monitoring the Antenna .....	1-5
1.1.3 Testing the Antenna .....	1-5
1.2 Signal Processor .....	1-6
1.2.1 Configuring the Signal Processor .....	1-6
1.2.2 Calibrating the RVP7 or RVP8 Signal Processor .....	1-7
1.2.3 Monitoring the Signal Processor .....	1-7
1.2.4 Testing the Signal Processor .....	1-7
1.3 Running the IRIS Utilities .....	1-8
1.3.1 Running the Utilities Locally from a Terminal Window .....	1-8
1.3.2 Running the Utilities Locally Using the utils menu .....	1-9
1.3.3 Running Utilities or the utils Menu from a Remote Workstation .....	1-10
1.4 Getting Online Help .....	1-12
1.4.1 Moving Around in the Document .....	1-12
1.4.2 Searching for Information .....	1-12
1.4.3 Printing Online Documentation .....	1-13
1.4.4 Accessing Other SIGMET Online Books .....	1-13
<b>2. Antenna Utility .....</b>	<b>2-1</b>
2.1 Invoking Antenna .....	2-2
2.2 Antenna Menu .....	2-3
2.2.1 Azimuth and Elevation Section .....	2-4
2.2.2 Control Panel .....	2-6
2.2.3 Status Panel .....	2-8
2.3 Antenna Commands .....	2-10
2.3.1 I/O Summary Menu .....	2-10
2.4 Testing Antenna Safeguards .....	2-13
2.5 Running Antenna in Sun Tracking Mode .....	2-14
2.6 Stable Platform Display .....	2-16
2.6.1 Overview of Stable Platform Concepts .....	2-16
2.6.2 Invoking the Stable Platform Display Section .....	2-17
2.6.3 AZ/EL Graphical Display Features .....	2-17
2.6.4 Stable Platform Parameters Display .....	2-18
2.6.5 Sun Tracking Check of Stable Platform Corrections .....	2-19

<b>3. Ascope Utility</b>	<b>3-1</b>
3.1 Invoking Ascope	3-2
3.2 Ascope Menu	3-3
3.2.1 Antenna Status	3-4
3.2.2 Display Status	3-4
3.2.3 Radar Status	3-6
3.2.4 Processing Status	3-8
3.2.5 Filters	3-11
3.2.6 Calibration	3-13
3.3 Ascope Plots	3-16
3.3.1 Reflectivity vs. Range Plot (T and Z)	3-16
3.3.2 Doppler Mean Velocity vs. Range Plot (V)	3-16
3.3.3 Spectrum Width vs. Range Plot (W)	3-17
3.3.4 ZDR vs. Range Plot (ZDR) (available with ZDR option)	3-17
3.3.5 Linear Channel A/D vs. Range Plot (I and Q or Mag and Arg)	3-18
3.3.6 LOG Channel A/D vs. Range Plots (ALOG)	3-18
3.3.7 Doppler Spectrum Plot (Spec)	3-18
3.3.8 Time Series at a Selected Range (I, Q, and LOG)	3-20
3.4 Ascope Commands	3-21
3.5 Data Recording and Playback	3-22
3.5.1 The “Record” Menu	3-22
3.5.2 The “Playback” Menu	3-25
3.5.3 Format of the Recorded Data	3-27
3.6 The Digital Signal Simulator	3-29
3.6.1 Testing with the Digital Signal Simulator	3-32
3.7 Ascope Checkup Procedures	3-34
3.7.1 Coarse Adjustment of the Gain and Offset Pots	3-34
3.7.2 Fine Adjustment of the Gain and Offset Pots	3-36
3.7.3 Phase and Amplitude Stability Checks	3-36
3.7.4 Doppler Velocity Sign Check	3-38
<b>4. Bitex Utility</b>	<b>4-1</b>
4.1 Invoking Bitex	4-2
4.2 Bitex Window	4-3
4.3 Bitex Commands	4-6
4.4 Customizing of Bitex	4-7
4.4.1 General – Bitex Customization Options	4-7
4.4.2 Bitex Customization Tools	4-8
4.4.3 Bitex Panel Options	4-9
4.4.4 Bitex Data Point Configuration	4-10

<b>5. Color Setup Utility</b>	<b>5-1</b>
5.1 Overview	5-1
5.2 Starting color_setup	5-3
5.3 Configuring a Color Scale	5-3
5.4 Configuring a Color Set	5-8
5.5 Configuring the Color Palette	5-10
5.6 Configuring the Special Colors	5-10
5.7 Example Values to Get Started	5-11
<b>6. Dspix Utility</b>	<b>6-1</b>
6.1 Invoking Dspix	6-1
6.2 Dspix Commands and Prompts	6-1
6.3 Sample Dspix Session	6-2
<b>7. Overlay Utility</b>	<b>7-1</b>
7.1 Invoking Overlay	7-2
7.2 Listing and Printing Overlay Files	7-7
7.3 Viewing an Overlay with overlay	7-8
7.4 Format of Overlay Files	7-10
7.4.1 Overlay Header	7-10
7.4.2 Text Strings and Bitmap Icons	7-11
7.4.3 Map Outlines	7-12
7.4.4 Layer Functions and Command	7-12
7.4.5 Solid Underlay Regions	7-13
7.4.6 GIF Underlay Regions	7-13
7.4.7 Example of an Overlay File	7-16
7.5 Format of catchment files	7-19
7.6 Creating and Editing Overlay Files	7-20
<b>8. Setup Utility</b>	<b>8-1</b>
8.1 Invoking Setup and Built-In Error Checking	8-2
8.2 Radar Video Processor	8-4
8.2.1 System Type	8-4
8.2.2 Optional Data Parameters	8-5
8.2.3 System Parameters	8-8
8.2.4 Calibration	8-10
8.2.5 Signal Processing Options	8-12
8.2.6 Data Simulations	8-14
8.2.7 Pulswidth Definitions	8-15
8.2.8 Digital IF Gain Control (RVP6 REV.B)	8-17
8.2.9 Real Time Display (RTD)	8-19
8.3 Radar Control Processor	8-21
8.3.1 Interface to RCP	8-21

8.3.2	Advanced Interface Features .....	8-24
8.3.3	Radar Site and Antenna Placement .....	8-25
8.3.4	Antenna Characteristics .....	8-26
8.3.5	Control and Support Features .....	8-28
8.3.6	Control Bit Definitions .....	8-30
8.3.7	Status Bit Definitions .....	8-32
8.3.8	Network Status Reports .....	8-34
8.3.9	RST Mode Requests .....	8-35
8.4	IRIS Input Setups .....	8-37
8.5	IRIS General Setups .....	8-40
8.5.1	Modes and Protocols .....	8-40
8.5.2	Speech and Signaling .....	8-41
8.5.3	File System Quotas .....	8-43
8.5.4	Run-Time Priorities .....	8-45
8.5.5	Window Alert Configuration .....	8-46
8.5.6	Site Names and Site Codes .....	8-47
8.6	License Setups .....	8-48
8.7	IRIS Ingest Setups .....	8-50
8.7.1	Data Source Selection .....	8-50
8.7.2	Signal Processing and Data Storage .....	8-51
8.7.3	Scanning Options .....	8-52
8.7.4	DSP Noise Sampling .....	8-55
8.7.5	Transmitter Control .....	8-57
8.7.6	Clutter Suppression .....	8-57
8.7.7	Intervening Attenuation .....	8-58
8.7.8	Unfolding of Velocity .....	8-59
8.7.9	Velocity Fallspeed Correction .....	8-60
8.8	IRIS Product Setups .....	8-61
8.8.1	Product Generation .....	8-61
8.8.2	Reflectivity Profile and Wind .....	8-63
8.8.3	Status Products .....	8-64
8.8.4	Product Transmission and Display .....	8-65
8.8.5	Product Scheduling Priority .....	8-66
8.8.6	Warning Regions .....	8-67
8.9	IRIS Output Devices Setups .....	8-68
8.9.1	Output Device General Specifications .....	8-68
8.9.2	Printer Specific Parameters .....	8-69
8.9.3	Window Specific Parameters .....	8-70
8.9.4	Network Specific Parameters .....	8-71
8.9.5	Archive Specific Parameters .....	8-75
8.9.6	Link Specific Parameters .....	8-77
8.9.7	Link Device Parameters .....	8-77

8.10 IRIS Web Setups .....	8-79
<b>9. RVP8/RCP8 Network Export Utilities .....</b>	<b>9-1</b>
9.1 Starting and Stopping DspExport and AntExport .....	9-2
9.2 Example Network Configurations .....	9-5
9.2.1 Case 1: Separate PC's for RVP8, RCP8 and Host (e.g., IRIS) .....	9-6
9.2.2 Case 2: Separate RVP8, Combined RCP8/RCW (e.g., IRIS Host) ...	9-7
9.2.3 Case 3: Combined RVP8, RCP8/RCW (e.g., IRIS Host) .....	9-8
9.2.4 Case 4: Combined RVP8, IRIS Host .....	9-9
9.2.5 Case 5: AMR with separate Main RCP8 and Host .....	9-10
9.2.6 Case 6: Separate RVP8, RCP8, IRIS and a remote workstation .....	9-11
9.3 Non-Network Antenna Angles to RVP8 .....	9-12
9.4 RCP8 on Serial Interface .....	9-13
<b>10. Zauto7 Utility .....</b>	<b>10-1</b>
10.1 Invoking Zauto .....	10-2
10.1.1 Before running zauto .....	10-2
10.1.2 Invoking zauto .....	10-2
10.2 Zauto Menu .....	10-3
10.2.1 Calibration Parameters .....	10-4
10.2.2 Calibration Plot .....	10-5
10.2.3 Calibration Display .....	10-7
10.2.4 Configuration Menu .....	10-9
10.2.5 Results Display .....	10-10
10.3 Zauto Commands .....	10-13
10.4 Manually Calibrating the Signal Processor Output .....	10-14
10.5 Automatically Calibrating the Signal Processor Output .....	10-16
10.6 The Siggen Calibration File .....	10-18
<b>11. Zcal Utility .....</b>	<b>11-1</b>
11.1 Invoking Zcal .....	11-1
11.2 Zcal Commands and Prompts .....	11-2
11.3 Changing LOG Receiver Calibration Numbers .....	11-3
<b>Index .....</b>	<b>Index-1</b>

## Figures

Figure 1–1: Typical Antenna Installation .....	1–4
Figure 1–2: Typical Signal Processor Installation .....	1–6
Figure 5–1: Steps in Defining a Color Scale .....	5–2
Figure 5–2: Color Configuration Menu Example for Velocity .....	5–4
Figure 5–3: Color Set Configuration Menu example for velocity. ....	5–9
Figure 7–1: Sample Overlay Display .....	7–9
Figure 8–1: Setup Utility Main Screen for IRIS and RDA .....	8–2

## Tables

Table 1–1: IRIS Utilities by Function .....	1–1
Table 1–2: Summary of IRIS Utilities .....	1–2
Table 3–1: Coherency Relationships .....	3–37
Table 6–1: DspX Commands .....	6–1
Table 8–1: Input Pipes Supplied with IRIS .....	8–38
Table 8–2: Output Pipes Supplied with IRIS .....	8–72
Table 8–3: Copy Scripts Supplied with IRIS .....	8–74
Table 11–1: Zcal Commands .....	11–2