

Table of Contents

Preface	viii
1. Introduction to IRIS Products	1-1
1.1 IRIS Product Overview	1-2
2. Configuring IRIS Products	2-1
2.1 Product Configuration Menu	2-3
2.1.1 Task Summary	2-4
2.1.2 Map Projections	2-6
2.1.3 Product Parameters	2-10
2.1.4 Display Parameters	2-12
2.2 BASE: Echo Base Product	2-17
2.3 BEAM: Antenna Beam Pattern Product	2-19
2.4 CAPPI: Constant Altitude Plan Position Indicator	2-22
2.5 FCAST: Forecast	2-24
2.6 HMAX: Height of Maximum Intensity Product	2-27
2.7 MAX: Maximum Reflectivity	2-29
2.8 PPI: Plan Position Indicator	2-34
2.9 RAIN1: Hourly Rain Accumulation	2-36
2.9.1 Scheduling RAIN1 Products	2-38
2.10 RAINN: N-Hour Rain Accumulation	2-40
2.10.1 Scheduling RAINN Products	2-41
2.11 RAW: Raw Data	2-43
2.11.1 Recording RAW Data Automatically	2-44
2.12 RHI: Range Height Indicator	2-46
2.13 RTI: Range Time Indicator	2-50
2.14 SRI: Surface Rainfall Intensity	2-54
2.14.1 Input reflectivity profiles	2-56
2.14.2 Product Configuration	2-59
2.14.3 Correction example	2-61
2.15 STAT: IRIS System Status	2-64
2.16 TOPS: Echo Tops	2-65
2.17 TRACK: Track/Forecast	2-67
2.18 VIL: Vertically Integrated Liquid	2-71
2.19 VVP: Velocity Volume Processing	2-73
2.19.1 Configuring the Associated TASK	2-75
2.19.2 Producing VVP Product Output	2-75
2.20 WARN: Warning/Centroid Product	2-77
2.20.1 WARN Product Configuration Menu	2-81
2.20.2 Using the WARN Product	2-84

2.21	WIND: Wind Speed and Direction	2-85
2.22	XSECT: Cross Section	2-87
3.	Optional IRIS Products	3-1
3.1	CATCH: Subcatchments Precipitation Accumulation	3-2
3.1.1	Overview	3-2
3.1.2	CATCH Product Configuration	3-3
3.1.3	Subcatchment Definition	3-5
3.1.4	Scheduling CATCH Products	3-5
3.1.5	CATCH Product Algorithm	3-6
3.1.6	Product Display	3-7
3.2	COMP: Composite	3-9
3.2.1	Overview	3-9
3.2.2	Composite Algorithm	3-12
3.2.3	COMP Configuration Menu	3-13
3.2.4	WARN Algorithm	3-16
3.2.5	COMP Scheduling	3-17
3.3	DWELL Algorithm: Composite in Time	3-19
3.3.1	Overview	3-19
3.3.2	Dwell Algorithm Examples	3-21
3.3.3	DWELL Algorithm and Scheduling	3-24
3.3.4	Basic DWELL Algorithm Configuration	3-28
3.3.5	Target Detection: Input TASK and Product Optimization	3-32
3.3.6	Target Detection: Algorithm and Configuration	3-34
3.3.7	Target Detection: Migratory Bird Examples	3-38
3.4	NDOP: Multiple Doppler	3-46
3.4.1	Input velocity corrections	3-47
3.4.2	Product Configuration	3-49
3.4.3	Display and Algorithm Notes	3-52
3.5	SHEAR: Wind Shear	3-55
3.5.1	The SHEAR Algorithm	3-59
3.5.2	Optimizing for Microburst Detection	3-61
3.6	SLINE: Shear Line (Optional)	3-66
3.6.1	Shear Line Radar Signatures	3-70
3.6.2	The Shear Line Algorithm	3-71
4.	Scheduling Products	4-1
4.1	Product Scheduler Menu	4-2
4.2	Adding, Removing, and Editing Scheduled Products	4-6
4.3	Scheduling and Stopping Product Generation	4-7
4.4	Some Hints on Running Products	4-9

5. The Quick Look Window	5-1
5.1 Setting-Up and Starting the Quick Look Windows	5-2
5.2 General Window Layout	5-3
5.3 General Window Control/Monitoring	5-5
5.4 Selecting Products for Display	5-8
5.5 Live Action Tool- Product Generation and Display	5-10
5.6 Changing the Size of the Window and Zoom Level	5-11
5.7 Color Scale Tool	5-12
5.8 Display Options Tool	5-14
5.9 Animation or Loop Tool	5-22
5.10 Slide Show Tool	5-28
5.11 Cursor Tool	5-31
5.12 Track/Annotate Tool	5-34
5.13 Forecast Tool	5-41
5.14 Cross-Section (XSECT) Tool	5-43
5.15 Product Output Options Tool	5-48
5.15.1 VVP Output Options: Time-Height	5-49
5.15.2 VVP Output Options: Line Graphs	5-52
5.15.3 WIND and FCAST Output Options	5-54
5.15.4 CAPPI Height Selection Tool	5-55
5.15.5 NDOP Output Options	5-56
5.15.6 WARN Output Options	5-57
5.16 Printing and Exporting Displays	5-58
5.17 Window Keyboard Commands	5-59
6. Requesting Product Output	6-1
6.1 Product Output Devices and Files	6-2
6.2 Product Output Menu	6-3
6.2.1 Filter Section	6-4
6.2.2 Product List	6-7
6.3 Sending a Product to a Device	6-10
6.4 Flagging a Product	6-12
7. Performing Archive Operations	7-1
7.1 Archive Menu	7-2
7.1.1 Archive Control Area	7-3
7.1.2 Archive Log Area	7-5
7.2 Initializing a Tape or Disk for Recording	7-7
7.3 Mounting a Tape or Disk	7-9
7.4 Recording Data	7-10
7.5 Creating and Printing a Log	7-12
7.6 Retrieving Product Files from Archive	7-13

7.7	Stopping an Archive Operation	7-15
7.8	Unmounting a Tape or Disk	7-15
8.	Managing Ingest Files	8-1
8.1	Ingest Summary Menu	8-2
8.1.1	Filter Menu	8-2
8.1.2	Ingest File List	8-4
8.2	Tagging and Untagging Files	8-6
9.	Choosing Overlay Files	9-1
9.1	Overlay Menu	9-2
9.2	Assigning an Overlay to a Radar Site	9-3
A.	Basic Radar Meteorology	A-1
A.1	Introduction	A-1
A.2	Reflectivity	A-2
A.3	Geometry	A-4
A.4	Problems in interpretation of radar images	A-4
A.5	Doppler wind measurements	A-5
A.6	Clutter cancellation	A-6
B.	Product Configuration Example	B-1
B.1	Summary of Configuration Examples	B-2
B.2	Setting Up the Weather MONITOR Mode	B-4
B.3	Setting Up the Terminal Doppler Modes	B-21
C.	Radial Velocity Correction	C-1
C.1	Ship Motion Parameters and Coordinate Transformations	C-2
C.2	Radial Velocity Correction	C-3
C.3	Configuration	C-6
C.4	Testing	C-7
C.4.1	The Antenna Utility	C-7
C.4.2	The Rays Utility	C-7
C.5	In Situ Testing Suggestions	C-8
C.5.1	Dynamic Adjustment of Moment Arms	C-8
C.6	Summary of Velocity Correction Algorithm: INU Example	C-9
D.	IRIS 3D	D-1
D.1	Introduction	D-1
D.2	Using the IRIS/3D Software	D-3
D.3	Installation and Configuration	D-11

E. IRIS TDWR Features	E-1
E.1 Overview	E-1
E.1.1 Items provided with the IRIS/TDWR Option	E-1
E.1.2 IRIS/TDWR Terminology	E-2
E.1.3 IRIS/TDWR Hardware Configuration Example	E-3
E.1.4 Data Flow for Ribbon Display Generation	E-4
E.1.5 IRIS/TDWR Configuration Summary	E-5
E.2 IRIS Preparation	E-6
E.2.1 Protected Area Configuration (Arenas)	E-6
E.2.2 IRIS TASK and Product Configuration	E-8
E.2.3 IRIS Product Output Configuration	E-9
E.3 Ribbon Displays	E-11
E.3.1 What is a Ribbon Display?	E-11
E.3.2 Types of Ribbon Displays Supported by IRIS	E-11
E.3.3 Dale Ribbon Display Hardware Installation	E-12
E.3.4 Dale Ribbon Display General Use	E-13
E.3.5 IRIS Virtual Ribbon Display	E-15
E.3.6 Ribbon Display Software Configuration	E-16
E.3.7 Ribbon Display Testing with tdwr_sim	E-21
E.3.8 Summary of Ribbon Display Alert Messages	E-22
E.4 TDWR/LLWAS Integrator and Runways Utility	E-23
E.4.1 What is the “Integrator”	E-23
E.4.2 Configuring the Integrator and Runways Utility- runways.conf	E-25
E.4.3 Starting the Integrator	E-29
E.4.4 Runways Utility	E-30
F. Hydromet Raingage Correction	F-1
F.1 Overview	F-1
F.2 Hydromet Data Flow for Raingage Correction	F-2
F.3 Gage Data File Format	F-4
F.4 Configuration of RAIN1 with Raingage Correction	F-6
F.5 Algorithm for RAIN1 Gage Calibration	F-11
F.6 RAIN1 Scheduling with Gage Product	F-12
F.7 References	F-13
Index	Index-1

Figures

Figure 2-1: Example of 15-tilt Volume Scan	2-5
Figure 2-2: Color Legend Format Example	2-15
Figure 2-3: Example of MAX Display	2-30
Figure 2-4: Example of MAX Geometry	2-31
Figure 2-5: Example reflectivity profile	2-54
Figure 2-6: Example of VVP Reflectivity profile	2-57
Figure 2-7: Example Profile Correction vs. Range	2-63
Figure 2-8: Track with Two Centroids	2-68
Figure 2-9: Example of Radial Velocity vs. Azimuth Display	2-74
Figure 2-10: HAIL Warning/Centroid	2-78
Figure 2-11: Example of Warning Situation Display	2-79
Figure 2-12: Cross Section Geometry	2-88
Figure 3-1: PPI of dBZ at a Single Time	3-21
Figure 3-2: Dwell of PPI for the Previous 2 Hours Showing dBZ	3-22
Figure 3-3: Dwell of PPI for the Previous 2 Hours Showing Time (Age)	3-23
Figure 3-4: background field for 2-Hour Dwell Showing dBZ	3-26
Figure 3-5: Schematic Examples of Wind Shear	3-57
Figure 3-6: Radial Shear Algorithm Schematic	3-59
Figure 3-7: B-Scan Space (PPI surface)	3-61
Figure 3-8: Mean Velocity Shear Correction	3-62
Figure 3-9: TASK Configuration for Microburst Detection	3-64
Figure 3-10: Typical Shear Line Features	3-67
Figure 4-1: Illustration of Next-Data-Time, ALL and NEXT	4-7
Figure 4-2: Illustration of Skip Time with and All Request	4-8
Figure 9-1: Overlay Menu with Pop-Up Menu	9-3
Figure A-1: Range Bin Geometry	A-2
Figure A-2: dBZ Values for Various Phenomena	A-3
Figure A-3: Beam Height vs. Range	A-4
Figure A-4: Typical Spectrum Plot	A-7
Figure B-1: Z_120 CAPPI Product Configuration	B-4
Figure B-2: GROUND CAPPI Product Configuration	B-5
Figure B-3: MAX150 MAX Product Configuration	B-6
Figure B-4: Z_005_300 PPI Product Configuration	B-7
Figure B-5: HOURLY RAIN1 Product Configuration	B-8
Figure B-6: 06_HOURS RAINN Product Configuration	B-9
Figure B-7: STAR_RHI RHI Product Configuration	B-10
Figure B-8: RAIN TOPS Product Configuration	B-11
Figure B-9: CLOUD TOP Product Configuration	B-12
Figure B-10: VIL240 VIL Product Configuration	B-13
Figure B-11: VVP Product Configuration	B-14

Figure B-12: RWY_45 XSECT Product Configuration	B-15
Figure B-13: SEVERE WARN Product Configuration	B-16
Figure B-14: MONITOR Mode Product Schedule	B-17
Figure B-15: MONITOR Mode Radar Status Menu	B-18
Figure B-16: TD_RWY_09 and TD_RWY_27 Protected Areas	B-22
Figure B-17: TDWR TASK Configuration	B-23
Figure B-18: TDWR Task Schedule	B-24
Figure B-19: Z_010_30 PPI Product Configuration	B-25
Figure B-20: TD_009_30 SHEAR Product Configuration	B-26
Figure B-21: 010_RWY_09 SHEAR Product Configuration	B-27
Figure B-22: RWY09 WARN Product Configuration	B-28
Figure B-23: TD_RWY_09 Product Schedule	B-29
Figure C-1: Vectors used for Velocity Correction In Earth Coordinates	C-4
Figure D-1: IRIS 3D Data Flow	D-2
Figure F-1: RAIN1 Raingage Correction Data Flow	F-3
Figure F-2: Example of Rain1GageCor.conf file	F-7
Figure F-3: Radar Data Averaging about a Raingage Location	F-9

Tables

Table 1-1: IRIS Products	1-2
Table 2-1: Default Picture Resolutions	2-16
Table 2-2: Suggested Monthly Melting Height Values	2-58
Table B-1: MONITOR MENUS	B-2
Table B-2: MONITOR Products	B-2
Table B-3: TD_RWY_09 Menu Configuration Names	B-3
Table B-4: TD_RWY_09 TASKS	B-3
Table B-5: TD_RWY_09 MONITOR Products	B-3