

Index

A

Automatic Startup, 1–16

B

Backup. *See* Sigbru

Backup procedure, 1–50

HP-UX, 2–9

Linux, 2–12

C

CDE, front panel configuration, 2–6

Checkup_iris command, 3–1

D

DAT drive. *See* Sigbru

Df command, 2–4

Directory structure

anchor point, 1–3

data directories, 1–4

Disk, space requirements, 1–3

DSP, calibration procedure, 1–50

DVD. *See* Sigbru

E

EMACS, installing, 1–26

Environment variable, data directories, 1–4

F

File, ownership and mode, 1–29

checking and changing, 2–4

Framebuffer Method, A–22

G

GNU EMACS, installing, 1–26

H

hosts.equiv file, 1–8

I

in-use bits, 3–4

Inetd, linux configuring, 1–13 , A–21

Install utility, options, 1–24

IRIS_INGEST , environment variable, 1–4

IRIS_LOG, environment variable, 1–4

IRIS_OBSERVERS, environment variable,
1–11

IRIS_OPERATORS, environment variable,
1–11

IRIS_PRODUCT, environment variable, 1–4

IRIS_PRODUCT_RAW, environment vari-
able, 1–4

IRIS_TAPE_INV, environment variable, 1–4

IRIS_TEMP, environment variable, 1–4

L

Library, installation option, 1–27

Linux, installing RHEL4, A–1

Login

logout, 1–32

operator, 1–30

poweroff, 1–32

procedure, 1–30

root, 1–31

N

Network configuration, A–15

Ntp, 1–12 , A–20

O

Object module, installation option, 1–27

Observer, user account, 1–3

Operating system, minimum version require-
ments, 1–1

Operator

list of valid operators, 1–11

user account, 1–3

P

Partitioning, A–7

Passwords, 1–30
Postscript Setup menu, C–4
 image color, C–5
 image position, C–5
 printing options, C–5
 image size, C–5
 paper orientation, C–5
 paper size, C–5
 printer queue, C–4
Power off, 1–32
Printer Options, configuring
 image color, C–5
 image position, C–5
 image size, C–5
 paper orientation, C–5
 paper size, C–5
 Postscript Setup menu, C–4
 printer queue, C–4
Printer Queue, Postscript Setup menu, C–4
Printers, C–1
 configuring for IRIS, C–1
 listing with lpstat, C–3
 local print queues, C–1
 network print queues, C–2
 remote print queues, C–3
Printing Options, Postscript Setup menu, C–5

Profile file, 1–10
 template, B–1
Ps_iris command, 3–2

R

Rcp configuration, A–19
RCP8 setup summary, 1–36
RDA
 FPGA "flash", 1–33
 Kernel module, 1–33
redhat-config utilities, 2–13
Remote node, installation option, 1–25
Restart_iris command, 3–3
Restore. *See* Sigbru
 .rhosts file, 1–8
RVP8 setup summary, 1–37

S

SCSI interface, pass-through driver installation, 1–15
Serial line setup, 1–9
Show_iris command, 3–4
Show_machine_code command, 1–7
Sigbru utility, D–1
 DAT. *See* Sigbru
 devices. *See* Sigbru
 DVD. *See* Sigbru
 HDD. *See* Sigbru
Sigconfig script, A–4
sigmet_env Command, 3–1
sigmet_env, 1–7
Softplane, softplane.conf, 1–39
Software
 configuration
 introduction, 1–35
 softplane.conf, 1–39
 utilities, 1–35
 installation, reboot test, 1–34
 login, 1–30
 upgrade, download files, 1–20
 version, 1–18
Source code, installation option, 1–27
Structmap command, 3–6
su, 1–31

T

Tape drive. *See* Sigbru
Testing IRIS installation, 1–50
Time & Date, Linux, 2–12
Timezone, setting, A–6

U

User accounts, 1–3

X

X-Window , IRIS startup, 2–9