

# Index

## A

Automatic Startup, 1–15

## B

Backup. *See* Sigbru

Backup procedure, 1–48

HP-UX, 2–9

Linux, 2–12

## C

CDE, front panel configuration, 2–6

Checkup\_iris command, 3–1

## D

DAT drive. *See* Sigbru

Df command, 2–4

Directory structure

anchor point, 1–3

data directories, 1–4

Disk, space requirements, 1–3

DSP, calibration procedure, 1–48

DVD. *See* Sigbru

## E

EMACS, installing, 1–25

Environment variable, data directories, 1–4

## F

File, ownership and mode, 1–28

checking and changing, 2–4

Framebuffer Method, A–25

## G

GNU EMACS, installing, 1–25

## H

hosts.equiv file, 1–8

## I

in-use bits, 3–4

Inetd, linux configuring, A–24

Install utility, options, 1–23

IRIS\_INGEST, environment variable, 1–4

IRIS\_LOG, environment variable, 1–4

IRIS\_OBSERVERS, environment variable,  
1–11

IRIS\_OPERATORS, environment variable,  
1–11

IRIS\_PRODUCT, environment variable, 1–4

IRIS\_PRODUCT\_RAW, environment variable,  
1–4

IRIS\_TAPE\_INV, environment variable, 1–4

IRIS\_TEMP, environment variable, 1–4

## L

Library, installation option, 1–26

Linux, installing RHEL4, A–1

Login

logout, 1–31

operator, 1–29

poweroff, 1–31

procedure, 1–29

root, 1–30

## N

Network configuration, A–16

Ntp, A–23

## O

Object module, installation option, 1–26

Observer, user account, 1–3

Operating system, minimum version requirements, 1–1

Operator

list of valid operators, 1–11

user account, 1–3

## P

Partitioning, A–7

Passwords, 1–29  
Postscript Setup menu, C–4  
    image color, C–5  
    image position, C–5  
    printing options, C–5  
    image size, C–5  
    paper orientation, C–5  
    paper size, C–5  
    printer queue, C–4  
Power off, 1–31  
Printer Options, configuring  
    image color, C–5  
    image position, C–5  
    image size, C–5  
    paper orientation, C–5  
    paper size, C–5  
    Postscript Setup menu, C–4  
    printer queue, C–4  
Printer Queue, Postscript Setup menu, C–4  
Printers, C–1  
    configuring for IRIS, C–1  
    listing with lpstat, C–3  
    local print queues, C–1  
    network print queues, C–2  
    remote print queues, C–3  
Printing Options, Postscript Setup menu, C–5  
  
Profile file, 1–10  
    template, B–1  
Ps\_iris command, 3–2

## R

Rcp configuration, A–21  
RCP8 setup summary, 1–35  
RDA  
    FPGA "flash", 1–32  
    Kernel module, 1–32  
redhat-config utilities, 2–13  
Remote node, installation option, 1–24  
Restart\_iris command, 3–3  
Restore. *See* Sigbru  
    .rhosts file, 1–8  
RVP8 setup summary, 1–36

## S

SCSI interface, pass-through driver installation, 1–14  
Serial line setup, 1–9  
Show\_iris command, 3–4  
Show\_machine\_code command, 1–7  
Sigbru utility, D–1  
    DAT. *See* Sigbru  
    devices. *See* Sigbru  
    DVD. *See* Sigbru  
    HDD. *See* Sigbru  
Sigconfig script, A–4  
sigmet\_env Command, 3–1  
sigmet\_env, 1–7  
Softplane, softplane.conf, 1–38  
Software  
    configuration  
        introduction, 1–34  
        softplane.conf, 1–38  
        utilities, 1–34  
    installation, reboot test, 1–33  
    login, 1–29  
    upgrade, download files, 1–19  
    version, 1–17  
Source code, installation option, 1–26  
Structmap command, 3–6  
su, 1–30

## T

Tape drive. *See* Sigbru  
Testing IRIS installation, 1–48  
Time & Date, Linux, 2–12  
Timezone, setting, A–6

## U

User accounts, 1–3

## X

X-Window , IRIS startup, 2–9